BLISS Bikini Trimmer

Service
Service
Service

HP6376/00
HP6378/00
HP6380/00



Philips Consumer Lifestyle

ServiceManual

PRODUCT INFORMATION

Features

- Wet & dry use : In and out of the shower
- Rechargeable : Charge lasts up to 60 minutes

Accessories

- **Precision Trimmer**
- **Micro Shaver**
- **Micro Trimmer**
- **Epilator**
- **Eyebrow Comb**
- **Precision Comb**
- **Beauty bag**

Safety

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

TECHNICAL INFORMATION

- No specific issues.

DISASSEMBLY- AND RE-ASSEMBLY ADVISE

- No specific issues.

REPAIR INSTRUCTION

- No specific issues.

OPTIONAL (accessories)

- No specific issues.


Published by Philips Consumer Lifestyle Printed in the Netherlands
© Copyright reserved Subject to modification

0905

PHILIPS

HP6376/00
HP6378/00
HP6380/00

PARTS LIST & EXPLODED VIEW



Pos	Service Code	Description	HP6376	HP6378 HP6380
1	4203 035 89670	Precision Comb	x	x
2	4203 035 89680	Eyebrow Comb		x
3	4203 035 89690	Precision Trimmer	x	x
4	4203 035 89700	Micro Trimmer		x
5	4203 035 89710	Epilator		x
6	4203 035 89720	Micro Shaver + protecting cap	x	x
7	4203 035 84650	Cleaning Brush	x	x
8	4203 035 55960	Adapter - USA	x	x