
INDESIT company



Model type:
PH750T(IX)

Commercial code:
F034304

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4230270 Exploded views



4230270 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00035710				instructions - lid fitting		
000	C00097494				user inst. book it-gb-fr-es ph7		
000	C00119109				instruction book nl-bd-pt		
001	C00119201				pan grid black right ph750t		
002	C00039148				rubber buffer for pan support		
003	C00142942				pan grid black tc ph750t rohs		
004	C00052932				burner cap semi rapide		
005	C00052929				burner ring - medium		
006	C00052933				burner cap auxiliary (small) black		
007	C00052930				burner base/flame splitter - small		
008	C00018819				seal - hob/worktop		
009	C00119224		91031...		knob - black ph7		
009	C00276351	91101...			knob - p.i.ph6-9 (inox)		
010	C00039156				knob disc - spring		
011	C00119226				knob disc an ph7		
012	C00052986				thermocouple ** not for triple		
012	C00093834				screw nut m6		
013	C00052951				ignition electrode (l=700)		
014	C00052926				burner cup - medium burner		
015	C00033835				gas jet 70 - lpg/ng medium burner		
015	C00057740				gas jet ng 106 - small burner		
016	C00052960				burner fixing screw (stainless		
018	C00052927				burner cup - small burner		
019	C00052939				gas jet 50 lpg - small burner		
019	C00066166				nat gas aux. burner nozzle rapido		
020	C00113652		10129...		jet sabaf tc d131		
020	C00119170				nozzle lpg d87		
020	C00283230	10130...			nozzle met. d145/100		
021	C00095765				screw nut thermo. tc		
021	C00113400				thermocouple tc l=600mm		
021	C00119169				joint thermocouple		
022	C00090374				spark plug seal		
022	C00095465		01023...	1 x C00282425	electrode tc + o-ring l=600		
022	C00282425	01024...			electrode tc + 3.6 kw o-ring l=600		
023	C00052934				electrode clip		

4230270 Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
024	C00097487				terminal block+ignit.trasformer		
024	C00297029				terminal board assy + cable 6a		
025	C00097492				tap fixing plate		
026	C00111238				fixing bracket - tap copreci		
027	C00111240		71104...		gas tap medium/auxiliary copreci		
027	C00111241		71104...		gas tap large copreci		
027	C00111244		71104...		gas tap - triple burner 57		
027	C00262593	71105...			gas tap - large burners sabaf 39		
027	C00262594		10129...		gas tap - triple burner sabaf		
027	C00262595	71105...			gas tap - small+medium+oval		
027	C00280172	10130...			gas tap - triple burner v.90°tc		
028	C00119161				base cover ph750t		
029	C00280173				junction clamp richco		
030	C00035727			1 x C00276836	mains supply cable 3x2,5		
031	C00052952				clamp kit - hob/worktop		
032	C00052918			1 x C00143845	support bracket - glass cover		
033	C00052968				tap bracket		
034	C00097736				gas pipe ph750		
036	C00010506				sealing washer - gas elbow/pipe		
037	C00024370				elbow connection (1/2 male x 2)-		
038	C00017439				gas pipe - aluminium tube 8x1mm		
039	C00052925				burner cup - large burner		
040	C00056359				gas jet (80) lpg - large burner		
040	C00056360				gas jet 110 nat gas - large burner		
041	C00119230			1 x C00256551	working table ph750t ix		
042	C00032682				blanking plug - lid hinge hole		
043	C00052928				burner ring/flame splitter - large		
044	C00052931				burner cap rapide (large) black		
045	C00119112				grid black 2 burners ph7		
046	C00119202		10129...		burner cap centre tc shiny black		
046	C00283256	10130...			burner cap centre tc shiny black		
047	C00053174		10129...		outer burner cap black work triple		
047	C00283257	10130...			burner cap outer tc black gloss		
048	C00119171		10129...		burner base/flame split. - triple		
048	C00283228	10130...			burner base/flame split. - triple		

4230270 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
050	C00024299				hinge lh - glass lid		
051	C00025355				cover (glass lid hinge) - black		
052	C00033797				rubber buffer (lid rear) - grey		
052	C00033923				rubber buffer (lid rear) - white		
053	C00024297				hinge right - glass lid		
054	C00053196				rubber buffer - glass lid front		
055	C00097803			1 x C00118680	glass lid ph7 - white		
055	C00097805				glass lid ph7 - old white		
055	C00097807				glass lid ph7 - mirror		
055	C00097808				glass lid ph7 - black		
056	C00119160		71104...		ignition microswitch (5) ph750t		
056	C00264572	71105...			ignition microswitch (5) ph750t		
057	C00119172				burner cup - triple burner 3.8kw		
099	C00064912				screw m4x18 tsp nikelata		
099	C00111235				microswitch ring		
099	C00111239				screw m4x17tsp zinc		
099	C00119195				kit injector (gn) - natural gas		
099	C00119197				kit injector lpg ph750t		
099	C00123459				screw cblx m4-8 galv. (t20)		
099	C00142147				kit grids+splitter+burn.cap ph750t		

Electric schemes and links

Cod. 16001635901



Legend

Legend: 16001635901

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card