
INDESIT company



Model type:
SO100

Commercial code:
F034285

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:

REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics


INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

F1.451 Exploded views

matr.50405.0001




F1.451

F1.451 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00116385				user instructions booklet so100		
099	C00116389				seal		
100	C00116390				oven top		
102	C00116391				thermo-elect.activat so100		
104	C00116394				valve so100		
106	C00116395				seal, valve stem		
108	C00116398				lighting glass		
110	C00116399				oven lamp bulb		
112	C00116400				lamp-socket		
114	C00116401				inner dashboard so100		
116	C00116402				glass dashboard inox so100		
118	C00116403				right jack support		
120	C00116404				plug, cover		
125	C00116405				pipe		
126	C00116407				electrovalve		
130	C00116408				display card so100##		
134	C00116409				right column		
140	C00116410				tank		
144	C00116411				generator 1600w		
145	C00116412				generator seal so100		
146	C00116413				guide		
148	C00116414				cavity ix so10##		
150	C00116415				left column so100		
154	C00116416				heater mat so100		
156	C00116418				side, cladding so100		
164	C00116419				guide (left)		
166	C00116420				deflector		
168	C00116421				connection piece		
172	C00116422				back panel so100		
178	C00116423				motor blower		
182	C00116424				air guide		
184	C00116425				air guide		
190	C00116426				mains cable		

F2.435 Exploded views

matr.50405.0001




F2.435

F2.435 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
200	C00116430				sensor head 1040mm		
201	C00116431				sensor head 820mm		
202	C00116432				fixing bracket		
204	C00116434				temperature limiter		
205	C00116435				cable grip		
206	C00116437			1 x C00280275	enamelled door		
207	C00116438			1 x C00280036	kit screws		
210	C00116439				oven door handle inox so100		
212	C00116440				oven door glass so100		
214	C00116441				condensation trim lower door -		
216	C00116443				hook spring		
217	C00116444				screw so100		
218	C00116445			1 x C00280045	wallet of washers (x2)		
220	C00116446				left hinge		
222	C00116447				hinge right		
224	C00116448				radio interference suppressor		
228	C00116449				lower panel		
238	C00116450				oven grid		
248	C00116451				plate so100		
250	C00116452				microswitch		

Electric schemes and links

Cod. ceSO100




Legend

Legend: ceSO100

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card

Electric schemes and links

Cod. seSO100



seSO100

Legend

Legend: seSO100

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card