
INDESIT company



Model type:

HL90(IX)

Commercial code:

F027240

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes


60660p0 Exploded views



60660p0 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
102	C00059630				control box cover		
103	C00077891				ass.pulsantiera m6 (220v)		
104	C00059632				control box		
105	C00077492				gemma spia rossa 286999010t		
106	C00077547				pulsante 0-1 cr.sat.d11		

60660q0 Exploded views



60660q0 Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00084268				desc_ric_c00084268		
001	C00085314				frame x 90		
002	C00059594				metal grease filter		
012	C00079589				supporto motore (v2)		
013	C00079828				convogliatore tangenziale		
014	C00077603				girante dx (v2)		
015	C00014076				impellor fastening nut		
016	C00077604				girante sx (v2)		
017	C00032261				motor 6/40 k220-240 dx		
018	C00079525				guarnizione gomma		
019	C00079569				staffa z per supporto motore		
020	C00084269				desc_ric_c00084269		
021	C00085315				support for spring		
022	C00015764				spring		
023	C00085316				junction clamp		
024	C00010529				clip 3,5x13x6,5 (70215)		
025	C00043029				ceiling lamp in hardened glass		
026	C00079455				coperchio portalampada		
027	C00042985				lamp 40w		
028	C00026910				lampholder		
029	C00079590				supporto portalampada		
030	C00084271				desc_ric_c00084271		
031	C00135750				cable holder		
034	C00135762				rawlplug		
035	C00084273				desc_ric_c00084273		
036	C00135757				screw 4,2x44,4		
037	C00085317				casing assembly 90 inox		
038	C00085318				support hoods		
040	C00079503				flangia d150 (v2)		
041	C00073976				supply cable s.14 2x075x2100w		
042	C00084278				desc_ric_c00084278		
043	C00085319				lower chimney section inox		
044	C00085320				upper chimney section inox		
045	C00084281				desc_ric_c00084281		
046	C00084283				desc_ric_c00084283		

60660q0 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
050	C00079578				tappo doppio isolamento		
051	C00079557				rondella girante		
052	C00050421				terminal board support		
053	C00050422				terminal board cover		
055	C00015773				cable clamp		
056	C00051049				spigot adapter 150-120mm		
057	C00085322				fixing bracket		
099	C00081379			1 x C00094495	filter s30 t/f		

Electric schemes and links

Cod. se094100



Legend

Legend: se094100

AT	Ignition transformer	POT	Thermostated potentiometer
CF	Oven commutator	PT	Plate electric (Automatic)
CP	Plate commutator(Normal end Rapid)	PTC	Thermostated sensor
CT	Plate commutator(Automatic)	RCE	Grill heating element external
DCDR	Double Knob double crown burner control card	RCI	Grill heating element internal
EV	Electro Valve	RE	Energy regulator
FRON	Daschboard	RF	Oven lower heating element
ILG	Lamp switch turnspit	RG	Grill heating element
IT	Thermostated switch	RG COM	Grill heating element union
L	Line (Feed)	RV	Heating element ventilated oven
LF	Dashboard light	SA	Boiler operating led
LI	Oven light	SB	Thermostated burner led
M	Suction motor handle	SF	Warning light working
MG	Turnspit motor	SO	Probe temperature
MO	Terminal board	ST	Warning light thermostat
MUF	Oven	TH	Thermostat fixed
MV	Fan motor	TH2	Thermostated burner cooling
N	Neutral (Feed)	THR	Adjustable thermostat
PA	Ignition push	TP	Termoprotector
PE	Plate electric (Normal and Rapid)	TRAV	Support terminal board
PEL	Wall socket	TRM	Thermostated burner control card
PIF	Cooking programmer	VAP	Steam boiler heating element