
INDESIT company



Model type:
FZ1022C.1IX

Commercial code:
F039982

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4210340a Exploded views



4210340a Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00145068 | | | | quick guide touch piezo | | |
| 000 | C00145069 | | | | cooking book touch piezo | | |
| 000 | C00145718 | | | | user booklet it-gb-fr-es-pt | | |
| 000 | C00145719 | | | | user booklet nl-de | | |
| 001 | C00081571 | | | | back panel ovens | | |
| 002 | C00081573 | | | | top oven | | |
| 003 | C00089130 | | | | cooling fan 220-240 v. (ck) | | |
| 004 | C00143453 | | | | evac.conduit preassembled rohs | | |
| 005 | C00082747 | | | | thermostat 190c | | |
| 006 | C00081587 | | | | ventilation ducting | | |
| 007 | C00098400 | | | | upper element oven/grill 2700w | | |
| 008 | C00145717 | | | | eeprom hot sw 28393520000 | | |
| 009 | C00142847 | | | | main board touch rohs hot2003 | | |
| 010 | C00098559 | | | | bracket for main board | | |
| 011 | C00138851 | | | | probe | | |
| 012 | C00081582 | | | | chimney | | |
| 013 | C00142878 | | | | conversion board touch control | | |
| 014 | C00113020 | | | | spacer board digital diamond | | |
| 015 | C00145709 | | | | display board - new touch | | |
| 016 | C00114046 | | | | rubber buffer - display board - | | |
| 017 | C00094651 | | | | gasket dashboard diamond/quartz | | |
| 018 | C00145716 | | | | dashboard fz1022.1ix+support | | |
| 019 | C00095818 | | | | oven insulation 3cm | | |
| 020 | C00109677 | | | | electric oven 7cp 3cm | | |
| 021 | C00113040 | | | | oven front panel black fz1000 | | |
| 022 | C00143065 | | | | hinge roller support right rohs | | |
| 023 | C00111612 | | | | hinge for oven door right full glass | | |
| 024 | C00143112 | | | | side panel right built in ariston | | |
| 025 | C00111669 | | | | plugge right attachment hinge | | |
| 026 | C00081585 | | | | taptite screw | | |
| 027 | C00195332 | | | | oven back panel self-cleaning | | |
| 029 | C00081577 | | | 1 x C00301789 | grill pan black | | |
| 029 | C00098172 | | | 1 x C00099622 | deep tray black 446x364x56 | | |
| 030 | C00081578 | | | | oven grid | | |
| 031 | C00111662 | | | | plug third door glass | | |

4210340a Spare parts list


| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 032 | C00111659 | | | | oven metal inner door tech full | | |
| 033 | C00111677 | | | | plate clamp handle new tech | | |
| 034 | C00082473 | | | | handle spacer | | |
| 035 | C00257330 | | | | oven door glass fz61 ix ha+ | | |
| 036 | C00142032 | | | | door handle new experience inox | | |
| 037 | C00111665 | | | | third door glass full glass | | |
| 038 | C00142660 | | | | oven door inner glass & brackets | | |
| 039 | C00111664 | | | | packing inner door full glass | | |
| 040 | C00082486 | | | | oven bottom cover | | |
| 041 | C00116236 | | | 1 x C00297596 | wire runners oven shelf supp. | | |
| 042 | C00084756 | | | | fixing insert m4 | | |
| 043 | C00116235 | | | | runners - oven shelf supports | | |
| 044 | C00091781 | | | 1 x C00271907 | round securing nut - shelf runners | | |
| 045 | C00089119 | | | | screw condensation trim - lower | | |
| 046 | C00111683 | | | | condensation trim - lower door | | |
| 047 | C00081579 | 90621... | | | oven door seal | | |
| 047 | C00111687 | | 90620... | | oven door seal | | |
| 048 | C00111671 | | | | plugge left attachment hinge oven | | |
| 049 | C00111668 | | | | attachment hinge oven door full | | |
| 050 | C00111614 | | | | hinge for oven door left full glass | | |
| 051 | C00143066 | | | | lh oven door hinge support rohs | | |
| 052 | C00082487 | | | | cabinet fixing square | | |
| 053 | C00138834 | | | | round heating element | | |
| 054 | C00143111 | | | | side panel left ariston built in | | |
| 055 | C00095819 | | | | oven insulation mat - rear 3cm 7c | | |
| 056 | C00113947 | | | 1 x C00113770 | halogen oven lamp 230v-25w | | |
| 057 | C00113770 | | | | lamp-socket halogen 25w-230v | | |
| 058 | C00081601 | | 20316... | | terminal block itw x f2000 | | |
| 058 | C00271142 | 20317... | | | terminal block | | |
| 059 | C00093670 | | | | screw burner support 8mm | | |
| 059 | C00119339 | | | | rear cross beam new s2000 | | |
| 060 | C00035727 | | | 1 x C00276836 | mains supply cable 3x2,5 | | |
| 061 | C00081589 | | | | circulating fan motor 220-240v | | |
| 062 | C00097990 | | | | self-cleaning oven panel rh/lh | | |
| 063 | C00082359 | | | | turnspit motor | | |

4210340a Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 064 | C00138869 | | | | rotisserie shelf | | |
| 065 | C00082367 | | | | turnspit f2000 | | |
| 099 | C00013973 | | | | screw 8p x 12,75 tpr black | | |
| 099 | C00064912 | | | | screw m4x18 tsp nikelata | | |
| 099 | C00081583 | | | | taptite screw m4x8 | | |
| 099 | C00083853 | | | 1 x C00270746 | junction clamp | | |
| 099 | C00088347 | | | 1 x C00145442 | screw trc 3.5x25 tsp | | |

## Electric schemes and links

Cod. 16002127600



# Legend

Legend: 16002127600

| | | | |
|---|---|---|---|
| AE | Ignition transformer | PE | Plate electric (Normal and Rapid) |
| AT | Ignition transformer | PEL | Wall socket |
| CF | Oven commutator | PIF | Cooking programmer |
| CP | Plate commutator(Normal end Rapid) | POT | Thermostated potentiometer |
| CT | Plate commutator(Automatic) | PT | Termoprotector |
| DC DR | Double Knob double crown burner control card | PTC | Thermostated sensor |
| EV | Electro-Valve | RCE | Grill heating element ex- ternal |
| FC | End of cooking programmer | RCI | Grill heating element internal |
| FRONT | Daschboard | RE | Energy regulator |
| I/LF | OVEN LIGHT SWITCH | RF | Oven lower heating element |
| I/LF-MG | OVEN LIGHT SWITCH + ROTISSERIE | RG | Grill heating element |
| I/MG | TURNSPIT SWITCH | RG COM | Grill heating element un- ion |
| IL | Knobs' Lighting | RV | Heating element ventilated oven |
| ILG | Lamp switch turnspit | SA | Boiler operating led |
| IT | Thermostated switch | SB | Thermostated burner led |
| L | Line (Feed) | SF | Warning light working |
| LF | Oven light | SO | Probe temperature |
| LI | Oven light | SP | Operating Indicator Light for the Plate |
| M | Suction motor handle | ST | Warning light thermostat |
| MG | Turnspit motor | TH | Thermostat fixed |
| MO | Terminal board | TH2 | Thermostated burner cooling |
| MUFF | Oven | THR | Adjustable thermostat |
| MV | Fan motor | TP | Termoprotector |
| N | Neutral (Feed) | TRAV | Support terminal board |
| PA | Ignition push-button | TRM | Thermostated burner control card |