

0WKM070002

KENWOOD "EU" KM070
KENWOOD COOKING CHEF




64
108
107
66
67
68
69
72
110
112
113
109
114
105
106
77
76
73
74
78
79
80
104
116
115
117
118
103
100
119
120
82
84
85
86
90
75
87
121
96
122
93
125
124
99
95
98
97
94
88
89
123
127

KENWOOD
KM070 COOKING CHEF
EU KM070

Pos.	Code	Description
	KW412095	BOWL - KENLYTE
	KW715266	PLANET HUB *13T04 - SEE TECHNICAL INFORMATION IT0314
	KW714714	LID (SPLASHGUARD)
	KW715267	VERTICAL DRIVE SHAFT *13T04
	KW714713	SPLASHGUARD ASSEMBLY COMPLETE
	KW715268	HUB COVER
	KW715643	INDUCTION PCB ASSEMBLY - v2
	KW630879	GREASE - FOOD GRADE - 100g
	KW715642	INDUCTION COIL & NTC ASSEMBLY - v2
	KW715641	FAN MOTOR ASSEMBLY - v2
	KW715261	COMPLETE GEARBOX *13T04
001	KW712887	MEDIUM/HIGH SPEED OUTLET COVER ASSEMBLY
002	KW674980	MEDIUM DRIVE OUTLET SPIGOT - GREY
003	KW712889	SPIGOT SEAT PLATE
004	KW712885	TOP COVER - PRINTED Â´KENWOODÂ´
005	KW675001	FRONT GEARBOX MOUNT
006	KW712886	SLOW SPEED OUTLET COVER ASSEMBLY
007	KW712941	REED SWITCH ASSEMBLY COMPLETE (SLOW
008	KW712909	INDUCTION PCB COVER
009	KW712918	FAN MOTOR ASSEMBLY
010	KW712948	LEAD ASSEMBLY (POWER PCB LCD PCB)
011	KW674552	MEDIUM SPEED DRIVE SHAFT & WASHER
013	KW712900	HEAD LIFT LEVER ASSEMBLY
014	IT0314	VEDI INFOTECNICA
015	KW712942	REED SWITCH ASSEMBLY (HEAT GUARD)
016	KW712894	TOP COVER SEAL
017	KW712892	LOWER GEARBOX COVER
018	KW712905	EXHAUST GRILLE - CHROME
019	KW712906	RETAINING SPRING (EXHAUST GRILLE)
020	KW712952	SUPPLY CORD ASSEMBLY - EU PLUG
021	KW712891	BUFFER - PACK 3 (SLOW SPEED OUTLET KNOB)
022	KW712890	SLOW SPEED OUTER KNOB ASSEMBLY INCLUDING BUFFER
024	KW712921	INDUCTION COIL AND NTC ASSEMBLY
025	KW712920	NTC AND BOWL REED SWITCH ASSEMBLY INCLUDING COVER
026	KW712911	FOOT (PACK 6)

027	KW712910	BASE MOULDING
028	KW712919	INDUCTION PCB ASSEMBLY
029	KW710366	HEADLIFT SPRING & LATCH PLATE
033	KW712946	LEAD ASSEMBLY (CONTROL PCB POWER PCB)
034	KW712944	EARTH LEAD ASSEMBLY (PEDESTAL)
035	KW712922	POWER PCB ASSEMBLY
036	KW712923	CARRIER (POWER PCB)
037	KW712904	PEDESTAL - PRINTED Â´COOKING CHEF MAJORÂ´
038	KW675037	BODY LOCATION PIN
039	KW712896	BODY COVER
040	KW712897	BODY COVER INSERT
042	KW674746	GEARBOX TOP MOUNT
043	KW712895	BODY - WITH EARTH HOLE
044	KW712932	WAVY WASHER (TEMPERATURE CONTROL KNOB)
045	KW712931	TEMPERATURE CONTROL KNOB ASSEMBLY
046	KW712901	CIRCLIP (PACK 3) - HEAD LIFT LEVER
047	KW712954	SLOW SPEED OUTLET LEVER
049	KW712940	LCD PCB ASSEMBLY COMPLETE
050	KW712925	WAVY WASHER (SPEED CONTROL KNOB)
053	KW712924	SPEED CONTROL KNOB ASSEMBLY
054	KW712949	LEAD ASSEMBLY (CONTROL PCB LCD PCB)
055	KW712950	LEAD ASSEMBLY (HEAT GUARD / OUTLET COVER INTERLOCKS LCD PCB)
056	KW710743	MAGNET
057	KW712991	CONTROL PCB ASSEMBLY COMPLETE
058	KW712888	LATCH AND SPRING SET (MEDIUM/HIGH SPEED OUTLET COVER)
059	KW712907	HIGH TEMPERATURE SEAT PAD
060	KW712945	LEAD ASSEMBLY (INDUCTION PCB CONTROL PCB)
061	KW712908	INDUCTION COIL SUPPORT CASTING
062	KW712947	POWER LEAD ASSEMBLY (INDUCTION PCB POWER PCB)
063	KW674992	HIGH SPEED OUTLET SPIGOT - GREY
064	KW674655	GEARBOX LOCATION BOLT & WASHER (PACK 3)
066	KW712955	DOWEL TUBE AND MOUNT SET
067	KW712943	EARTH LEAD ASSEMBLY (GEARBOX)
068	KW674564	LARGE PULLEY
069	KW712953	GEARBOX UPPER COVER - WITH EARTHING HOLE
072	KW674693	GEARBOX ASSEMBLY BOLT KIT

073	KW674617	PINION GEAR ASSEMBLY
074	KW674681	IDLER GEAR ASSEMBLY & WASHERS
075	KW710409	STALL PLUG *special tool to assist with the removal & replacement of large pulley
076	KW674605	PENULTIMATE GEAR ASSEMBLY & WASHERS
077	KW712893	GEARBOX REAR SPACER
078	KW674590	OUTPUT SHAFT GEAR ASSEMBLY
079	IT0313/UK0025	VEDI INFOTECNICA
080	KW710369	GEARBOX LOWER COVER ASSEMBLY
082	KW712913	PLANET HUB ASSEMBLY INCLUDING COVER
084	KW712914	PLANET HUB SEAL - SEE TECHNICAL INFORMATION IT0314
085	KW712915	PLANET HUB COVER - SEE TECHNICAL INFORMATION IT0314
086	KW712916	PLANET HUB NUT - SEE TECHNICAL INFORMATION IT0314
090	KW712868	FLEXIBLE WIPER
093	KW713240	CLEANING BRUSH (for flexible wiper)
097	KW712870	BEARING (STIRRING TOOL)
098	KW712871	WASHER
100	KW712903	GROMMET (QUADRANT) - PACK 3
103	KW712902	QUADRANT ASSEMBLY AND BRACKET
104	KW713924	ANKARSRUM MOTOR ASSEMBLY COMPLETE - 230V
105	KW713177	PULLEY (ANKARSRUM MOTOR)
106	KW674722	DRIVE BELT
107	KW710367	MOTOR MOUNT MOULDING (ANKARSRUM MOTOR)
108	KW674801	PLASTIC WASHER - PACK 3
109	KW712884	FOLDING HANDLE - SINGLE - LEFT/RIGHT HAND SIDE
110	KW714716	SUPPORTING RING
113	KW712883	REMOVEABLE TRAY
114	AW37575001	BOWL ASSEMBLY - STAINLESS STEEL WITH HANDLES
115	KW712876	SCRAPER
116	KW712873	BOWL MAGNET ASSEMBLY AND CIRCLIP
117	KW713360	HEAT GUARD SEAL (FOR MODIFIED HEAT GUARD)
118	KW714720	HEAT GUARD ASSEMBLY WITH SPRING RETAINER
119	KW712898	HINGE PIN
120	KW712899	HEAD LIFT SPRING
123A	KW714266	FLEXIBLE BEATER - BLACK BLADE
123	KW713803	FLEXIBLE BEATER - BLACK BLADE

KENWOOD KM070 COOKING CHEF

EU KM070

123	KW714263	FLEXIBLE BEATER - GREY BLADE
124	KW713800	HIGH TEMPERATURE FLEXIBLE BEATER ASSEMBLY (NEW STYLE) INCLUDING 2 BLADES
125	KW713801	FLEXIBLE BEATER BLADE HOLDER ASSEMBLY
125	KW714262	FLEXIBLE BEATER BLADE HOLDER ASSEMBLY - GREY
126	KW713802	FLEXIBLE BEATER - GREY BLADE
127	KW712874	WORKSURFACE PROTECTION MAT