
INDESIT company



Model type:

TK 64 S (IX)

Commercial code:

F038835

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4523820 Exploded views




4523820 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00141999				user booklet it-gb-fr-de-nl-es-pt		
000	C00142000				user instruction booklet dk-no-se-		
000	C00261727				service manual		
001	C00141996				top ix##		
002	C00033103			1 x C00255958	seal - hob/worktop		
003	C00142873				keys board touch kbt rad sing rohs		
004	C00096964			1 x C00145573	keys board spring		
005	C00097003				heater, 2300w (1000w)		
006	C00260941				heater, 1200w/230v d=165		
007	C00096965				fixing spring		
008	C00141994			1 x C00142145	hob fixing squares (kit)		
009	C00261920				heater, 1800w/230v d200		
010	C00082512				junction block itw f2000		

Electric schemes and links

Cod. 16001660801




Legend

Legend: 16001660801

Electric schemes and links

Cod. 160016609



Legend

Legend: 160016609