
INDESIT company



Model type:

I5VM1AXFR

Commercial code:

F085309

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4280190R Exploded views




4280190R

Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00002478 | | | 1 x C00016138 | washer 4,1x12x1 | | |
| 001 | C00259939 | | | | back spacer | | |
| 001 | C00286743 | | | | screw 8px12.7 torx | | |
| 002 | C00118134 | | | | hob top glass ix## | | |
| 003 | C00089582 | | | | table bracket | | |
| 003 | C00089583 | | | | table bracket | | |
| 004 | C00139052 | | | | heater 1200w/230v | | |
| 005 | C00079389 | | | | blocking cross-piece for electric | | |
| 006 | C00139053 | | | | heater 1700w/230v | | |
| 007 | C00115183 | | | | side panel right inox 50x60x60 | | |
| 008 | C00115184 | | | | side panel left inox 50x60x60 | | |
| 010 | C00296854 | | | | rear panel | | |
| 011 | C00078572 | | | | top rear crosspiece | | |
| 012 | C00139052 | | | | heater 1200w/230v | | |
| 013 | C00058383 | | | | fixing spring | | |
| 014 | C00136453 | | | | brown bumper | | |
| 015 | C00065059 | | | | residual heat lights | | |
| 099 | C00082777 | | | | hinge box | | |
| 099 | C00640366 | | | | chain anchorage | | |


4280220I Exploded views



4280220I Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 003 | C00139061 | | | | thermostat, 16a 250v 230c t300 | | |
| 007 | C00039459 | | | | junction block three-phase fastex | | |
| 007 | C00082587 | | | 1 x C00039459 | terminal block 3.pole (fastex) | | |
| 010 | C00078419 | | | | upper element oven/grill | | |
| 011 | C00270941 | | | | oven insulation mat | | |
| 012 | C00078605 | | | | cavity | | |
| 014 | C00078411 | | | 1 x C00141625 | door seal long 355x310 mm 4 side | | |
| 015 | C00077461 | | | | hinge support | | |
| 016 | C00078391 | | | | enamelled drip tray black | | |
| 017 | C00296329 | | | | oven shelf | | |
| 019 | C00078402 | | | | oven back panel | | |
| 020 | C00039578 | | | | push in spring clip - thermostat | | |
| 021 | C00081585 | | | | taptite screw | | |
| 022 | C00081416 | | | | stove bottom 50 x 60 | | |
| 023 | C00016119 | | | 1 x C00055585 | foot | | |
| 030 | C00078399 | | | | base element support | | |
| 031 | C00078406 | | | | electr. protection l = 407 mm | | |
| 031 | C00256783 | | | | base element 1000w | | |
| 032 | C00077461 | | | | hinge support | | |
| 033 | C00138834 | | | | round heating element | | |
| 034 | C00082468 | | | | turnspit | | |
| 035 | C00082359 | | | | turnspit motor | | |
| 036 | C00078604 | | | | turnspit support | | |
| 037 | C00253966 | | | | oven insulation mat - rear 30mm | | |
| 038 | C00076978 | | | | oven lamp 25w 220v | | |
| 039 | C00078426 | | | | lamp assembly 25 w 230 v | | |
| 040 | C00078403 | | | | oven panel crosspiece | | |
| 041 | C00078421 | | | | fan and motor assembly 220-240 | | |
| 052 | C00078410 | | | | chimney | | |

4280410U Exploded views




4280410U Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00013413 | | | | energy regulator (hotplate) 6+0 | | |
| 002 | C00028055 | | | | pilot lamp green | | |
| 003 | C00044805 | | | | 2-pole earthing rivet | | |
| 003 | C00094651 | | | | gasket dashboard diamond/quartz | | |
| 003 | C00306288 | | | | control panel i5vm1a(x) fr | | |
| 004 | C00284675 | | | | knob disc - black piastra el./vtc | | |
| 005 | C00016035 | | | | control knob disc spring | | |
| 006 | C00304699 | | | | electrical knob black c3 | | |
| 007 | C00299110 | | | | rubber buffer upper door profile | | |
| 007 | C00304680 | | | | upper door profile fg cu.50x60 | | |
| 008 | C00301058 | | | | plug rh upper door profile | | |
| 009 | C00304677 | | | | screw trc 4,5x16 zin nera | | |
| 009 | C00304697 | | | | oven door handle bk c3 indesit | | |
| 010 | C00304681 | | | | plug rh glass door bottom | | |
| 011 | C00285238 | | | | door gum oven black (luce) | | |
| 011 | C00304723 | | | | oven door glass i5gshagxfr | | |
| 012 | C00304684 | | | | plug lh bottom door glass | | |
| 013 | C00077463 | | | | dishwarmer door inox | | |
| 013 | C00077470 | | | | black dishwarmer door support | | |
| 014 | C00081026 | | | | tongue dx | | |
| 015 | C00081027 | | | | flap support lh 128.8mm | | |
| 016 | C00081025 | | | | braccetto | | |
| 018 | C00304682 | | | | hinge for oven door f.f.19mm | | |
| 019 | C00301059 | | | | plug lh upper glass door profile | | |
| 020 | C00304679 | | | | oven door inner glass pf.fg c50 | | |
| 021 | C00268126 | | | | neon lens clear | | |
| 022 | C00305237 | | | | control knob disc - black | | |
| 023 | C00285754 | | | | knob disc -for el. termostat black | | |
| 024 | C00284673 | | | | knob disc - minute minder black | | |
| 025 | C00028054 | | | | pilot light - horizontal fitting red | | |
| 026 | C00052527 | | | | minute timer d = 6mm | | |
| 027 | C00078436 | | | | oven thermostat | | |
| 028 | C00304666 | | | | switch pack multi10 - 50x60 | | |

Electric schemes and links

Cod. 16002983400



# Legend

Legend: 16002983400

| | | | |
|---|---|---|---|
| AE | Ignition transformer | PE | Plate electric (Normal and Rapid) |
| AT | Ignition transformer | PEL | Wall socket |
| CF | Oven commutator | PIF | Cooking programmer |
| CP | Plate commutator(Normal end Rapid) | POT | Thermostated potentiometer |
| CT | Plate commutator(Automatic) | PT | Termoprotector |
| DC DR | Double Knob double crown burner control card | PTC | Thermostated sensor |
| EV | Electro-Valve | RCE | Grill heating element ex- ternal |
| FC | End of cooking programmer | RCI | Grill heating element internal |
| FRONT | Daschboard | RE | Energy regulator |
| I/LF | OVEN LIGHT SWITCH | RF | Oven lower heating element |
| I/LF-MG | OVEN LIGHT SWITCH + ROTISSERIE | RG | Grill heating element |
| I/MG | TURNSPIT SWITCH | RG COM | Grill heating element un- ion |
| IL | Knobs' Lighting | RV | Heating element ventilated oven |
| ILG | Lamp switch turnspit | SA | Boiler operating led |
| IT | Thermostated switch | SB | Thermostated burner led |
| L | Line (Feed) | SF | Warning light working |
| LF | Oven light | SO | Probe temperature |
| LI | Oven light | SP | Operating Indicator Light for the Plate |
| M | Suction motor handle | ST | Warning light thermostat |
| MG | Turnspit motor | TH | Thermostat fixed |
| MO | Terminal board | TH2 | Thermostated burner cooling |
| MUFF | Oven | THR | Adjustable thermostat |
| MV | Fan motor | TP | Termoprotector |
| N | Neutral (Feed) | TRAV | Support terminal board |
| PA | Ignition push-button | TRM | Thermostated burner control card |