
INDESIT company



Model type:
A34CEX

Commercial code:
F026483

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:

REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics


INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

1190190n

Exploded views



1190190n Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00074626 | | | | kit connection lb-dryers | | |
| 000 | C00087171 | | | | user istructions fr-d-it-p-gb | | |
| 001 | C00086524 | | | | cover | | |
| 002 | C00085323 | | | | side panel | | |
| 003 | C00085371 | | | | back panel | | |
| 004 | C00085325 | | | | top rear crosspiece | | |
| 005 | C00081321 | | | | top bracket | | |
| 006 | C00085372 | | | | bottom back panel | | |
| 007 | C00085327 | | | | interspace | | |
| 008 | C00085373 | | | | sink | | |
| 009 | C00085374 | | | | hose sink | | |
| 010 | C00770143 | | | | zoemer / buzzer (was 810143) | | |
| 011 | C00087166 | | | | drum | | |
| 012 | C00770145 | | | | extractable beater (ex 810145) | | |
| 013 | C00090733 | | | | belt installing tool 'iar' ## | n1040228 | |
| 013 | C00770336 | | | | belt l = 1932 mm h 9 | | |
| 014 | C00770285 | | | | felp tape (ex810285) | | |
| 015 | C00085376 | | | | engine compartment door | | |
| 016 | C00087248 | | | | nut | | |
| 016 | C00770055 | | | | drum support (ex 810055) | | |
| 017 | C00770101 | | | | bearing 22x7x8 608-2z (ex | | |
| 018 | C00770103 | | | | bearing locking disc (ex 810103) | | |
| 019 | C00770322 | | | | steun rechts | | |
| 020 | C00770323 | | | | steun links | | |
| 021 | C00063885 | | | | bracket thermostat | | |
| 022 | C00770219 | | | | thermostaat 1 t 90ø c nc (was | | |
| 023 | C00085424 | | | | power relay | | |
| 024 | C00064809 | | | | bracket | | |
| 025 | C00085332 | | | | radio interference suppressor | | |
| 026 | C00085333 | | | | heating element220v 2400w/230v | | |
| 027 | C00063677 | | | | spring | | |
| 028 | C00063893 | | | | thermostat 120øc | | |
| 029 | C00085334 | | | | crossing of cable | | |
| 030 | C00085335 | | | | supply cable | | |
| 031 | C00063676 | | | | thermostat 135øc | | |

1190190n

Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 032 | C00086526 | | | | front panel | | |
| 033 | C00086527 | | | 1 x C00089557 | plate | | |
| 034 | C00085378 | | | | bottom crosspiece | | |
| 035 | C00085379 | | | | pin for plinth | | |
| 036 | C00085380 | | | | pin for plinth | | |
| 037 | C00087042 | | | | square | | |
| 038 | C00085382 | | | | kick plate | | |
| 039 | C00085383 | | | | tampa do vao de condensacao | | |
| 040 | C00085384 | | | | guarnicao tampa vao condensacao | | |
| 041 | C00085385 | | | | strike plate | | |
| 042 | C00085386 | | | | spring | | |
| 043 | C00085387 | | | | spring | | |
| 044 | C00086528 | | | | hinge plate outer case | | |
| 046 | C00086529 | | | 1 x C00092880 | microswitch | | |
| 047 | C00086530 | | | 1 x C00089749 | lid assembly white | | |
| 048 | C00086531 | | | | conveyor | | |
| 049 | C00770222 | | | | bearing support | | |
| 050 | C00086560 | | | | tampa da sede da lampada | | |
| 051 | C00086532 | | | | seal | | |
| 052 | C00086533 | | | | front filter | | |
| 053 | C00770218 | | | | thermostaatplaatje (was 810218) | | |
| 054 | C00086534 | | | | safety thermostat gasket | | |
| 055 | C00086536 | | | | bracket | | |
| 056 | C00087167 | | | | microswitch | | |
| 057 | C00086538 | | | 1 x C00092882 | filter | | |
| 058 | C00086540 | | | | door gasket | | |
| 059 | C00086541 | | | | probe support 'iar' | | |
| 060 | C00085388 | | | | sink upper | | |
| 061 | C00085389 | | | | lower sink | | |
| 062 | C00770252 | | | | pakking condensorhuis (was | | |
| 063 | C00085390 | | | | pakking condensorhuis | | |
| 064 | C00085391 | | | | pakking condensorhuis short | | |
| 065 | C00770325 | | | | houder condensor | | |
| 066 | C00770349 | | | | condensor | | |
| 067 | C00085392 | | | | side front panel | | |

1190190n Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 068 | C00085393 | | | | side front panel | | |
| 069 | C00770347 | | | | rubber condensor | | |
| 070 | C00770348 | | | | pakking condensor | | |
| 071 | C00770346 | | | | greep condensor | | |
| 072 | C00770326 | | | | ventilatorkap | | |
| 073 | C00086542 | | | | ventilatorkap | | |
| 074 | C00063891 | | | | motor | | |
| 076 | C00077219 | | | | blower fan | | |
| 077 | C00770048 | | | | rubber shock absorber (ex 810048) | | |
| 078 | C00770242 | | | | spacer motor support (ex 810242) | | |
| 079 | C00063889 | | | | seal blower fan | | |
| 080 | C00085395 | | | | drain pump | | |
| 081 | C00085396 | | | | drain pump hose | | |
| 082 | C00085397 | | | | pump cover | | |
| 083 | C00770330 | | | | slang condensor | | |
| 084 | C00085398 | | | | dryer loading | | |
| 085 | C00770251 | | | | plug condensorhuis (was 810251) | | |
| 087 | C00085399 | | | | rod float | | |
| 088 | C00085400 | | | | float | | |
| 089 | C00085401 | | | | micro support | | |
| 090 | C00770034 | | | | voetje (was 810034) | | |
| 091 | C00085402 | | | | bodemplaat | | |
| 092 | C00087168 | | | | dashboard | | |
| 093 | C00087169 | | | | drawer handle | | |
| 094 | C00085412 | | | | condensate collector drawer | | |
| 095 | C00087170 | | | | support knob timer | | |
| 096 | C00086547 | | | | timer knob | | |
| 097 | C00770999 | | | | knob spring timer | | |
| 098 | C00086548 | | | | pushbotton switch | | |
| 099 | C00086549 | | | | pushbotton switch | | |
| 100 | C00085427 | | | | timer | | |
| 101 | C00086567 | | | | led | | |
| 102 | C00085343 | | | | switch nc | | |
| 102 | C00085344 | | | | switch na+na | | |
| 102 | C00086324 | | | | switch | | |

1190190n Spare parts list


| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 103 | C00085418 | | | | injector iar | | |
| 104 | C00085419 | | | | tubo da gaveta ao injector iar | | |
| 105 | C00077046 | | | 1 x C00077042 | support top | | |
| 999 | C00063403 | | | | top hinge block black | | |
| 999 | C00063404 | | | | bottom hinge block | | |
| 999 | C00089557 | | | | locking assembly | | |
| 999 | C00770140 | | | | klemveer waterreservoir (was | | |
| 999 | C00770144 | | | | wiring fixing (ex 810144) | | |
| 999 | C00770241 | | | | condensator 10 mf (was 810241) | | |
| 999 | C00770243 | | | | terminall (was 810243) | | |
| 999 | C00770295 | | | | afvoerslang mea (was 810295) | | |
| 999 | C00770315 | | | | verwarmingselementscrew 4,2x9,5 | | |
| 999 | C00770328 | | | | rooster | | |
| 999 | C00770345 | | | | ring condensor | | |

Notices


n1040228: Replacing the belt.


---


To replace the belt, perform the following instructions:
1) Check that there are no rubber residues in the motor pulley (photo 1).
2) Position the dryer on its front, remove the back panel and check that the basket opening lip is positioned correctly see photo 3 and 4.
3) Remount the belt and check that it is positioned correctly on the motor pulley (1-2 slots from the bottom), perform one complete turn of the basket by hand to stabilize the belt positioning.






Foto 1



Posizione cesto non corretta
Foto 2
Posizione cesto corretta
Il labbro bocca cesto deve essere esterno alla parete dell'autolubrificante


Labbro bocca cesto
Foto 3

## Electric schemes and links

Cod. ce039200

CE039200




# Legend

Legend: ce039200

Electric schemes and links

Cod. se100200



## Legend

Legend: se100200