
INDESIT company



Model type:

PF604(IX)

Commercial code:

F028615

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4230140 Exploded views



4230140 Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00094827				instructions - lid fitting		
000	C00094903				user instruct.book it-gb-fr-ar		
001	C00075781				cover support sx pf6-7 restyling		
002	C00075714				cover left hinge chromed		
003	C00075713				cover right hinge chromed new		
004	C00075780				cover support dx pf6-7 restyling		
005	C00094828			1 x C00256613	glass lid - mirror cf6		
005	C00094829			1 x C00256617	glass lid - black cf6		
005	C00094830			1 x C00118817	glass lid - white cf6		
005	C00094831			1 x C00256619	glass lid - brown cf6		
005	C00094832			1 x C00256620	glass lid - av cf6		
006	C00053196				rubber buffer - glass lid front		
007	C00074160				electric plate 145r 230v 1500w		
008	C00018723			1 x C00018819	sealing gasket - hob/worktop		
009	C00094895			1 x C00256717	spillage tray-stainless steel pf604		
010	C00074135				neon lens clear		
010	C00082507				pilot light green		
011	C00094896				microswitch knob disc pf604 style		
012	C00094901				electric plate knob black p604		
013	C00009306				element cover - 145mm plate		
014	C00013398			1 x C00029158	element support		
015	C00094902				electric commutator for plate		
016	C00094899				electric commutator flask clamp		
017	C00074179			1 x C00143807	tap bracket pf6-7a restyling		
018	C00280173				junction clamp richco		
019	C00094900				base cover pf604 style		
020	C00052959				terminal block trifase itw p.i.		
021	C00052952				clamp kit - hob/worktop		
022	C00009307				fixing cover for electric plate		
023	C00031687				element cover - 180mm		
024	C00074114				blanking plug-lid hinge hole pf7a		
025	C00075782				taptite screw m4x10 f.ron.t.e.zntrp		
025	C00092140				bolt m4x12 te.esa.es.		
026	C00094898				electric plate d180 2000w 230v		
027	C00094897				electric plate d110 600w 230v		

4230140 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
099	C00009296			1 x C00002506	nut m6x6x10		
099	C00037385				reinforcement washer for foot		
099	C00082509				taptite screw m4x10		

Electric schemes and links

Cod. 16001598902




Legend

Legend: 16001598902

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card

Electric schemes and links

Cod. 16001636000



Legend

Legend: 16001636000

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card