
INDESIT company



Model type:

K600M.C(W)/EU

Commercial code:

F029354

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes


4156010 Exploded views



4156010 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00076640				user instruct.it-pt-es-uk-deau-fr-		
000	C00097167				user istructions indesit gb-bu-gr.		
001	C00038035				oven lamp assembly		
002	C00015910				oven lamp e14 220v 15w		
004	C00044805				2-pole earthing rivet		
006	C00034051				vent chimney		
007	C00064142				cross beam mounting plane c60		
008	C00039574				upper element oven/grill 1+1,2kw		
010	C00030885				heat deflector plate - knobs		
013	C00027982				oven door seal- 4 sides brown		
016	C00030161				oven grate 30mm wires		
017	C00017948				aluminium drip tray		
017	C00031422				drip tray - black enamelled		
025	C00033881				drawer		
030	C00039459				junction block three-phase fastex		
031	C00016435				heating element - oven bottom		
034	C00034805				cover plate - for rear cover		
034	C00039463				rear cover		
035	C00063991				electric oven 7pizza s2000 c60		
036	C00033953				oven insulation - sides		
037	C00020226				protection		
037	C00066500				back insulating material oven		
038	C00016108				oven outer back panel		
040	C00016057				fan motor-(cooking) 220v/240v		
042	C00011573			1 x C00297891	oven thermostat		
043	C00039578				push in spring clip - thermostat		
045	C00033403				oven back panel (inner) enamelled		
047	C00016423				ducting - lower heating element		
048	C00038914			1 x C00280851	fixing plate for self-tapping screw		
049	C00033977				oven function switch (5 position)		
086	C00064111				moulding fissing oven s2000		
099	C00033573				protection oven botton heating		
099	C00091358				cchimney rubber buffer		


4156110 Exploded views



4156110 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00074943			1 x C00112089	wh glass cover c60 indesit		
002	C00074834				white hitting gum glass cover c60		
011	C00063862				right cover hinge		
012	C00064288				working table c60 04 145 white		
013	C00074817				side panel dx bianco 60		
014	C00033310				drawer slide		
015	C00064081				drawer support		
017	C00064130				cooker base c60 white		
018	C00033339				adjustable foot en		
024	C00074820				white side panel, left c60		
025	C00063863				hinge left (on lid)		
029	C00064110				rear spacer		
031	C00064082				slide with pin - drawer, right		
032	C00064083				slide with pin - drawer, left		
034	C00074827				plinth white indesit c60		


4156210 Exploded views



4156210 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
060	C00030938				electric plate d=180 220v 2kv		
061	C00031687				element cover - 180mm		
062	C00009296			1 x C00002506	nut m6x6x10		
063	C00013413				energy regulator (hotplate) 6+0		
067	C00035740			1 x C00197004	electric plate d=220 220v 2kv		
068	C00033379				hotplate d145n.1000watt 220v		
069	C00017353				fixing cover - 220mm hotplate		
070	C00009306				element cover - 145mm plate		
071	C00013398			1 x C00029158	element support		

4156310 Exploded views



4156310 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
003	C00028054				pilot light - horizontal fitting red		
003	C00028055				pilot lamp green		
004	C00052527				minute timer d = 6mm		
005	C00064140				inner control panel 60		
006	C00052525				pilot lamp lens - orange		
007	C00054502			1 x C00268126	pilot lamp lens - green		
009	C00081060				dashboard k600m(w)/s		
010	C00093469				grey knob disc new		
011	C00016035				control knob disc spring		
012	C00093472				timer knob withe indesit new		
013	C00093474				white knob for electric rings new		
014	C00074829				lower profil, white c60		
015	C00074942				oven inner door & glass		
016	C00074766				oven door glass 60 withe indesit		
017	C00074814				door handle c60 white indesit		
018	C00074815			1 x C00075497	post dx c60 indesit		
019	C00048108				oven door hinge (fixed hinge		
021	C00074824				pishwarmer door white		
022	C00074816			1 x C00075497	post sx c60 indesit		
024	C00063861				hinge support (fixed hinge pivot)		
029	C00064565				moulding fissing door c60 s2000		
099	C00013973				screw 8p x 12,75 tpr black		
099	C00017240				self-tapping screw 8px9,52 t1/2t-		
099	C00033163				washer - black		
099	C00033431				screw m5 x 20 tsp black		
099	C00074657				third door glass kit indesit s2000		
099	C00074765				gasket oven door long c60 indesit		


Notices

n1015015: Method to remove the external glass of the oven door.

On all built-in cooker and oven models, when it is necessary to remove the glass from the oven door handle (to avoid breaking the handle) the glass is not removed upwards, but should be oscillated towards the right and left until the two silicone points, that unite the glass to the handle, detach.

Electric schemes and links

Cod. se074000



Legend

Legend: se074000

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card