
INDESIT company



Model type:
PK640EXHA

Commercial code:
F082197

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4450170 Exploded views



4450170 Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00290191				pan grid (rh)black 65-40 h/a2011		
002	C00289817				rubber buffer for pan support		
003	C00052932				burner cap semi rapide		
004	C00290834				support pan grid p.i.adv bk 425°c		
005	C00052929				burner ring - medium		
006	C00290005				knob gas dual(bk-ix)pi ha2011		
007	C00289857				click itw ha-11 rub.copreci 210°		
008	C00111235				microswitch ring		
008	C00282789				blanking plug		
009	C00018819				seal - hob/worktop		
010	C00052941				natural gas jet (96)		
011	C00093834				screw nut m6		
011	C00289758				thermocouple - aux/med.l600		
012	C00118496			1 x C00052951	electrode l=520		
013	C00052926				burner cup - medium burner		
014	C00052934				electrode clip		
015	C00290193				terminal block b230046 - itw		
015	C00297819				terminal block 4 f.+cavo		
016	C00289771				mains supply cable pvc 6a 3x0.75		
017	C00290169				gas pipe p.i.2011 632		
019	C00052952				clamp kit - hob/worktop		
020	C00290194				ignition microswitch 4 mic. itw-		
021	C00289713				gas tap - triple burnerv.90°din r		
021	C00289756				gas tap - din aux-sr 28 copreci		
022	C00290164				gas pipe - aluminium tube aux		
022	C00290165				gas pipe - aluminium tube 65-32rt		
022	C00290166				gas pipe - aluminium tube 65-40 r		
022	C00290178				gas pipe - aluminium tube 65-40		
023	C00010506				sealing washer - gas elbow/pipe		
024	C00024370				elbow connection (1/2 male x 2)-		
025	C00052925				burner cup - large burner		
026	C00292404				gas jet d=132h large burner		
027	C00052927				burner cup - small burner		
028	C00066166				nat gas aux. burner nozzle rapido		
029	C00300889				hob top pk640ixha diamond clean		

4450170 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
030	C00289815				support pan grid (lh)p.i.h/a-11		
031	C00289812			1 x C00289816	support pan grid p.i.h/a-11 adv bk		
032	C00289813				support pan grid (rh) p.i.h/a-11		
033	C00052928				burner ring/flame splitter - large		
034	C00052931				burner cap rapide (large) black		
035	C00052930				burner base/flame splitter - small		
036	C00052933				burner cap auxiliary (small) black		
037	C00290162				pan grid (lh) 65-40 h/a2011		
051	C00291345				kit glass cover c7k(bk)		
052	C00291360				support glass cover lh		
053	C00081133				cover left hinge		
054	C00075713				cover right hinge chromed new		
055	C00291359				support glass cover rh		
056	C00053196				rubber buffer - glass lid front		
099	C00273333				jets kit for lpg		
099	C00280173				junction clamp richco		

Electric schemes and links

Cod. 16001635901



Legend

Legend: 16001635901

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card