Beard trimmer

BT1000

Service
Service
Service



Philips Consumer Lifestyle

Service Manual

Product information

Service scenario:

- Repair
- Parts exchange

Safety information

- This product meets the requirements regarding interference suppression on radio and TV.

Place of production date



Technical information

Cutting system

- Cutting element: Stainless steel blades
- Non-scratching teeth: For more comfort

4 built-in length settings

- Slide the comb up to the desired length setting, from 1,5 to 7 mm or use it without the comb for a 0,5 mm stubble.

Accessories

- Maintenance: Dry clean only, by means of cleaning brush

Ease of use

- Cleaning: Pop open trimmer head

Power

- Battery Type: 2 AA battery (not included)

Service

- 2-year warranty
- No oil needed

Optional (accessories)

- No specific issues


Published by Philips Consumer Lifestyle Printed in the Netherlands
© Copyright reserved Subject to modification

15/03


PHILIPS

To clean the trimmer head:


1. If the comb is on the aplliance, pull it off.
2. Flip the cutting unit open with your thumb.



3. Clean the cutting unit and hair chamber with the brush.



4. Close the cutting unit by pushing it back onto the appliance (‘click’).



Pos	Service code	Description
1	4222 036 30921	Pop open trimmer head
2	4222 036 30931	Comb
3	4222 026 02770	Cleaning brush