
INDESIT company



Model type:

TQ751S(ICE)GH/HA

Commercial code:

F048154

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4230540 Exploded views



4230540 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00260572				user booklet it-gb-fr-nl-es		
000	C00260573				user booklet pt-de		
001	C00260912				pan grid (centre) cast iron		
002	C00260911				grid for 2 burners right cast iron		
003	C00064919				burner cap - semirapide black		
004	C00136244				flame splitter medium		
005	C00260772				burner support semiifast raf exp		
005	C00287341				screw burner support 8mm		
006	C00063701				seal-hob/worktop		
007	C00260767		10522...		knob gas tq6-7 an black 6mm		
007	C00287355	10523...			knob gas tq6-7 an black 8mm		
008	C00016035				control knob disc spring		
009	C00260765				knob disc an		
010	C00260987		10522...		working table glass tq751s(ice)ix	n1011j00	
010	C00287357	10523...			working table glass tq751s(ice)ix		
011	C00288669				electrode clip br. ftgh defendi		
012	C00118496			1 x C00052951	electrode l=520		
013	C00052986				thermocouple ** not for triple		
013	C00093834				screw nut m6		
014	C00052960				burner fixing screw (stainless		
015	C00063709				washer		
016	C00052938				gas jet 64 lpg - medium burner		
016	C00052941				natural gas jet (96)		
017	C00096132				packing d=153,4		
018	C00052926				burner cup - medium burner		
019	C00297029				terminal board assy + cable 6a		
020	C00111240				gas tap medium/auxiliary copreci		
020	C00111241				gas tap large copreci		
020	C00280014				gas tap - miniwok b.61		
021	C00141902				back pipe semifast rh - tap		
022	C00141898				front pipe semifast rh - tap		
023	C00260683				gas pipe mini wok		
024	C00141900				burner supply pipe aux		
025	C00141901				front left burner supply pipe		
026	C00141908				flask burner cup - medium burner		

4230540 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
027	C00280173				junction clamp richco		
028	C00111238				fixing bracket - tap copreci		
028	C00260792				tap fixing plate		
029	C00064912				screw m4x18 tsp nikelata		
029	C00111239				screw m4x17tsp zinc		
030	C00035727			1 x C00276836	mains supply cable 3x2,5		
031	C00052952				clamp kit - hob/worktop		
032	C00260670				base cover td-tq751		
033	C00141903				gas pipe pz750		
035	C00010506				sealing washer - gas elbow/pipe		
036	C00024370				elbow connection (1/2 male x 2)-		
037	C00052927				burner cup - small burner		
038	C00052939				gas jet 50 lpg - small burner		
038	C00066166				nat gas aux. burner nozzle rapido		
039	C00260745				burner cup - mini wok		
040	C00260662				ignition electrode mini wok		
041	C00260657				thermocouple miniwok defendi		
042	C00027972				ultrarapid lpg gas nozzle 94		
042	C00260746				d=138 nozzle nat gas		
043	C00260660				gasket cup miniwok		
044	C00052925				burner cup - large burner		
045	C00052940				gas jet 116 ng large burner		
045	C00056359				gas jet (80) lpg - large burner		
046	C00260669				burners support 75 wok		
047	C00260774				burner support auxiliary raf exp		
047	C00287341				screw burner support 8mm		
048	C00063702				burner base - auxiliary		
049	C00064918				burner cap auxiliary black semi		
050	C00093670				screw burner support 8mm		
050	C00260989				burner support mini wok an		
051	C00260677				burner base/flame splitter mini		
052	C00260674				burner cap (outer ring) - mini wok		
053	C00260675				burner cap (inner) mini wok raf		
054	C00260771				burner support fast raf exp		
054	C00287341				screw burner support 8mm		

4230540 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
055	C00136243				flame splitter - large		
056	C00064920				burner cap rapide black		
057	C00111235				microswitch ring		
057	C00145276				ignition microswitch (5) copreci		
058	C00053844				rubber buffer (griddle) - black		
059	C00260913				grid for 2 burners left cast iron		
099	C00011550				screw burner support 8mm		
099	C00271397				jets kit for butano td751s(ice)ix/ha		


Notices

n1011j00: Introduced new working table glass from 8 mm

At the end of the stocks of working table glass pre-modified it is necessary to order simultaneously new Code of working table glass, new code of knobs and 8 mm burner support screws.
For the correct installation procedure please refer to the Technical Bulletin TB001366 present in the documentation.

Electric schemes and links

Cod. 16001635901



Legend

Legend: 16001635901

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card