
INDESIT company



Model type:
K984ES(XS)/I

Commercial code:
F028528

# General notes

## Technical Documentation guidelines

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4150120 Exploded views




4150120 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00080912 | | | | user istructions | | |
| 003 | C00015910 | | | | oven lamp e14 220v 15w | | |
| 003 | C00038035 | | | | oven lamp assembly | | |
| 007 | C00039640 | | | | spark ignition transformer + filter | | |
| 016 | C00033953 | | | | oven insulation - sides | | |
| 017 | C00017312 | | | | gas jet 85 lpg large burner | | |
| 029 | C00016435 | | | | heating element - oven bottom | | |
| 030 | C00033573 | | | | protection oven botton heating | | |
| 031 | C00039574 | | | | upper element oven/grill 1+1,2kw | | |
| 043 | C00039578 | | | | push in spring clip - thermostat | | |
| 044 | C00011573 | | | 1 x C00297891 | oven thermostat | | |
| 046 | C00044985 | | | | electric oven/grill switch | | |
| 099 | C00002766 | | | | protection box for speed | | |
| 099 | C00014840 | | | | blanking cap 22mm | | |
| 099 | C00024352 | | | | plate for fixing pin | | |
| 099 | C00034805 | | | | cover plate - for rear cover | | |
| 099 | C00044805 | | | | 2-pole earthing rivet | | |
| 099 | C00051671 | | | | kit gir.54x57/90x57 ariston | | |

4150220 Exploded views

Matr.01114.001





4150220

4150220 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 002 | C00033357 | | | | chimney | | |
| 005 | C00027844 | | | | seal (3 sides) oven door - black | | |
| 008 | C00030161 | | | | oven grate 30mm wires | | |
| 009 | C00031422 | | | | drip tray - black enamelled | | |
| 010 | C00033881 | | | | drawer | | |
| 011 | C00033319 | | | | slide with pin - warming drawer | | |
| 016 | C00016108 | | | | oven outer back panel | | |
| 017 | C00035727 | | | 1 x C00276836 | mains supply cable 3x2,5 | | |
| 019 | C00039460 | | | | terminal block 2.pole (fastex) | | |
| 020 | C00039462 | | | | back panel cooker 54 fastex | | |
| 022 | C00033569 | | | | moulding fissing oven en | | |
| 023 | C00033360 | | | | upper back cross-piece | | |
| 024 | C00033365 | | | | nett cylinder top and bottom | | |
| 025 | C00020226 | | | | protection | | |
| 026 | C00016423 | | | | ducting - lower heating element | | |
| 028 | C00033361 | | | | back panel pb | | |

4150420 Exploded views




4150420 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00036435 | | | | cover support sx 54-90 en | | |
| 002 | C00016034 | | | | spring left cover | | |
| 002 | C00036426 | | | | hinge sx for glass cover 90 | | |
| 005 | C00016033 | | | | spring right cover | | |
| 005 | C00036425 | | | | hinge dx for glass cover 90 | | |
| 006 | C00036434 | | | | cover support dx 54-90 en | | |
| 009 | C00033534 | | | | black grid 90 en | | |
| 011 | C00036597 | | | | reinforcement bracket hinge | | |
| 015 | C00018453 | | | | flexible tube holder | | |
| 016 | C00033488 | | | | side panel 57/90inox dx | | |
| 017 | C00033302 | | | | front strut dx grey 54 x 57 | | |
| 018 | C00033366 | | | | cooker base | | |
| 019 | C00033339 | | | | adjustable foot en | | |
| 020 | C00033364 | | | | athermic panel | | |
| 021 | C00033310 | | | | drawer slide | | |
| 022 | C00033301 | | | | front strut sx grey 54 x 57 | | |
| 023 | C00033338 | | | | drawer support | | |
| 026 | C00033460 | | | | side panel 57 inox sx | | |
| 027 | C00043654 | | | | hob inox kn9426xs/g | | |
| 032 | C00033532 | | | | reducing grid - pan grids | | |
| 041 | C00039343 | | | | transparent side angular | | |
| 043 | C00039918 | | | | dividing panel crosspiece 57 skd | | |
| 044 | C00081104 | | | | grey glass cover 90 indesit | | |
| 049 | C00043600 | | | | ferrule support thickness dx black | | |
| 050 | C00019351 | | | | nett cylinder shelf | | |
| 050 | C00043599 | | | | ferrule support thickness sx black | | |
| 051 | C00034765 | | | | nett cylinder grid | | |
| 099 | C00024772 | | | | back protection working table | | |
| 099 | C00047022 | | | | washer | | |

4150520 Exploded views

Matr. 40615.0001




4150520 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00032428 | | | | burner cap - large burner black | | |
| 002 | C00027167 | | | | flame splitter - large burner | | |
| 003 | C00023997 | | | | burner base - large burner | | |
| 004 | C00033379 | | | | hotplate d145n.1000watt 220v | | |
| 005 | C00032430 | | | | burner cap - small burner black | | |
| 006 | C00027179 | | | | flame splitter - small burner | | |
| 007 | C00030727 | | | | burner base - small burner | | |
| 008 | C00009306 | | | | element cover - 145mm plate | | |
| 010 | C00033384 | | | | distributing pipe | | |
| 011 | C00018089 | | | | gas jet small (48) - lpg | | |
| 011 | C00018090 | | | | gas jet small (74) - natural | | |
| 011 | C00038244 | | | | gas small burner cyti d= 130 gz35 | | |
| 012 | C00004682 | | | | blanking tap 1/2 gas threading | | |
| 013 | C00033381 | | | 1 x C00017439 | feed pipe front burners dx en 90 | | |
| 014 | C00030706 | | | | burner cup - small burner | | |
| 015 | C00033382 | | | 1 x C00017439 | supply tube for dx medium burner | | |
| 016 | C00033383 | | | 1 x C00017439 | supply tube for sx medium burner | | |
| 017 | C00013413 | | | | energy regulator (hotplate) 6+0 | | |
| 018 | C00045381 | | | | tap with valves by-pass kit 41/100 | | |
| 018 | C00046673 | | | | tap with valves by-pass 30/100 | | |
| 019 | C00031027 | | 80301... | | bolt m4 | | |
| 019 | C00264392 | 80302... | | | bolt m4x17.8 tsp esagonale sabaf | | |
| 020 | C00044980 | | | | tap bracket | | |
| 023 | C00033380 | | | 1 x C00017439 | feed pipe front burners sx en 90 | | |
| 024 | C00030708 | | | | burner cup - large burner | | |
| 028 | C00027185 | | | 1 x C00018092 | gas jet (139) large natural/small | | |
| 028 | C00033834 | | | | gas jet medium (110) - natural | | |
| 028 | C00033835 | | | | gas jet 70 - lpg/ng medium burner | | |
| 029 | C00030707 | | | | burner cup - medium burner | | |
| 032 | C00013398 | | | 1 x C00029158 | element support | | |
| 033 | C00011040 | | | | not uk - hose ferrule - methane | | |
| 034 | C00042952 | | | | gas medium burner cyti d= 197 | | |
| 035 | C00010509 | | | | not uk- hose ferrule - lpg | | |
| 036 | C00010506 | | | | sealing washer - gas elbow/pipe | | |
| 044 | C00030732 | | | | thermocouple r450 | | |

4150520 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 045 | C00031687 | | | | element cover - 180mm | | |
| 046 | C00018102 | | | 1 x C00087386 | spark ignition plug | | |
| 047 | C00034308 | | | | electric plate 180 220v 1500 watt | | |
| 048 | C00030726 | | | | burner base - medium burner | | |
| 049 | C00027172 | | | | flame splitter - medium burner | | |
| 050 | C00032429 | | | | burner cap - medium burner black | | |
| 051 | C00034810 | | | | large burner city gas nozzle 280 | | |
| 061 | C00015731 | | | | knob spacer | | |
| 099 | C00009296 | | | 1 x C00002506 | nut m6x6x10 | | |
| 099 | C00041167 | | | | bolt m4 x 11 | | |

4150650 Exploded views



4150650 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00080912 | | | | user istructions | | |
| 003 | C00046345 | | | | switch support internal black | | |
| 004 | C00045793 | | | | ignition switch | | |
| 006 | C00080921 | | | | dashboard k 982 es(x) | | |
| 007 | C00028053 | | | | pilot lamp lens - green | | |
| 008 | C00080919 | | | | knob disc gas burners black | | |
| 009 | C00080920 | | | | knob disc timer black | | |
| 010 | C00080914 | | | | timer knob black indesit 90 | | |
| 011 | C00008507 | | | | snap hook door pb | | |
| 012 | C00008506 | | | | snap arrest mechanism door 95pb | | |
| 013 | C00080916 | | | | gas knob indesit black 90 | | |
| 014 | C00016035 | | | | control knob disc spring | | |
| 015 | C00080913 | | | | black knob for electric rings | | |
| 016 | C00033401 | | | | oven inner-door 2 glass | | |
| 017 | C00080915 | | | | knob ele.oven black | | |
| 018 | C00080917 | | | | disc for elt.stat.black oven | | |
| 019 | C00080911 | | | | door handle black | | |
| 020 | C00080905 | | | | door upper hinge | | |
| 021 | C00033371 | | | | inner-door en. | | |
| 022 | C00033486 | | | | inox en. door | | |
| 023 | C00080950 | | | | door handle pb giugia.black | | |
| 024 | C00033394 | | | | door lower hinge brown | | |
| 024 | C00087419 | | | | door lower hinge brown | | |
| 025 | C00033373 | | | | p.b. plug en. | | |
| 028 | C00033461 | | | | inox dishwarmer door 54 | | |
| 029 | C00037155 | | | | dishwarmer inner-door 54 en | | |
| 030 | C00066444 | | | | lower profil inox 54 4mm | | |
| 031 | C00080910 | | | | oven door glass mirror | | |
| 032 | C00033322 | | | | hinge for oven door 54 90 tr 38 | | |
| 033 | C00074835 | | | | grey hitting gum glass cover c60 | | |
| 034 | C00033163 | | | | washer - black | | |
| 035 | C00033431 | | | | screw m5 x 20 tsp black | | |
| 036 | C00002498 | | | | nut 5ma | | |
| 037 | C00025362 | | | 1 x C00017200 | internal glass for oven door x uk | | |
| 038 | C00017209 | | | | washer - inner glass clamping | | |

4150650 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 039 | C00017208 | | | | screw - inner door glass clamping | | |
| 042 | C00046344 | | | | ignition button giugiaro rold black | | |
| 044 | C00052527 | | | | minute timer d = 6mm | | |
| 045 | C00033337 | | | | hinge support | | |
| 045 | C00033396 | | | | back spacer lock dooren. | | |
| 046 | C00080918 | | | | knob support for electric plate | | |
| 099 | C00011551 | | | | black screw m5 x 9 tsp | | |
| 099 | C00017240 | | | | self-tapping screw 8px9,52 t1/2t- | | |
| 099 | C00050662 | | | | third door glass kit cookers | | |

Notices


n1015015: Method to remove the external glass of the oven door.

---

On all built-in cooker and oven models, when it is necessary to remove the glass from the oven door handle (to avoid breaking the handle) the glass is not removed upwards, but should be oscillated towards the right and left until the two silicone points, that unite the glass to the handle, detach.

Electric schemes and links

Cod. 16001607500




se16001607500

# Legend

Legend: 16001607500

| | | | |
|---|---|---|---|
| AE | Ignition transformer | PE | Plate electric (Normal and Rapid) |
| AT | Ignition transformer | PEL | Wall socket |
| CF | Oven commutator | PIF | Cooking programmer |
| CP | Plate commutator(Normal end Rapid) | POT | Thermostated potentiometer |
| CT | Plate commutator(Automatic) | PT | Termoprotector |
| DC DR | Double Knob double crown burner control card | PTC | Thermostated sensor |
| EV | Electro-Valve | RCE | Grill heating element ex- ternal |
| FC | End of cooking programmer | RCI | Grill heating element internal |
| FRONT | Daschboard | RE | Energy regulator |
| I/LF | OVEN LIGHT SWITCH | RF | Oven lower heating element |
| I/LF-MG | OVEN LIGHT SWITCH + ROTISSERIE | RG | Grill heating element |
| I/MG | TURNSPIT SWITCH | RG COM | Grill heating element un- ion |
| IL | Knobs' Lighting | RV | Heating element ventilated oven |
| ILG | Lamp switch turnspit | SA | Boiler operating led |
| IT | Thermostated switch | SB | Thermostated burner led |
| L | Line (Feed) | SF | Warning light working |
| LF | Oven light | SO | Probe temperature |
| LI | Oven light | SP | Operating Indicator Light for the Plate |
| M | Suction motor handle | ST | Warning light thermostat |
| MG | Turnspit motor | TH | Thermostat fixed |
| MO | Terminal board | TH2 | Thermostated burner cooling |
| MUFF | Oven | THR | Adjustable thermostat |
| MV | Fan motor | TP | Termoprotector |
| N | Neutral (Feed) | TRAV | Support terminal board |
| PA | Ignition push-button | TRM | Thermostated burner control card |