Service
Service
Service



HD 4820/A
HD 4820/B
HD 4821/A
HD 4822/B


Service Manual

MSH code
8824 820 00000
8824 821 00000
8824 822 00000

PRODUCT INFORMATION

Voltage	: 220-240V
Frequency	: 50-60Hz
Power consumption	: 800W
Color setting	: Ivory with orange parts White with green parts

	Dustcover	Bunwarmer	Max. timer setting
HD4820/A	-	-	180 sec. ±15%
HD4820/B	-	-	160 sec. ±15%
HD4821/A	x	-	180 sec. ±15%
HD4822/B	-	x	160 sec. ±15%



SERVICE INFORMATION

- Crumbtray for all toasters
- In case of a technical defect, toasters have to be replaced
- Only numbered items are serviceable parts

1	Dustcover (ivory)	4822 442 01486
2	Bunwarmer (ivory)	4822 690 10126
	Bunwarmer (white)	4822 256 10501
3	Crumbtray (orange)	4822 418 10362
	Crumbtray (green)	4822 418 10363

Published by Philips Domestic Appliances and Personal Care Printed in Hong Kong ©Copyright reserved Subject to modification

4822 729 21961
04/98

PHILIPS