
INDESIT company



Model type:

PH640MST(AV)R/HA

Commercial code:

F048208

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4230390 Exploded views



4230390 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00257170				instruction book nl-bd-pt-ar		
000	C00257171				instruction book it-gb-fr-es-ro		
001	C00024300				cover (glass lid hinge) - brown		
001	C00025355				cover (glass lid hinge) - black		
001	C00118351				cover (glass lid hinge) - pw		
002	C00024299				hinge lh - glass lid		
003	C00033797				rubber buffer (lid rear) - grey		
003	C00033923				rubber buffer (lid rear) - white		
004	C00053199				glass lid - black		
004	C00053200				glass lid - brown		
004	C00053201				glass lid - mirror		
004	C00054498				glass lid - antique white		
004	C00118314				kit glass cover c6h(pw)		
006	C00024297				hinge right - glass lid		
007	C00052922				pan grid (rh) - shiny black		
008	C00039148				rubber buffer for pan support		
010	C00039156				knob disc - spring		
012	C00110586				rustic knob ph6-9-pf7 antracite-		
014	C00053338				knob disc - anthracite		
015	C00052960				burner fixing screw (stainless		
016	C00053176				gas jet 91 lpg - triple burner/wok		
016	C00065921				small metha.gas nozzle triple		
018	C00053244				ignition spark plug - triple burner		
019	C00093834				screw nut m6		
019	C00094330				thermocouple - triple burner		
020	C00053254				burner cup - triple burner		
021	C00297836				terminal block 4f.+cavo 6a		
022	C00017439				gas pipe - aluminium tube 8x1mm		
023	C00035727			1 x C00276836	mains supply cable 3x2,5		
024	C00280173				junction clamp richco		
025	C00066373				base cover		
026	C00052952				clamp kit - hob/worktop		
027	C00143845				support bracket - glass cover rohs		
029	C00010506				sealing washer - gas elbow/pipe		
030	C00024370				elbow connection (1/2 male x 2)-		

4230390 Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
031	C00052987				gas pipe (tap manifold)		
032	C00111240		70819...		gas tap medium/auxiliary copreci		
032	C00111241		70819...		gas tap large copreci		
032	C00111244		70819...		gas tap - triple burner 57		
032	C00262593	70820...			gas tap - large burners sabaf 39		
032	C00262594	80820...			gas tap - triple burner sabaf		
032	C00262595	70820...			gas tap - small+medium+oval		
033	C00111235				microswitch ring		
033	C00111243		70819...		microswitch n°4 copreci ph640		
033	C00264307	70820...			microswitch n°4 sabaf ph640		
034	C00052921				fixing bracket - tap manifold		
034	C00111238				fixing bracket - tap copreci		
035	C00064912				screw m4x18 tsp nikelata		
036	C00052926				burner cup - medium burner		
037	C00052960				burner fixing screw (stainless		
037	C00063709				washer		
038	C00052938				gas jet 64 lpg - medium burner		
038	C00052941				natural gas jet (96)		
039	C00052934				electrode clip		
040	C00052927				burner cup - small burner		
041	C00052939				gas jet 50 lpg - small burner		
041	C00056823				gas jet (71) ng/lpg		
042	C00052925				burner cup - large burner		
043	C00118496			1 x C00052951	electrode l=520		
044	C00052986				thermocouple ** not for triple		
044	C00076393				glass lid -c6h(ice)		
045	C00056359				gas jet (80) lpg - large burner		
045	C00056360				gas jet 110 nat gas - large burner		
046	C00257195				working table ph640mst(av)/ha		
047	C00018723			1 x C00018819	sealing gasket - hob/worktop		
048	C00032682				blanking plug - lid hinge hole		
049	C00052928				burner ring/flame splitter - large		
050	C00052931				burner cap rapide (large) black		
051	C00052930				burner base/flame splitter - small		
052	C00052933				burner cap auxiliary (small) black		

4230390 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
053	C00052929				burner ring - medium		
054	C00052932				burner cap semi rapide		
055	C00053173				burner base/flame splitter - triple		
056	C00053174				outer burner cap black work triple		
057	C00053175				burner cap (centre disc)triple black		
058	C00052923				pan grid (lh) shiny black		
059	C00131879			1 x C00033532	reduction pan support black		
060	C00052988				pan grid (centre) shiny black		
061	C00053196				rubber buffer - glass lid front		
099	C00002451				washer 4,2x8x0,6		
099	C00053731				gas jet kit - city gas g110		
099	C00053734				desc_ric_c00053734		
099	C00054791				gas jet kit -air propane-ph6-pl6		
099	C00057980				electric insulation bugnato ph6		
099	C00057988				kit nozzle set lpg hobs g30/31		
099	C00058924				gas jet kit-metano ph6-9 g20		
099	C00097351				kit grids+spli.+knob+disc iron		

Electric schemes and links

Cod. 417089b



Legend

Legend: 417089b

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card