
INDESIT company



Model type:
H461.1(GY)

Commercial code:
F043093

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:

REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.


6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

e413s1lsl

Exploded views

61018.0001



e413s1lsl

e413s1lsl Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00194949				user instruct.bookl indesit		
007	C00136037				filter fixing		
007	C00194907				filter fixing		
009	C00194908				baffle filter		
017	C00194909				lighting diffuser support		
023	C00136032				bushing support		
024	C00136033				lower bushing support		
025	C00136036				cover		
026	C00126387			1 x C00042985	lamp		
028	C00034834				lamp-socket 39n - t190		
029	C00098062				lamp cover k24 best		
043	C00136016				motor		
049	C00136018				fin wheel		
050	C00136017				support,motor		
052	C00136021				cable clamp		
057	C00126508				check valve		
058	C00023541				reduction 123/100		
060	C00194910				mains cable		
071	C00194912				heading front right		
072	C00194913				heading front left		
076	C00136055				upper glass		
084	C00194914				trolley		
086	C00136056				reduction		
112	C00136019				protecting nut motor		
130	C00194919				front		
145	C00136029				terminal board box		
146	C00136030				terminal box lid		
147	C00027737				junction clamp 3.5x3 el r2300162		
152	C00136031				cable clamp		
223	C00194924				key		
228	C00194926				control board		
230	C00136028				control panel cover an		
234	C00194927				board casing		
240	C00194928				control key support		
253	C00126530				micro + lever		

e413s1lsl Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
266	C00136020				motor protection		
288	C00136048				ball sliding guide		
309	C00194929				spacer		
312	C00136022				protection panel		
476	C00136038				ceiling lamp spacer		
477	C00136040				wedge,an		
999	C00194931				fixing assembly		
999	C00195271				carcoal filter		

Electric schemes and links

Cod. se8784



Legend

Legend: se8784

AT	Ignition transformer	POT	Thermostated potentiometer
CF	Oven commutator	PT	Plate electric (Automatic)
CP	Plate commutator(Normal end Rapid)	PTC	Thermostated sensor
CT	Plate commutator(Automatic)	RCE	Grill heating element external
DCDR	Double Knob double crown burner control card	RCI	Grill heating element internal
EV	Electro Valve	RE	Energy regulator
FRON	Daschboard	RF	Oven lower heating element
ILG	Lamp switch turnspit	RG	Grill heating element
IT	Thermostated switch	RG COM	Grill heating element union
L	Line (Feed)	RV	Heating element ventilated oven
LF	Dashboard light	SA	Boiler operating led
LI	Oven light	SB	Thermostated burner led
M	Suction motor handle	SF	Warning light working
MG	Turnspit motor	SO	Probe temperature
MO	Terminal board	ST	Warning light thermostat
MUF	Oven	TH	Thermostat fixed
MV	Fan motor	TH2	Thermostated burner cooling
N	Neutral (Feed)	THR	Adjustable thermostat
PA	Ignition push	TP	Termoprotector
PE	Plate electric (Normal and Rapid)	TRAV	Support terminal board
PEL	Wall socket	TRM	Thermostated burner control card
PIF	Cooking programmer	VAP	Steam boiler heating element