
INDESIT company



Model type:
OF440

Commercial code:
F026473

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

5078210 Exploded views



5078210 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00085013				user booklet ch-indesit/2001		
001	C00084988				white handle indesit 'of220-290-		
003	C00084996				comp dr white 1514x600x77		
004	C00084992				door gasket white		
005	C00607126			1 x C00003261	ice scraper		
007	C00612414				lamp cover		
008	C00084999				partition grid white 466,5x170		
009	C00612357				arcas/ispraflex lamp holder(faston		
010	C00006522				lamp 15w (e14)		
011	C00008785				conipres 4,9 hinge with spring		
012	C00100496				white upper hinge cover (b-c)		
013	C00100497				white hinge cover (b-c) conipres		
015	C00085001			1 x C00277494	basket (wxh) 499x215x250 white		
017	C00085041				foot d.18x40 - adjustable		
018	C00085003				water drainage plug (d.10x20)		
019	C00084987				drain white		
020	C00612581				white side grid wxh 550x206		
022	C00085011				lead clamp		
023	C00008598				mains supply cable 3x0,75		
024	C00085032				thermostat 077b-2638(of220-290-		
025	C00085037				front side panel compressor		
026	C00002516				nut - thermostat(center-post)		
027	C00085012				dashboard		
028	C00075582			1 x C00114742	knob - thermostat d.6 mm		
029	C00085020				wiring + indicators light	n1035025	
029	C00085050				yellow red pilot lamp (ch-		
029	C00085051				green red pilot lamp (ch-		
029	C00085052				red red pilot lamp (ch-		
030	C00614585			1 x C00008471	compressor fixing plate		
031	C00032453				rubber shock absorber -		
032	C00085034				compressor crosspiece (plastic)		
033	C00043734				plate clamp - 80x22 compressor		
036	C00085035				back side panel compressor		
037	C00066259			1 x C00099801	compr. tw1390ys-tw160ks 220-		51264730000
037	C00270730			1 x C00290908	comp hmk12aa 220-240/50-198w		51264730001

5078210 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
038	C00008727				charging pipe without valve		
038	C00042354				charging pipe 6x90 mm r134a		51264730000
038	C00043021				service pipe with valve (6 nfmssv)		51264730001
039	C00042357			1 x C00042334	filter gr.12 (r134a gas)		51264730000
040	C00063738				condenser armco 1325x550'ch430		
041	C00009033				condenser support armco (plastic)		


Notices

n1035025: Wiring harness for horizontal freezers of series Indesit-2001 (Setubal)

The new horizontal freezers of series Indesit-2001, produced in Setubal (Portugal) use on the model with lamp-holder two different wiring harnesses of the control block according to the type of used compressor.
The electric connection of the lamp-holder can be directly done on the terminal board of the compressor; in this case when the wiring harness is 085020 and the wires of wiring harness end with female blocks faston on the freezer.
Otherwise, it is better to use the terminal board code 085025, when the wiring harness of compressor is not used. This second wiring harness is different from the first one because of the presence of the 2-way and female block. The latter has to be connected to the male one, built on the wiring harness, which comes out from the freezer cover.
When the compressor is substituted, when it is different form the one originally built on, the wiring harness has to be substituted, too, changing also the cover, if it necessary.

Electric schemes and links

Cod. se092100



SE092100

Legend

Legend: se092100

BZ	Audio freezer alarm	N	Neutral
C	Starting capacitor	PTC	PTC relay
CM	Running capacitor	R	Heating resistance
CO	Compressor	RA	Ammetrical relay
EV	Electrovalve	RAN	Heating element condensation
FA	Radio anti-trouble filter	RFZ	Heating element condensation freezer
IDS	Schackler with warning	RH	Thermal relay
IEC	ON OFF loads switch	RS	Defrosting resistance
IEFR	ON OFF refrigerator switch	RS1	Defrosting resistance no-frost evaporator
IETH	Thermostat exclusion	RS2	Defrosting resistance no-frost gutter
ILFR	Push-button for fridge lamp/fan	RTA	Thermo actuator defrosting resistance
ILFZ	Push-button for freezer lamp/fan	SA	Allarm warning
ILI	Lamp switch	SC	Freezing warning
IP	Door switch	SDC	CONTROL CARD DIAGRAM
IR	Line switch	SL	Line warning
ISC	Warning light-freezing switch	SND1	PROBE REFRIGERATOR EVAP.
IV	Fan-motor switch	SND2	AIR-PROBE FREEZER
IVFZ	Freezer fan-motor switch	SND3	AIR-PROBE REFRIGERATOR
L	Line	TA1	Open thermo actuator
LFR	Fridge lamp	TA2	Closed thermo actuator
LFZ	Freezer lamp	TC	Turbocooling
LI	Lighting lamp	TF	Fuse-thermic
M	Mass/Eart symbol	THA	Allarm thermostat
MO	Terminal board	THC	Freezer thermostat
MT	Timer motor	THDF	Refrigerator shackler thermostat
MV	Fan motor	THI	Thermostat switch
MVC	Compressor fan motor	THR	Adjustable thermostat
MVCO	Compressor compartment fan	TP	Thermoprotector