
INDESIT company



Model type:
AE2M.1(BK)

Commercial code:
F030100

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:

REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics


INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

0662a Exploded views

matr.40115.0001



0662a Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00099118				user instruction book ae2m.1		
001	C00099111				flange		
005	C00137541				deflector		
006	C00095185				motor propeller		
007	C00090422			1 x C00242721	motor		
008	C00135453			1 x C00242493	support motor		
011	C00098573				motor propeller		
012	C00138568				motor		
014	C00099112				conveyor		
023	C00099113				grease filter		
024	C00126799				filter mount. linkage h8160 b		
026	C00099138				filter grate		
029	C00126656			1 x C00242506	filter flange h3160x an		
030	C00135822			1 x C00242507	grate fixing plate		
031	C00131593			1 x C00292492	lamp 40w 240v		
032	C00098368				lampholder		
046	C00135642				lamp switch		
047	C00135643				fan motor speed - switch		
054	C00099139				rear wall bk		
055	C00099140				door bk cm 60		
079	C00095214				microswitch		
080	C00098371				microswitch slider		
082	C00095215				upper, right support		
083	C00095216				left upper guide support		
085	C00134787			1 x C00242530	fixing hook		
093	C00099117				electrical connection protection		
104	C00098372				reflector		
106	C00095218			1 x C00242534	flap support		
111	C00095219			1 x C00242541	lower, right gasket		
112	C00095220			1 x C00242532	lower, left gasket		
113	C00137555				grid bracket support		
114	C00095221			1 x C00242540	support,lwr rh		
115	C00095222				lower, left support		
116	C00137490			1 x C00242529	fastening assembly		
117	C00126332				indicator		

0662a Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
119	C00126504			1 x C00242531	sliding guide spacer		
120	C00098373			1 x C00242536	carbon filter 10559 h4260/41/380		
122	C00099141				control box ae2m.1 bk		
123	C00137491				microswitch protection		
167	C00135447			1 x C00242489	clip		
254	C00137561				lampholder fastening part		
540	C00099126				ceiling lamp right		
541	C00099127				ceiling lamp left		
552	C00095225				door locking knobs right		
553	C00095226				door locking knobs left		
999	C00143132				drain coupling + check valve		
999	C00196071				fixing brackets		

Electric schemes and links

Cod. se094A



se094A

Legend

Legend: se094A

AT	Ignition transformer	POT	Thermostated potentiometer
CF	Oven commutator	PT	Plate electric (Automatic)
CP	Plate commutator(Normal end Rapid)	PTC	Thermostated sensor
CT	Plate commutator(Automatic)	RCE	Grill heating element external
DCDR	Double Knob double crown burner control card	RCI	Grill heating element internal
EV	Electro Valve	RE	Energy regulator
FRON	Daschboard	RF	Oven lower heating element
ILG	Lamp switch turnspit	RG	Grill heating element
IT	Thermostated switch	RG COM	Grill heating element union
L	Line (Feed)	RV	Heating element ventilated oven
LF	Dashboard light	SA	Boiler operating led
LI	Oven light	SB	Thermostated burner led
M	Suction motor handle	SF	Warning light working
MG	Turnspit motor	SO	Probe temperature
MO	Terminal board	ST	Warning light thermostat
MUF	Oven	TH	Thermostat fixed
MV	Fan motor	TH2	Thermostated burner cooling
N	Neutral (Feed)	THR	Adjustable thermostat
PA	Ignition push	TP	Termoprotector
PE	Plate electric (Normal and Rapid)	TRAV	Support terminal board
PEL	Wall socket	TRM	Thermostated burner control card
PIF	Cooking programmer	VAP	Steam boiler heating element