
INDESIT company



Model type:

PO740ES(IX)/HA

Commercial code:

F048138

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4230150 Exploded views



4230150 Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00095165				user instr. book it-gb-fr-nl-es-pt-		
000	C00097896				instruction booklet pt-bd-ar		
001	C00095133				cast iron grate medium tech		
002	C00095134				rubber buffer - pan grid iron		
003	C00095146				semifast burner cap		
004	C00095143				burner base - medium burner sabaf		
005	C00095129				knob - tech po740		
006	C00094026				knob spring		
007	C00095130				knob disc - tech po740		
008	C00018819				seal - hob/worktop		
009	C00095150				gasket cup planes small		
010	C00095149				gasket cup planes medium		
011	C00093834				screw nut m6		
012	C00095164				thermocouple l=600mm		
013	C00033835				gas jet 70 - lpg/ng medium burner		
013	C00095151				natural gas semiifast burner		
014	C00095140				ignition spark plug l=600		
015	C00052934				electrode clip		
016	C00095152				burner cup - medium burner		
017	C00095359				ignition transformer		
018	C00095156				semi-rapid burner supply pipe		
019	C00095162				thermostat with valve		
020	C00064912				screw m4x18 tsp nikelata		
021	C00095137				flask		
022	C00042042				insert fixing double glass		
023	C00035727			1 x C00276836	mains supply cable 3x2,5		
024	C00052952				clamp kit - hob/worktop		
025	C00118862				base cover po740		
026	C00095138				bracket retainer		
027	C00095160				fixing bracket tech		
028	C00118868				gas pipe po740 tech		
029	C00118867				gas tap - large burner		
031	C00010506				sealing washer - gas elbow/pipe		
032	C00024370				elbow connection (1/2 male x 2)-		
033	C00095157				pipe - tap rapid		

4230150 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
034	C00095159				front right burner supply pipe		
035	C00095158				semi-rapid burner supply pipe		
038	C00095153				burner cup - large burner		
039	C00052937				gas jet 86 lpg - large burner		
039	C00052940				gas jet 116 ng large burner		
040	C00095148				gasket cup planes large		
041	C00095154				burner cup - small burner		
042	C00052939				gas jet 50 lpg - small burner		
042	C00095155				gas jet (72) gn - small burner 72		
043	C00256001				spillage tray - smooth po740es ha		
044	C00095144				burner base/flame splitter - large		
045	C00095147				fast burner cap		
046	C00095142				burner base/flame splitter - small		
047	C00095136				cast iron grate large tech		
048	C00095145				auxiliary burner cap		
049	C00095135				cast iron grate small tech		
050	C00297837				terminal block 5 f.+cavo 6a		
099	C00052960				burner fixing screw (stainless		
099	C00280173				junction clamp richco		

Electric schemes and links

Cod. 16001900100



se16001900100

Legend

Legend: 16001900100

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card