
INDESIT company



Model type:

PZ640T(IX)/HA

Commercial code:

F048141

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4230350 Exploded views



4230350 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00141752 | | | | user instructions booklet it-gb-fr- | | |
| 000 | C00141753 | | | | user instructions booklet nl-bd-pt- | | |
| 001 | C00141845 | | | | pan grid (rh) - shiny black pz640t | | |
| 002 | C00039148 | | | | rubber buffer for pan support | | |
| 003 | C00141844 | | | | pan grid (centre) shiny black | | |
| 004 | C00119202 | | 10129... | | burner cap centre tc shiny black | | |
| 004 | C00283256 | 10130... | | | burner cap centre tc shiny black | | |
| 005 | C00053174 | | 10129... | | outer burner cap black work triple | | |
| 005 | C00283257 | 10130... | | | burner cap outer tc black gloss | | |
| 006 | C00119171 | | 10129... | | burner base/flame split. - triple | | |
| 006 | C00283228 | 10130... | | | burner base/flame split. - triple | | |
| 007 | C00052932 | | | | burner cap semi rapide | | |
| 008 | C00052929 | | | | burner ring - medium | | |
| 009 | C00142721 | | 80217... | | knob inox nickel | | |
| 009 | C00263684 | 80218... | | | knob (gas tap) opaque chrome | | |
| 010 | C00039156 | | | | knob disc - spring | | |
| 011 | C00097589 | | 80217... | | knob disc - classic ix | | |
| 011 | C00263685 | 80218... | | | knob disc chrome | | |
| 012 | C00018723 | | | 1 x C00018819 | sealing gasket - hob/worktop | | |
| 013 | C00113652 | | 10129... | | jet sabaf tc d131 | | |
| 013 | C00119170 | | | | nozzle lpg d87 | | |
| 013 | C00283230 | 10130... | | | nozzle met. d145/100 | | |
| 014 | C00095765 | | | | screw nut thermo. tc | | |
| 014 | C00113400 | | | | thermocouple tc l=600mm | | |
| 015 | C00095465 | | 01023... | 1 x C00282425 | electrode tc + o-ring l=600 | | |
| 015 | C00282425 | 01024... | | | electrode tc + 3.6 kw o-ring l=600 | | |
| 016 | C00119172 | | | | burner cup - triple burner 3.8kw | | |
| 017 | C00052938 | | | | gas jet 64 lpg - medium burner | | |
| 017 | C00052941 | | | | natural gas jet (96) | | |
| 018 | C00052960 | | | | burner fixing screw (stainless | | |
| 019 | C00052926 | | | | burner cup - medium burner | | |
| 020 | C00118496 | | | 1 x C00052951 | electrode l=520 | | |
| 021 | C00052986 | | | | thermocouple ** not for triple | | |
| 021 | C00093834 | | | | screw nut m6 | | |
| 022 | C00052934 | | | | electrode clip | | |

4230350 Spare parts list


| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 023 | C00095359 | | | | ignition transformer | | |
| 024 | C00141761 | | | | gas pipe pz640 | | |
| 025 | C00035727 | | | 1 x C00276836 | mains supply cable 3x2,5 | | |
| 025 | C00280173 | | | | junction clamp richco | | |
| 026 | C00052952 | | | | clamp kit - hob/worktop | | |
| 027 | C00141764 | | | | base cover xp 640 mst | | |
| 028 | C00297837 | | | | terminal block 5 f.+cavo 6a | | |
| 029 | C00141763 | | | | tap bracket pz | | |
| 030 | C00141760 | | | | fixing saddle - gas tap | | |
| 031 | C00145274 | | | 1 x C00002455<br>1 x C00111239<br>1 x C00111241 | gas tap fast 90 micromeccanica | | |
| 031 | C00145275 | | | 1 x C00002455<br>1 x C00111239<br>1 x C00111240 | gas tap aux/semifast micromeccani | | |
| 031 | C00145690 | | | 1 x C00002455<br>1 x C00111239<br>1 x C00111244 | gas tap triple burner 90 | | |
| 032 | C00141756 | | | | front left burner supply pipe | | |
| 033 | C00141758 | | | | burner supply pipe aux | | |
| 034 | C00141757 | | | | pipe semifast- tap | | |
| 035 | C00141759 | | | | pipe burner t.c. | | |
| 036 | C00052925 | | | | burner cup - large burner | | |
| 037 | C00056359 | | | | gas jet (80) lpg - large burner | | |
| 037 | C00056360 | | | | gas jet 110 nat gas - large burner | | |
| 038 | C00052927 | | | | burner cup - small burner | | |
| 039 | C00052939 | | | | gas jet 50 lpg - small burner | | |
| 039 | C00066166 | | | | nat gas aux. burner nozzle rapido | | |
| 041 | C00010506 | | | | sealing washer - gas elbow/pipe | | |
| 042 | C00024370 | | | | elbow connection (1/2 male x 2)- | | |
| 043 | C00255986 | | | | working table pz 640 t ix ha | | |
| 044 | C00052928 | | | | burner ring/flame splitter - large | | |
| 045 | C00052931 | | | | burner cap rapide (large) black | | |
| 046 | C00052930 | | | | burner base/flame splitter - small | | |
| 047 | C00052933 | | | | burner cap auxiliary (small) black | | |

4230350 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 048 | C00141843 | | | | pan grid (lh) shiny black pz640- | | |
| 049 | C00111235 | | | | microswitch ring | | |
| 049 | C00143913 | | | | ignition microswitch (4) copreci | | |
| 099 | C00090374 | | | | spark plug seal | | |
| 099 | C00111239 | | | | screw m4x17tsp zinc | | |
| 099 | C00142729 | | | 1 x C00142145 | self-tapping screw 8spx6,35t1/2tz | | |
| 099 | C00263686 | | | | kit knob (gas tap) opaque chrome | | |

Electric schemes and links

Cod. 16001636200




se16001636200

# Legend

Legend: 16001636200

| | | | |
|---|---|---|---|
| AE | Ignition transformer | PE | Plate electric (Normal and Rapid) |
| AT | Ignition transformer | PEL | Wall socket |
| CF | Oven commutator | PIF | Cooking programmer |
| CP | Plate commutator(Normal end Rapid) | POT | Thermostated potentiometer |
| CT | Plate commutator(Automatic) | PT | Termoprotector |
| DC DR | Double Knob double crown burner control card | PTC | Thermostated sensor |
| EV | Electro-Valve | RCE | Grill heating element ex- ternal |
| FC | End of cooking programmer | RCI | Grill heating element internal |
| FRONT | Daschboard | RE | Energy regulator |
| I/LF | OVEN LIGHT SWITCH | RF | Oven lower heating element |
| I/LF-MG | OVEN LIGHT SWITCH + ROTISSERIE | RG | Grill heating element |
| I/MG | TURNSPIT SWITCH | RG COM | Grill heating element un- ion |
| IL | Knobs' Lighting | RV | Heating element ventilated oven |
| ILG | Lamp switch turnspit | SA | Boiler operating led |
| IT | Thermostated switch | SB | Thermostated burner led |
| L | Line (Feed) | SF | Warning light working |
| LF | Oven light | SO | Probe temperature |
| LI | Oven light | SP | Operating Indicator Light for the Plate |
| M | Suction motor handle | ST | Warning light thermostat |
| MG | Turnspit motor | TH | Thermostat fixed |
| MO | Terminal board | TH2 | Thermostated burner cooling |
| MUFF | Oven | THR | Adjustable thermostat |
| MV | Fan motor | TP | Termoprotector |
| N | Neutral (Feed) | TRAV | Support terminal board |
| PA | Ignition push-button | TRM | Thermostated burner control card |