
INDESIT company



Model type:

FK83.1EXHA

Commercial code:

F085264

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes


4420130 Exploded views



4420130 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00285255				oven top luce 2010		
002	C00285249				side panel right experience 2010		
003	C00285252				hinge gas roller supp+roller right		
004	C00285241				red warning light led 230v		
005	C00309254				control panel fk83.1exha		
006	C00295980				knob oven fk 83.1 x/ha (luce)		
007	C00285240				neon lens clear new exp.2010		
008	C00256198				rubber		
008	C00308944				oven door seal no piro luce		
009	C00309075				oven front panel no piro luce		
011	C00285212				door handle ix luce 2010		
012	C00285281				bolt hilo 4x17 tcb ph2 znb		
013	C00302171				deflector door inf.nopyro-no led-		
014	C00285248				hinge for oven door 2v f.luce no		
015	C00285246				outer door glass fk 61 x/ha		
016	C00285250				screw hilo 4x20 tmt fr mg ph2		
017	C00285247				oven inner door glass f60 bk		
018	C00285254				oven bottom cover experience		
019	C00285253				lh oven door hinge support		
020	C00285251				side panel left experience 2010		
021	C00291393				back panel ovens luce2010		


4420210 Exploded views



4420210 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00274590				oven insulation 3cm eurofibre		
002	C00296217				seal chimney exp 2010		
002	C00297548				chimney luce 2010		
003	C00309070				heat distribution panel fk83.1		
004	C00081585				taptite screw		
005	C00295924				oven grid		
006	C00308425				grill pan black rapid clean.		
007	C00307468				oven fk83.1 smaltato rapid clean		
008	C00274591				oven insulation mat - rear 3cm 7c		
009	C00303599				rear cross beam sp. 0.6mm		

4420330 Exploded views




4420330 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00297387				ventilation ducting -p nt nd-		
003	C00297549				deviator air luce 2010 can. spinta		
004	C00145486				oven thermostat		
005	C00039578				push in spring clip - thermostat		
006	C00081591				upper element oven/grill		
007	C00138834				round heating element		
008	C00288251				oven botton heating element		
009	C00288252				lower heating element box		
010	C00275943				mains supply cable 3x1,5 (os e 48)		
011	C00271142				terminal block		
012	C00076978				oven lamp 25w 220v		
013	C00078426				lamp assembly 25 w 230 v		
014	C00303460				circulating fan motor		
014	C00307140				fan nut		
015	C00089573				thermostat (ck)		
016	C00297130				commutator fast cooking		
017	C00266931				electronic programmer easy to use		
017	C00296899				buttons (programmer)		
018	C00285274				gasket dashboard luce 2010		
019	C00285263			1 x C00297387	closing panel singolar canal. exp		
020	C00089130				cooling fan 220-240 v. (ck)		
021	C00285269				thermostat 62c n.a		
099	C00270746				junction clamp		

Electric schemes and links

Cod. 16002630400



16002630400

Legend

Legend: 16002630400

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card