
INDESIT company



Model type:
DKFIX/HA

Commercial code:
F078216

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

18734731 Exploded views



18734731 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00291181				handle		
002	C00267564				lid - oil pan		
003	C00045344				fryer wire basket		
004	C00045342				fryer oil pan		
005	C00291182				knob nichel		
006	C00275548				support - heating element		
007	C00045347				"u" wire spring - hinge		
008	C00045341				ball - element hinge (hcr 58-65)		
009	C00045339				coil spring - element hinge		
010	C00045338				spring cap(hex)-element hinge		
011	C00289680				dryer heating element		
012	C00276846				pilot lamp lens		
013	C00045302				indicator light		
014	C00291183				yellow/green pilot lamp		
015	C00081782				indicator light -white		
016	C00081783				operating thermostat + switch		
017	C00045351				insulating casing - thermostat		
018	C00275548				support - heating element		
019	C00045350				retaining coil-t/stat capllary		
020	C00289679				safety thermostat		
021	C00045235				spring nut		
022	C00045332				insulation plate - terminal block		
023	C00045324				terminal block		
024	C00045322				cover - terminal block		
025	C00045323				cable clamp		
026	C00081752				plate clamp hobs		
027	C00275566				base cover tray		
028	C00045334				outer casing - oil pan		
029	C00045335				bottom support - casing		
030	C00291185				top plate pld f1 exp.ix ha		