
# 0191040008

## DE'LONGHI "INT" XTD3096E

Red



# DE'LONGHI XTD 3096E ORBIT ROSSO

## INT XTD3096E

| Pos. | Code | Description |
|---|---|---|
| | SP1705045 | Y 45/4 CONF-4SACC AIRSPACE |
| 01 | FU1073 | SUPPORT BASE |
| 02 | FU1016 | PROFILE |
| 03 | FU1017 | SIDE LEFT |
| 04 | FU1018 | BUMPER |
| 05 | FU1074 | CASTOR |
| 06 | ES000 | *NOT AVAILABLE |
| 07 | FU1075 | FLEXIBLE TUBE |
| 08 | FU1022 | CABLE WINDER |
| 09 | FU1076 | HANDLE |
| 10 | FU1023 | BRUSH |
| 11 | FU1024 | CLIP |
| 12 | FU1025 | PROTECTION |
| 13 | FU1026 | PIN |
| 14 | FU1027 | PUSH BUTTON |
| 15 | FU1028 | SPRING |
| 16 | FU1077 | COVER |
| 17 | FU1030 | RING NUT |
| 18 | FU1031 | BRUSH |
| 19 | FU1032 | VALVE |
| 20 | FU1033 | GASKET |
| 21 | FU1078 | COVER |
| 22 | FU1079 | PUSH BUTTON |
| 23 | FU1080 | BOARD |
| 24 | FU1081 | BODY |
| 25 | FU1038 | PUSH BUTTON |
| 26 | FU1039 | SPRING |
| 27 | FU1040 | PUSH BUTTON |
| 28 | FU1041 | SPRING |
| 29 | FU1042 | SWITCH |
| 31 | FU1043 | PUSH BUTTON |
| 32 | FU1044 | SPRING |
| 33 | 5391513600 | FILTER |
| 34 | FU1046 | SUPPORT |
| 36 | FU1047 | SUPPORT |
| 37 | FU1048 | RING NUT |
| 38 | FU1049 | RING |

## DE'LONGHI XTD 3096E ORBIT ROSSO

## INT XTD3096E

| | | |
|---|---|---|
| 39 | FU1050 | TUBE |
| 40 | FU1051 | GASKET |
| 41 | FU1052 | SPRING |
| 42 | FU1053 | VENT |
| 43 | FU1054 | GRID |
| 44 | FU1055 | SUPPORT RIGHT |
| 45 | FU1056 | SUPPORT LEFT |
| 46 | FU1057 | SUPPORT |
| 47 | FU1062 | BEARING |
| 48 | FU1058 | SUPPORT |
| 49 | FU1059 | HEPA FILTER |
| 50 | FU1060 | COVER |
| 51 | FU1061 | INSULATOR |
| 53 | FU1063 | SUPPORT |
| 54 | FU1064 | INSULATOR |
| 56 | FU1082 | MOTOR |
| 57 | FU1083 | BOARD |
| 58 | FU1067 | RING |
| 61 | FU1068 | SIDE RIGHT |
| 62 | FU1069 | CASTOR |
| 63 | ES000 | *NOT AVAILABLE |
| 64 | CJ1236 | BRUSH |