Coffeemaker

HD7450/00

Service
Service
Service



Philips Consumer Lifestyle

ServiceManual

PRODUCT INFORMATION

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

TECHNICAL INFORMATION

• Voltage	: 220 - 240 V
• Frequency	: 50 - 60 Hz
• Power consumption	: 650 W
• Standby power	: 0.5 W
• Contents jug	: 600 cc
• Coloursetting	: Metal / Black
• Filter size	: 1 x 2
• Dimentions (L x H x W)	: 220 x 170 x 260 mm

- **Descaling**
  When the water system is almost clogged by scale, operate the appliance a couple of times with 0.8 L white vinegar (4% acetic acid), with a paper filter in place.
  You may also use another suitable liquid descaler, in that case follow the instructions on the packaging of the descaler. Do not use other descaling agents, as this may harm the appliance.
  When this does not restore the function, then switch off the appliance when about half of the citric acid has passed through the system. Then let the appliance soak overnight, after that, continue the descaling operation.

  After descaling operate the appliance twice with a full tank of clean tap water to flush out any residual substances.

DISASSEMBLY- AND RE-ASSEMBLY ADVICE

- No specific issues

OPTIONAL (accessories)

- No specific issues

Published by Philips Consumer Lifestyle Printed in the Netherlands
© Copyright reserved Subject to modification

12/07

PHILIPS

- To be able to access the heating element in the appliance remove, the four screws (**A**) from the base of the appliance and remove the base plate. The hoses between the heater and the elbow joint and between the elbow joint and the tank are simple slide on connections.

- Please observe the proper cable routing when reinstalling the Mains cord and Mains switch. Also check if the internal cable storage is still functional after repair.

- The Tank lid (**1**) and Spout (**2**) have simple click connections and are easily replaceable.

PARTS LIST

Pos	Service code	Description	Remark
1	9965 100 57302	Tank lid	Black
2	9965 100 57304	Spout	Black
3	4222 459 48691	Filter holder	incl. drip stop
4	9965 100 57303	Spout pipe	
5	4222 459 48671	Jug lid	
6	4222 459 48651	Jug assy	incl. jug lid
7	4222 247 35400	Spoon	
8	4222 259 47851	Tubular pump	220 - 240 V
9	4222 248 43801	Fuse	
10	4222 259 19960	Thermostat	
11	4222 246 20042	Switch	

HD7450/00

