
INDESIT company



Model type:

D320MSIX/HA

Commercial code:

F050116

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

41711j0 Exploded views



41711j0 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00081685				user instruction book-i-de-es-fr-nl-		
001	C00076405				rubber buffer - pan grid		
002	C00081754				burner grid (2 burner) - black		
003	C00052933				burner cap auxiliary (small) black		
004	C00052930				burner base/flame splitter - small		
005	C00008505				retention plate 12x8x2		
005	C00053219				knob (gas tap/switch) - black		
006	C00039156				knob disc - spring		
007	C00053220				knob disc black		
008	C00081741				compression ring		
009	C00081765				microswitch 2f.		
010	C00045232				surround - ignition button		
011	C00081740				spacer		
012	C00057210				gas pipe elbow 1/2" gas		
013	C00057243				sealing washer-gas elbow/pipe		
014	C00081760				connection pipe		
015	C00081757				pipe - tap 2f.		
016	C00081756				burner tap by-pass 40/100		
017	C00052927				burner cup - small burner		
018	C00081761				connection pipe		
019	C00081758				burner tap by-pass 30/100		
020	C00081766				barrier		
021	C00081732				bracket - supply gas pipe		
022	C00045235				spring nut		
023	C00057251				plate clamp hobs		
024	C00081755				base cover tray		
025	C00045245				cable clamp - mains cable (black)		
026	C00076427				terminal board cover		
027	C00045248				terminal block (2 pole)		
029	C00076429				terminal board support		
030	C00045282				gasket for nozzle with valve		
031	C00052925				burner cup - large burner		
032	C00052934				electrode clip		
033	C00052951				ignition electrode (l=700)		
034	C00081763				thermocouple 300mm		

41711j0 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
034	C00081764				thermocouple 550mm		
035	C00081739				insulator		
036	C00081715				spark ignition transformer		
037	C00081738				impellor thermocouple		
038	C00081726			1 x C00002373	taptite screw		
039	C00081724			1 x C00026766	support bracket - glass cover		
040	C00081713			1 x C00032682	blanking plug - lid hinge hole		
041	C00259612				spillage tray -2f.stainless steel ha		
042	C00052928				burner ring/flame splitter - large		
043	C00052931				burner cap rapide (large) black		
044	C00081128				glass lid (not uk) cd 3(mr)		
045	C00081133				cover left hinge		
046	C00081132				cover right hinge		
047	C00081135				cover left support		
048	C00081134				cover right support		
049	C00081298				taptite screw m4x12 f.ron.t.e.zntrp		
050	C00053196				rubber buffer - glass lid front		
099	C00045250				clamping plate - hob/worktop		
099	C00052937				gas jet 86 lpg - large burner		
099	C00052939				gas jet 50 lpg - small burner		
099	C00052940				gas jet 116 ng large burner		
099	C00066166				nat gas aux. burner nozzle rapido		
099	C00082704				kit injector gas butano/gpl		