
INDESIT company



Model type:

CE6VM3(X)R/HA

Commercial code:

F048535

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes


4280190 Exploded views



4280190 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00196556 | | | | instruction book cs-it-uk-hu | | |
| 001 | C00123048 | | | | rubber bumper | | |
| 002 | C00258739 | | | | working table glass ha an | | |
| 003 | C00064577 | | | | top fixing square | | |
| 004 | C00139280 | | | | heater 2100w/230v | | |
| 005 | C00064285 | | | | side crosspiece c.60 | | |
| 006 | C00139052 | | | | heater 1200w/230v | | |
| 007 | C00115183 | | | | side panel right inox 50x60x60 | | |
| 008 | C00115184 | | | | side panel left inox 50x60x60 | | |
| 009 | C00098784 | | 40512... | | back strut rh/lh c60x60 lodz | | |
| 009 | C00308395 | 40513... | | | back strut rh/lh c60x60 lodz | | |
| 010 | C00098794 | | | | back panel cooker 60x60 lodz | | |
| 011 | C00140021 | | | | back support | | |
| 012 | C00139053 | | | | heater 1700w/230v | | |
| 013 | C00058383 | | | | fixing spring | | |
| 014 | C00136453 | | | | brown bumper | | |
| 015 | C00065059 | | | | residual heat lights | | |
| 099 | C00044805 | | | | 2-pole earthing rivet | | |

4280220 Exploded views




4280220 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00098800 | | | | chimney c60x60 lodz | | |
| 002 | C00099212 | | | | reduction chimney c60x60 lodz | | |
| 005 | C00094418 | | | | stop mains supply cable | | |
| 006 | C00051679 | | | | supply cable 3x4 l.1,5 | | |
| 007 | C00082512 | | | | junction block itw f2000 | | |
| 009 | C00121897 | | | | thermostat, 16a 250v 250øc | | |
| 010 | C00081591 | | | | upper element oven/grill | | |
| 011 | C00098797 | | | | electric oven insulation mat 60x60 | | |
| 012 | C00112217 | | | | cavity mult. c60x60 | | |
| 013 | C00098802 | | | | oven front panel c60x60 lodz | | |
| 014 | C00081579 | | | | oven door seal | | |
| 015 | C00098793 | | | 1 x C00297712 | hinge roller support right 60x60 | | |
| 016 | C00081577 | | | 1 x C00301789 | grill pan black | | |
| 017 | C00081578 | | | | oven grid | | |
| 018 | C00098803 | | | | condensation trim lower door - | | |
| 019 | C00108932 | | | 1 x C00081584 | oven back panel c60x60 | | |
| 020 | C00039578 | | | | push in spring clip - thermostat | | |
| 021 | C00081585 | | | | taptite screw | | |
| 022 | C00098787 | | | | base plate c60x60 lodz | | |
| 022 | C00098788 | | | | bracket for base plate c60x60 lodz | | |
| 023 | C00016119 | | | 1 x C00055585 | foot | | |
| 024 | C00139991 | | | | drawer/oven panel | | |
| 030 | C00138829 | | | | lower heating element box | | |
| 031 | C00081590 | | 11001... | 1 x C00288251<br>1 x C00288252 | oven botton heating element | | |
| 031 | C00288251 | 11002... | | | oven botton heating element | | |
| 032 | C00098792 | | | 1 x C00297711 | hinge roller support left 60x60 | | |
| 037 | C00081580 | | | | oven insulation mat - rear | | |
| 038 | C00076978 | | | | oven lamp 25w 220v | | |
| 039 | C00078426 | | | | lamp assembly 25 w 230 v | | |
| 040 | C00119339 | | | | rear cross beam new s2000 | | |
| 041 | C00081589 | | | | circulating fan motor 220-240v | | |
| 099 | C00017240 | | | | self-tapping screw 8px9,52 t1/2t- | | |

4280320 Exploded views

matr.40115.0001




4280320

4280320 Spare parts list


| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00013413 | | | | energy regulator (hotplate) 6+0 | | |
| 002 | C00088318 | | | 1 x C00196053 | commutator electr. oven | | |
| 003 | C00196555 | | | | dashboard ce6vm3 (x) r | | |
| 004 | C00074135 | | | | neon lens clear | | |
| 005 | C00016035 | | | | control knob disc spring | | |
| 006 | C00194379 | | | | knob electric bk ari | | |
| 007 | C00099195 | | | | oven inner door + inner door | | |
| 008 | C00109322 | | | | oven door handle black l=593 | | |
| 009 | C00258740 | | | | inox oven door glass ha c60 + | | |
| 010 | C00098782 | | 20118... | | warming drawer front 60x60 lodz | | |
| 011 | C00109654 | | | | black dishwarmer door support | | |
| 012 | C00098880 | | | | dishwarmer door inox 593x138 | | |
| 014 | C00139979 | | | | front drawer support | | |
| 015 | C00139980 | | | | drawer sheet metal c60x60 | | |
| 016 | C00098780 | | | | drawer support left 60x60 | | |
| 017 | C00098779 | | | | drawer support right 60x60 | | |
| 018 | C00098796 | | | | hinge for oven door normal | | |
| 019 | C00131242 | | | | roller holder | | |
| 024 | C00109660 | | | | inner dashboard c60x60 analogic | | |
| 025 | C00078436 | | | | oven thermostat | | |
| 027 | C00194454 | | | | black knob disc sch/ari rest c60 | | |
| 028 | C00074157 | | | | pilot light red | | |
| 028 | C00082507 | | | | pilot light green | | |
| 029 | C00064266 | 90420... | | | button for programmer coupatan | | |
| 029 | C00065022 | | 90419... | 1 x C00064266 | elek.timer knob black | | |
| 030 | C00039241 | | | | dial glass- timer for rustic oven | | |
| 031 | C00117517 | | 90419... | | timer 180 min. pw | | |
| 031 | C00278622 | 90420... | | | timer | | |
| 099 | C00017240 | | | | self-tapping screw 8px9,52 t1/2t- | | |
| 099 | C00082509 | | | | taptite screw m4x10 | | |

Notices


n1015106: PLATES CHANGEOVER SWITCH C00013413

---


The plates changeover switch used for cookers produced in the Lodz plant can be supplied by three different manufacturers: Deka, Ego and Dreefs.
The three changeover switches, even though different in appearance, are interchangeable.
Part code C00013413 used for service operations is the EGO changeover switch.
Pictures of the three changeover switches and the relative electrical connection diagram of are given below.



# DREEFS


4
3
1
2
5
P2
P1
P3
70.5
23
49
29.5
16.5
M 4
28
0 position
ROTATION


# EGO


4
3
1
2
5
P2
P1
P3
575
815
48
28
M4
27
ROTATION
position 0

| position | P3 | | P1 | | | P2 | |
|---|---|---|---|---|---|---|---|
| 0 | | | | | | |  |
| 1 | X | X | X | | X | X |  |
| 2 | X | X | | | X | X |  |
| 3 | X | X | | | X | |  |
| 4 | X | X | | | | X |  |
| 5 | X | | | X | | X |  |
| 6 | X | | X | | X | |  |

## Electric schemes and links

Cod. 16001779700



# Legend

Legend: 16001779700

| | | | |
|---|---|---|---|
| AE | Ignition transformer | PE | Plate electric (Normal and Rapid) |
| AT | Ignition transformer | PEL | Wall socket |
| CF | Oven commutator | PIF | Cooking programmer |
| CP | Plate commutator(Normal end Rapid) | POT | Thermostated potentiometer |
| CT | Plate commutator(Automatic) | PT | Termoprotector |
| DC DR | Double Knob double crown burner control card | PTC | Thermostated sensor |
| EV | Electro-Valve | RCE | Grill heating element ex- ternal |
| FC | End of cooking programmer | RCI | Grill heating element internal |
| FRONT | Daschboard | RE | Energy regulator |
| I/LF | OVEN LIGHT SWITCH | RF | Oven lower heating element |
| I/LF-MG | OVEN LIGHT SWITCH + ROTISSERIE | RG | Grill heating element |
| I/MG | TURNSPIT SWITCH | RG COM | Grill heating element un- ion |
| IL | Knobs' Lighting | RV | Heating element ventilated oven |
| ILG | Lamp switch turnspit | SA | Boiler operating led |
| IT | Thermostated switch | SB | Thermostated burner led |
| L | Line (Feed) | SF | Warning light working |
| LF | Oven light | SO | Probe temperature |
| LI | Oven light | SP | Operating Indicator Light for the Plate |
| M | Suction motor handle | ST | Warning light thermostat |
| MG | Turnspit motor | TH | Thermostat fixed |
| MO | Terminal board | TH2 | Thermostated burner cooling |
| MUFF | Oven | THR | Adjustable thermostat |
| MV | Fan motor | TP | Termoprotector |
| N | Neutral (Feed) | TRAV | Support terminal board |
| PA | Ignition push-button | TRM | Thermostated burner control card |