
INDESIT company



Model type:
AHSF.SIX/HA

Commercial code:
F080049

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

SVL001 Exploded views




SVL001 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00293342				assembly motor k25		
002	C00293421				right motor k25		
003	C00293422				left motor k25		
004	C00293424				control panel speed		
005	C00293426				control panel lamp		
006	C00293427				right motor propeller		
007	C00293428				left motor propeller		
008	C00293429				motor support		
009	C00293430				switch		
010	C00293431				lamp holder 210 mm		
011	C00293432				power supply cord with plug		
012	C00293433				terminal box		
013	C00293434				terminal board cover acc		
014	C00293435				lamp 25w		
015	C00293436				grease filter		
016	C00293437				slide 185mm		
017	C00293438				lamp cover		
018	C00293439				chimney adapter d.120		
019	C00293440				chimney valve ø120 mm		
020	C00293441				white right support		
021	C00293442				white left support		
022	C00293443				casing assembly		
023	C00293444				right frame		
024	C00293445				left frame		
025	C00293446				sliding sheet 216 mm		
026	C00293448				ceiling lamp support		
027	C00293449				front panel handle		
028	C00293451				filter carbon ##		
029	C00293452				installation kit		

Electric schemes and links

Cod. SE_SVL01



Legend

Legend: SE_SVL01