
INDESIT company



Model type:

FI51.B(BK)

Commercial code:

F033898

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4200190 Exploded views



4200190 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00115133				instructions booklet it-gb-fr-es-pt-		
001	C00081571				back panel ovens		
002	C00081573				top oven		
006	C00121897				thermostat, 16a 250v 250øc		
007	C00081591				upper element oven/grill		
009	C00039578				push in spring clip - thermostat		
010	C00088318			1 x C00196053	commutator electr. oven		
012	C00082349				oven insulation		
013	C00074135				neon lens clear		
014	C00115146				dashboard panel bk fi51.b		
015	C00114923				knob black lucid		
016	C00113241			1 x C00115541	right oven front panel		
				1 x C00115543			
018	C00090670			1 x C00143917	rh oven door hinge support		
019	C00081585				taptite screw		
020	C00081584			1 x C00290626	oven back panel (inner) enamelled		
022	C00081577			1 x C00301789	grill pan black		
023	C00081578				oven grid		
024	C00143009			1 x C00297744	oven door glass black indesit rohs		
026	C00033431				screw m5 x 20 tsp black		
026	C00115134				oven door handle black		
027	C00090677				oven door hinge		
028	C00090674			1 x C00115137	oven metal inner door+glass		
031	C00082486				oven bottom cover		
032	C00138829				lower heating element box		
033	C00081590		11001...	1 x C00288251	oven botton heating element		
				1 x C00288252			
033	C00288251	11002...			oven botton heating element		
035	C00090671			1 x C00143930	lh oven door hinge support		
036	C00090669			1 x C00115541	side panel left		
				1 x C00115545			
037	C00081581				oven insulation		
038	C00076978				oven lamp 25w 220v		
039	C00078426				lamp assembly 25 w 230 v		
040	C00081601		20316...		terminal block itw x f2000		


4200190 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
040	C00271142	20317...			terminal block		
041	C00081574			1 x C00119339	rear cross beam		
042	C00026767				supply cable 10a 3x1		
043	C00081589				circulating fan motor 220-240v		
044	C00052527				minute timer d = 6mm		
045	C00074157				pilot light red		
046	C00083853			1 x C00270746	junction clamp		
047	C00082365				oven thermostat		
048	C00081579				oven door seal		
049	C00090695				black oven front panel		
050	C00082376				electric oven		
052	C00115136				outlet vent (inner)		
053	C00114009				oven door trim black		
099	C00017240				self-tapping screw 8px9,52 t1/2t-		
099	C00033163				washer - black		
099	C00088347			1 x C00145442	screw trc 3.5x25 tsp		

Electric schemes and links

Cod. se082700

SE082700



COMMUTATORE DREEFS COD.160.013090.00

Legend

Legend: se082700

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card