
INDESIT company



Model type:

HE60.SX/HA

Commercial code:

F080048

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

SVL002 Exploded views




SVL002 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00293457				assembly motor k25		
002	C00293421				right motor k25		
003	C00293432				power supply cord with plug		
004	C00293458				lamp holder 400 mm		
005	C00293459				push-button board		
006	C00293433				terminal box		
007	C00293435				lamp 25w		
008	C00293460				terminal board cover acc		
009	C00293440				chimney valve ø120 mm		
010	C00293461				grease filter		
011	C00293438				lamp cover		
012	C00293462				motor propeller		
013	C00293463				motor support		
014	C00293464				console panel		
015	C00293465				casing assembly		
016	C00293466				lower chimney section		
017	C00293467				chimney upper		
018	C00293468				filter carbon		
019	C00293469				installation kit		

Electric schemes and links

Cod. SE_SVL02



Legend

Legend: SE_SVL02