




Gebrauchsanweisung
52 2401

Montageanweisung
52 2404


Copyright © (2016) by Siemens / SERGR_4101




Copyright © (2016) by Siemens / SERGR_4101




Copyright © (2016) by Siemens / SERGR_4101




Copyright © (2016) by Siemens / SERGR_4101




Copyright © (2016) by Siemens / SERGR_4101




Copyright © (2016) by Siemens / SERGR_4101



Copyright © (2016) by Siemens / SERGR_4101



Copyright © (2016) by Siemens / SERGR_4101



TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES					
Verdichter/Compressor/Compresseur Typ/Type Förderleistung/Delivery/Débit Anlaufstrom/Starting current/Cour Widerstand/Resistance/Résistance	de démarrage Ha/main/prin. Hi/aux	l/h A Ω Ω			
Temp.-Regler/Thermostat Typ/Type Reglerstellung/Position Schaltwerte/Switching values/ Valeurs de commutation („abtauen" od.)	„ein" „aus" „alarm"	°C			
Füllmenge/Fill.quantity/Charge	R134a	g			
Anschlußwert/Conn.load/Puiss. connectée		W			
Heizung/Heater/Chauffage Widerstand/Resistance/Résistance Leistung/Power/Puissance		Ω W			
Ventilator/Blower/Ventilateur Widerstand/Resistance/Résistance		Ω			
Schaltuhr/Timer/Minuterie de contact Widerstand/Resistance/Résistance		Ω			
Magnetventil/Magnetic valve/Electrovanne Widerstand/Resistance/Résistance Spannung/Voltage/Tension		Ω V			

Pos.			
1	14 1511		
2	16 2688		
3	16 2662		
4			
5			
6	15 4471		
7			
8	15 4472		
9	15 4470		
10	15 4469		
11			
12			

Copyright © (2016) by Siemens / SERGR_4101