
INDESIT company



Model type:

FR540.2(AN)

Commercial code:

F032169

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4210160 (... - 60831...) Exploded views




4210160 (... - 60831...) Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00094705				user instr. book it-gb-fr-es-pt-nl-		
000	C00111469				user instr. book ar fb51		
001	C00081571				back panel ovens		
002	C00081573				top oven		
003	C00089130				cooling fan 220-240 v. (ck)		
004	C00143061				evac.conduit preassembled rohs		
005	C00081599				thermostat 75c n.a. (ck)		
006	C00081587				ventilation ducting		
007	C00089573				thermostat (ck)		
008	C00081591				upper element oven/grill		
009	C00039578				push in spring clip - thermostat		
010	C00088318			1 x C00196053	commutator electr. oven		
012	C00074157				pilot light red		
013	C00083853			1 x C00270746	junction clamp		
014	C00081597				oven thermostat		
015	C00081582				chimney		
016	C00081581				oven insulation		
017	C00111471				rustic knob an/brownish		
018	C00074135				neon lens clear		
019	C00081569			1 x C00111653	side panel right		
020	C00143322				rh oven door hinge support rohs		
021	C00081585				taptite screw		
022	C00081584			1 x C00290626	oven back panel (inner) enamelled		
023	C00081577			1 x C00301789	grill pan black		
024	C00081578				oven grid		
025	C00082420				moulding - glass fixing		
026	C00082419				plate clamp handle		
027	C00082473				handle spacer		
028	C00110643				rustic door-handle brownish frg		
029	C00042326				screw m5x20 tcb		
030	C00094986				an oven door glass + squad.		
031	C00081594				oven door hinge (fixed pivot)		
032	C00082406				oven metal inner door+glass		
033	C00017240				self-tapping screw 8px9,52 t1/2t-		
034	C00082416				packing inner door fr54		

4210160 (... - 60831...) Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
035	C00081572				oven bottom cover		
036	C00138829				lower heating element box		
037	C00081590		11001...	1 x C00288251	oven botton heating element		
				1 x C00288252			
037	C00288251	11002...			oven botton heating element		
038	C00082414				oven front panel graphics fr54(an)		
039	C00143323				lh oven door hinge support rohs		
040	C00081568				cabinet fixing		
041	C00081570			1 x C00111655	side panel left		
042	C00081580				oven insulation mat - rear		
043	C00076978				oven lamp 25w 220v		
044	C00078426				lamp assembly 25 w 230 v		
045	C00081601		20316...		terminal block itw x f2000		
045	C00271142	20317...			terminal block		
046	C00081574			1 x C00119339	rear cross beam		
047	C00026767				supply cable 10a 3x1		
048	C00081589				circulating fan motor 220-240v		
049	C00081602			1 x C00094532	electric oven		
050	C00082414				oven front panel graphics fr54(an)		
051	C00081579				oven door seal		
052	C00082364				condensation trim - lower door		
053	C00081583				taptite screw m4x8		
054	C00144559				plate for fixing cooking		
055	C00111470			1 x C00275203	timer peapsa 230v 50hz		
056	C00039241				dial glass- timer for rustic oven		
057	C00110578				brownish button		
099	C00082509				taptite screw m4x10		
099	C00088347			1 x C00145442	screw trc 3.5x25 tsp		
099	C00089119				screw condensation trim - lower		

4210160a (60901...- ...) Exploded views



4210160a (60901...- ...) Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00094705				user instr. book it-gb-fr-es-pt-nl-		
000	C00111469				user instr. book ar fb51		
001	C00081571				back panel ovens		
002	C00081573				top oven		
003	C00195671				rubber drain conduct panel		
004	C00195672				fan motor blower		
005	C00082750				thermostat 62øc n.a		
006	C00195669				motor blower 220-240v 50/60hz		
007	C00089573				thermostat (ck)		
008	C00081591				upper element oven/grill		
009	C00039578				push in spring clip - thermostat		
010	C00088318			1 x C00196053	commutator electr. oven		
012	C00074157				pilot light red		
013	C00083853			1 x C00270746	junction clamp		
014	C00081597				oven thermostat		
015	C00195667			1 x C00285818	drain conduct panel ass.y		
016	C00082349				oven insulation		
017	C00111471				rustic knob an/brownish		
018	C00074135				neon lens clear		
019	C00081569			1 x C00111653	side panel right		
020	C00143322				rh oven door hinge support rohs		
021	C00081585				taptite screw		
022	C00081584			1 x C00290626	oven back panel (inner) enamelled		
023	C00081577			1 x C00301789	grill pan black		
024	C00081578				oven grid		
025	C00082420				moulding - glass fixing		
026	C00082419				plate clamp handle		
027	C00082473				handle spacer		
028	C00110643				rustic door-handle brownish frg		
029	C00042326				screw m5x20 tcb		
030	C00094986				an oven door glass + squad.		
031	C00081594				oven door hinge (fixed pivot)		
032	C00082405				oven metal inner door+glass		
033	C00017240				self-tapping screw 8px9,52 t1/2t-		
034	C00082416				packing inner door fr54		

4210160a (60901...- ...) Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
035	C00081572				oven bottom cover		
036	C00138829				lower heating element box		
037	C00081590		11001...	1 x C00288251	oven botton heating element		
				1 x C00288252			
037	C00288251	11002...			oven botton heating element		
038	C00082414				oven front panel graphics fr54(an)		
039	C00143323				lh oven door hinge support rohs		
040	C00081568				cabinet fixing		
041	C00081570			1 x C00111655	side panel left		
042	C00081580				oven insulation mat - rear		
043	C00076978				oven lamp 25w 220v		
044	C00078426				lamp assembly 25 w 230 v		
045	C00081601		20316...		terminal block itw x f2000		
045	C00271142	20317...			terminal block		
046	C00081574			1 x C00119339	rear cross beam		
047	C00026767				supply cable 10a 3x1		
048	C00081589				circulating fan motor 220-240v		
049	C00090922			1 x C00082376	electric oven		
051	C00081579				oven door seal		
052	C00082364				condensation trim - lower door		
053	C00195670			1 x C00285818	drain conduct panel thermoplastic		
054	C00144559				plate for fixing cooking		
055	C00111470			1 x C00275203	timer peapsa 230v 50hz		
056	C00039241				dial glass- timer for rustic oven		
057	C00110578				brownish button		
099	C00082509				taptite screw m4x10		
099	C00088347			1 x C00145442	screw trc 3.5x25 tsp		
099	C00089119				screw condensation trim - lower		

Electric schemes and links

Cod. 16001361102



se16001361102

Legend

Legend: 16001361102


AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card

Electric schemes and links

Cod. 16002143100

valid for versions with thermoplastic drain conduct panel assembly

valido per versioni con canalizzazione in termoplastica



se16002143100

Legend

Legend: 16002143100

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card