
INDESIT company



Model type:
KN6E52(W)/EX

Commercial code:
F073600

# General notes

## Technical Documentation guidelines

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4280190b Exploded views




4280190b

Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00064143 | | | | cover square, right | | |
| 002 | C00064145 | | | | square cover seal, right | | |
| 003 | C00197004 | | | | electric plate 2000w/230v d220 | | |
| 004 | C00033379 | | | | hotplate d145n.1000watt 220v | | |
| 005 | C00009306 | | | | element cover - 145mm plate | | |
| 006 | C00017353 | | | | fixing cover - 220mm hotplate | | |
| 007 | C00013398 | | | 1 x C00029158 | element support | | |
| 008 | C00117888 | | | | side panel right pw c60x60 lodz | | |
| 009 | C00098794 | | | | back panel cooker 60x60 lodz | | |
| 010 | C00117889 | | | | side panel left pw c60x60 lodz | | |
| 011 | C00098784 | | 40512... | | back strut rh/lh c60x60 lodz | | |
| 011 | C00308395 | 40513... | | | back strut rh/lh c60x60 lodz | | |
| 012 | C00140021 | | | | back support | | |
| 013 | C00031687 | | | | element cover - 180mm | | |
| 014 | C00030938 | | | | electric plate d=180 220v 2kv | | |
| 016 | C00118922 | | | | rubber buffer | | |
| 017 | C00063863 | | | | hinge left (on lid) | | |
| 018 | C00063862 | | | | right cover hinge | | |
| 019 | C00117707 | | | | polar white cover 60x60 lodz | | |
| 020 | C00064144 | | | | cover square, left | | |
| 021 | C00064146 | | | | square cover seal, left | | |
| 023 | C00117699 | | | | hob top 04 pw c60x60 | | |
| 099 | C00002457 | | | | washer 6,2x11x0,7 | | |
| 099 | C00009296 | | | 1 x C00002506 | nut m6x6x10 | | |
| 099 | C00284592 | | | | gas rail fixing bracket right | | |
| 099 | C00284593 | | | | gas rail fixing bracket left | | |
| 099 | C00640366 | | | | chain anchorage | | |

4280220 Exploded views




4280220 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00098800 | | | | chimney c60x60 lodz | | |
| 002 | C00099212 | | | | reduction chimney c60x60 lodz | | |
| 007 | C00082512 | | | | junction block itw f2000 | | |
| 009 | C00121897 | | | | thermostat, 16a 250v 250øc | | |
| 010 | C00081591 | | | | upper element oven/grill | | |
| 011 | C00098797 | | | | electric oven insulation mat 60x60 | | |
| 012 | C00145113 | | | | cavity c6 multi | | |
| 013 | C00098802 | | | | oven front panel c60x60 lodz | | |
| 014 | C00081579 | | | | oven door seal | | |
| 015 | C00098793 | | | 1 x C00297712 | hinge roller support right 60x60 | | |
| 016 | C00081577 | | | 1 x C00301789 | grill pan black | | |
| 017 | C00097991 | | | 1 x C00296346 | oven grid aus 447x365 | | |
| 018 | C00098803 | | | | condensation trim lower door - | | |
| 019 | C00108932 | | | 1 x C00081584 | oven back panel c60x60 | | |
| 020 | C00039578 | | | | push in spring clip - thermostat | | |
| 021 | C00081585 | | | | taptite screw | | |
| 022 | C00098787 | | | | base plate c60x60 lodz | | |
| 023 | C00016119 | | | 1 x C00055585 | foot | | |
| 024 | C00090921 | | | | protection | | |
| 027 | C00084756 | | | | fixing insert m4 | | |
| 030 | C00138829 | | | | lower heating element box | | |
| 031 | C00081590 | | 11001... | 1 x C00288251<br>1 x C00288252 | oven botton heating element | | |
| 031 | C00288251 | 11002... | | | oven botton heating element | | |
| 032 | C00098792 | | | 1 x C00297711 | hinge roller support left 60x60 | | |
| 037 | C00081580 | | | | oven insulation mat - rear | | |
| 038 | C00076978 | | | | oven lamp 25w 220v | | |
| 039 | C00078426 | | | | lamp assembly 25 w 230 v | | |
| 040 | C00119339 | | | | rear cross beam new s2000 | | |
| 041 | C00081589 | | | | circulating fan motor 220-240v | | |
| 045 | C00116236 | | | 1 x C00297596 | wire runners oven shelf supp. | | |
| 046 | C00271907 | | | | round securing nut - shelf runners | | |

4280320b Exploded views

matr.60718.0001





4280320b

4280320b Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00013413 | | | | energy regulator (hotplate) 6+0 | | |
| 002 | C00278299 | | | | commutator electr. oven | | |
| 003 | C00285402 | | | | dashboard kn6c117(w)/ru | | |
| 004 | C00074135 | | | | neon lens clear | | |
| 005 | C00016035 | | | | control knob disc spring | | |
| 007 | C00285403 | | | | oven inner door + inner door glass | | |
| 008 | C00082473 | | | | handle spacer | | |
| 008 | C00138911 | | | | spacer, 8mm | | |
| 008 | C00284041 | | | | oven door handle pw ind | | |
| 008 | C00285780 | | | | screw tmt fr m5x14 zincato | | |
| 009 | C00284039 | | | | oven door glass +squadr wh | | |
| 011 | C00288928 | | | | white dishwarmer door support | | |
| 012 | C00117513 | | | | dishwarmer door pw 593x138 lodz | | |
| 013 | C00117494 | | | | white pw base 60x60 lodz | | |
| 014 | C00139979 | | | | front drawer support | | |
| 018 | C00098796 | | | | hinge for oven door normal | | |
| 019 | C00276482 | | | | roller holder | | |
| 020 | C00284043 | | | | electrical knob-white ind | | |
| 023 | C00283966 | | | | knob disc - pw piastra el./vtc | | |
| 023 | C00284044 | | | | knob disc - pw thermostat | | |
| 023 | C00284109 | | | | knob disc - pw com.multi5. | | |
| 023 | C00284890 | | | | knob disc -for minute minder pw | | |
| 027 | C00099267 | | | | controls mounting panel c60x60 | | |
| 028 | C00078436 | | | | oven thermostat | | |
| 029 | C00193229 | | | | timer electric 120' italora | | |

## Electric schemes and links

Cod. 16001901600




se16001901600

# Legend

Legend: 16001901600

| | | | |
|---|---|---|---|
| AE | Ignition transformer | PE | Plate electric (Normal and Rapid) |
| AT | Ignition transformer | PEL | Wall socket |
| CF | Oven commutator | PIF | Cooking programmer |
| CP | Plate commutator(Normal end Rapid) | POT | Thermostated potentiometer |
| CT | Plate commutator(Automatic) | PT | Termoprotector |
| DC DR | Double Knob double crown burner control card | PTC | Thermostated sensor |
| EV | Electro-Valve | RCE | Grill heating element ex- ternal |
| FC | End of cooking programmer | RCI | Grill heating element internal |
| FRONT | Daschboard | RE | Energy regulator |
| I/LF | OVEN LIGHT SWITCH | RF | Oven lower heating element |
| I/LF-MG | OVEN LIGHT SWITCH + ROTISSERIE | RG | Grill heating element |
| I/MG | TURNSPIT SWITCH | RG COM | Grill heating element un- ion |
| IL | Knobs' Lighting | RV | Heating element ventilated oven |
| ILG | Lamp switch turnspit | SA | Boiler operating led |
| IT | Thermostated switch | SB | Thermostated burner led |
| L | Line (Feed) | SF | Warning light working |
| LF | Oven light | SO | Probe temperature |
| LI | Oven light | SP | Operating Indicator Light for the Plate |
| M | Suction motor handle | ST | Warning light thermostat |
| MG | Turnspit motor | TH | Thermostat fixed |
| MO | Terminal board | TH2 | Thermostated burner cooling |
| MUFF | Oven | THR | Adjustable thermostat |
| MV | Fan motor | TP | Termoprotector |
| N | Neutral (Feed) | TRAV | Support terminal board |
| PA | Ignition push-button | TRM | Thermostated burner control card |