
INDESIT company



Model type:

TD750S(ICE)IX/HA

Commercial code:

F050283

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4230550 Exploded views



4230550 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00260572				user booklet it-gb-fr-nl-es		
000	C00260573				user booklet pt-de		
001	C00098930				pan stand 2 pin type - shiny black		
003	C00052932				burner cap semi rapide		
004	C00136244				flame splitter medium		
005	C00093670				screw burner support 8mm		
005	C00260592				burner support semiifast		
006	C00063701				seal-hob/worktop		
007	C00260576		10612...		knob burners value alu 6mm		
007	C00287314	10613...			knob burners value alu 8mm		
008	C00016035				control knob disc spring		
009	C00065009				disc		
010	C00260707		10612...	10 x C00093670 5 x C00287314 1 x C00287366	working table glass td751-	n1011j00	
010	C00287366	10613...			working table glass td751-		
011	C00052934				electrode clip		
012	C00118496			1 x C00052951	electrode l=520		
013	C00052986				thermocouple ** not for triple		
013	C00093834				screw nut m6		
014	C00052960				burner fixing screw (stainless		
015	C00063709				washer		
016	C00052938				gas jet 64 lpg - medium burner		
016	C00052941				natural gas jet (96)		
017	C00096132				packing d=153,4		
018	C00052926				burner cup - medium burner		
019	C00297029				terminal board assy + cable 6a		
020	C00111240				gas tap medium/auxiliary copreci		
020	C00111241				gas tap large copreci		
021	C00141902				back pipe semifast rh - tap		
022	C00141898				front pipe semifast rh - tap		
023	C00141899				middle pipe fast tap		
024	C00141900				burner supply pipe aux		
025	C00141901				front left burner supply pipe		
026	C00141908				flask burner cup - medium burner		

4230550 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
027	C00280173				junction clamp richco		
028	C00111238				fixing bracket - tap copreci		
028	C00260792				tap fixing plate		
029	C00064912				screw m4x18 tsp nikelata		
029	C00111239				screw m4x17tsp zinc		
030	C00035727			1 x C00276836	mains supply cable 3x2,5		
031	C00052952				clamp kit - hob/worktop		
032	C00261172				base cover td750		
033	C00141903				gas pipe pz750		
035	C00010506				sealing washer - gas elbow/pipe		
036	C00024370				elbow connection (1/2 male x 2)-		
037	C00052927				burner cup - small burner		
038	C00052939				gas jet 50 lpg - small burner		
038	C00066166				nat gas aux. burner nozzle rapido		
039	C00052925				burner cup - large burner		
040	C00056359				gas jet (80) lpg - large burner		
040	C00056360				gas jet 110 nat gas - large burner		
041	C00052940				gas jet 116 ng large burner		
041	C00053176				gas jet 91 lpg - triple burner/wok		
042	C00261170				burners support 75		
043	C00093670				screw burner support 8mm		
043	C00260589				burner support auxiliary		
044	C00063702				burner base - auxiliary		
045	C00052933				burner cap auxiliary (small) black		
046	C00093670				screw burner support 8mm		
046	C00260591				burner support fast		
047	C00136243				flame splitter - large		
048	C00052931				burner cap rapide (large) black		
057	C00111235				microswitch ring		
057	C00145276				ignition microswitch (5) copreci		


Notices

n1011j00: Introduced new working table glass from 8 mm

At the end of the stocks of working table glass pre-modified it is necessary to order simultaneously new Code of working table glass, new code of knobs and 8 mm burner support screws.
For the correct installation procedure please refer to the Technical Bulletin TB001366 present in the documentation.

Electric schemes and links

Cod. 16001635901



Legend

Legend: 16001635901

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card