
INDESIT company



Model type:

PF604(WH)

Commercial code:

F028616

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4230140 Exploded views



4230140 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00094827				instructions - lid fitting		
000	C00094903				user instruct.book it-gb-fr-ar		
001	C00075781				cover support sx pf6-7 restyling		
002	C00075714				cover left hinge chromed		
003	C00075713				cover right hinge chromed new		
004	C00075780				cover support dx pf6-7 restyling		
005	C00094828			1 x C00256613	glass lid - mirror cf6		
005	C00094829			1 x C00256617	glass lid - black cf6		
005	C00094830			1 x C00118817	glass lid - white cf6	n1015100	03286160000 03286160100
005	C00094831			1 x C00256619	glass lid - brown cf6		
005	C00094832			1 x C00256620	glass lid - av cf6		
005	C00118680				glass cover cov ph7 (pw)		
006	C00053196				rubber buffer - glass lid front		
007	C00074160				electric plate 145r 230v 1500w		
008	C00018723			1 x C00018819	sealing gasket - hob/worktop		
009	C00094906				spillage tray-pf604 white	n1015100	03286160000 03286160100
009	C00118775				spillage tray-smooth pb604 pw		
010	C00074135				neon lens clear		
010	C00082507				pilot light green		
011	C00094896				microswitch knob disc pf604 style		
012	C00094907			1 x C00118754	electric plate knob white p604	n1015100	03286160000 03286160100
012	C00118754				electric plate knob pw style		
013	C00009306				element cover - 145mm plate		
014	C00013398			1 x C00029158	element support		
015	C00094902				electric commutator for plate		
016	C00094899				electric commutator flask clamp		
017	C00074179			1 x C00143807	tap bracket pf6-7a restyling		
018	C00280173				junction clamp richco		
019	C00094900				base cover pf604 style		
020	C00052959				terminal block trifase itw p.i.		
021	C00052952				clamp kit - hob/worktop		
022	C00009307				fixing cover for electric plate		

4230140 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
023	C00031687				element cover - 180mm		
024	C00074114				blanking plug-lid hinge hole pf7a		
025	C00075782				taptite screw m4x10 f.ron.t.e.zntrp		
025	C00092140				bolt m4x12 te.esa.es.		
026	C00094898				electric plate d180 2000w 230v		
027	C00094897				electric plate d110 600w 230v		
099	C00009296			1 x C00002506	nut m6x6x10		
099	C00037385				reinforcement washer for foot		
099	C00082509				taptite screw m4x10		

Notices

n1015100: POLAR WHITE FACTORY 03 (ALBACINA)

From serial no. 50504.0001, the new "Polar white" colour is used on all appliances produced in factory 03 in place of "White 27".

All models affected by this modification have a new industrial code.
To determine the new Polar White codes, it is necessary to know the industrial code or serial number of the appliance being repaired.

The new items, which bear the initials "PW", are not aesthetically interchangeable with premodification items as the whites are different.

Given below is the list of products/industrial codes (equal or higher) affected by the introduction of the new Polar White colour.


03156320500 PH 960MST (WH)
03156430500 PH 640MST (WH)
03156500400 PH 640MS (WH)
03156520300 PH 640M (WH)
03156540400 PH 631MS (WH)
03159860200 C 6H (WH)
03159900200 C 9H (WH)
03224050300 PF 750 AST (WH)
03224160400 PF 760 AS (WH)
03241400400 C7 NEW (WH)
03255070300 FB G (WH)
03259730200 C 6 (WH)
03280510400 TD 640 E (WH)
03280540300 TD 631 E (WH)
03285810201 PF 640 E (WH) (Sabaf)
03285811201 PF 640 E (WH) (Defendi)
03285860201 PF 640 ES (WH) (Sabaf)
03285861201 PF 640 ES (WH) (Defendi)
03285930201 PF 631 E (WH) (Sabaf)
03285931201 PF 631 E (WH) (Defendi)
03286160200 PF 604 (WH)
03286210200 CF 6 (WH)
03287060201 G640W
03287100200 E604W
03287140200 SY36W
03287940301 GF640W
03289260101 PF 640 ET(WH) NG
03289820101 HGK 20.B (WH)

03289850101 HGM 20.B (WH)
03290190100 FB 21 A.2 (WH)
03290200100 FB 51 A.1 (WH)
03290640300 FB 97 C.2/E (WH)
03290660100 FB 56 C.2 (WH)
03290690100 FB 52 AC.1 (WH)
03290710100 FB 26 C.2 (WH)
03290760100 FB 51.2 (WH)
03290810100 FB 26.2 (WH)
03290840100 FB 21.2 (WH)
03290920300 FD 97 C.1/E (WH)
03291320100 HB 50 A.1 (WH)
03291370100 HB 10 A.1 (WH)
03292770100 TV 76 S (WH)
03293150101 PF 640 P (WH)
03296400200 TC 64 S (WH)
03296670300 TC 64 S (WH) IL
03296690100 COV PH7 (WH)
03296730300 TC 63 S (WH)
03296790200 TC 60 (WH)
03296820200 TF 66 S (WH)
03296860300 TF 66 S (WH) IL
03296880200 TF 65 S (WH)
03298020101 S840GW
03298210200 BS43W
03298770100 T 753 S/M (WH)
03307210200 FD 961 P.1/E (WH)
03309230101 FM 21 K.C (WH)
03312680300 FB 86 P.1/E (WH)
03312780300 FD 960 P.2/E (WH)
03316730200 FX 36.1 WH
03316830200 FX 66.1 WH
03316920200 FX 35.2 WH
03321710200 FR 540.2 (WH)
03325450100 TA 66 S (WH)
03325470100 TA 65 S (WH)
03326200200 FA 46.1 WH
03326220100 FA 26.1 WH
03331430100 FZ 97 C.1 (WH)
03336980100 CISFB 51.2 (WH)
03336990100 CISFB 21.2 (WH)
03337020200 CISFBG (WH)
03337070101 CISPH 640 M (WH)
03337090101 CISPH 640 MS (WH)
03338660100 PI 604 (WH) GB
03338760101 PI 640 A (WH)
03338770101 PI 640 A (WH) GB
03338810201 PI 640 AS (WH)
03338950101 FI 20.B (WH)
03338990101 FI 51.B (WH)
03339940100 FZ 97 P.1 (WH)
03339960100 F 97 C.2 (WH)
03339990100 F 76 C.2 (WH)
03340130101 FI 21 K.B (WH) GB
03340170101 FI 31 K.B (WH) GB
03340190101 FIE 36 K.B (WH) GB
03340220101 FIE 56 K.B (WH) GB

03340620100 EC604W
03340660101 GC640W
03342210100 SC36EW
03342250100 SC77EW
03344920100 FCF 05 (WH)
03348320101 PL 640 P (WH)
03348460100 FX 336.1 WH
03353060100 FM 36.1 WH
03353090100 FM 336.1 WH
03353110100 FM 416.1 WH
03353130100 FM_66.1_WH

Electric schemes and links

Cod. 16001598902




Legend

Legend: 16001598902

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card

Electric schemes and links

Cod. 16001636000



Legend

Legend: 16001636000

AE	Ignition transformer	PE	Plate electric (Normal and Rapid)
AT	Ignition transformer	PEL	Wall socket
CF	Oven commutator	PIF	Cooking programmer
CP	Plate commutator(Normal end Rapid)	POT	Thermostated potentiometer
CT	Plate commutator(Automatic)	PT	Termoprotector
DC DR	Double Knob double crown burner control card	PTC	Thermostated sensor
EV	Electro-Valve	RCE	Grill heating element ex- ternal
FC	End of cooking programmer	RCI	Grill heating element internal
FRONT	Daschboard	RE	Energy regulator
I/LF	OVEN LIGHT SWITCH	RF	Oven lower heating element
I/LF-MG	OVEN LIGHT SWITCH + ROTISSERIE	RG	Grill heating element
I/MG	TURNSPIT SWITCH	RG COM	Grill heating element un- ion
IL	Knobs' Lighting	RV	Heating element ventilated oven
ILG	Lamp switch turnspit	SA	Boiler operating led
IT	Thermostated switch	SB	Thermostated burner led
L	Line (Feed)	SF	Warning light working
LF	Oven light	SO	Probe temperature
LI	Oven light	SP	Operating Indicator Light for the Plate
M	Suction motor handle	ST	Warning light thermostat
MG	Turnspit motor	TH	Thermostat fixed
MO	Terminal board	TH2	Thermostated burner cooling
MUFF	Oven	THR	Adjustable thermostat
MV	Fan motor	TP	Termoprotector
N	Neutral (Feed)	TRAV	Support terminal board
PA	Ignition push-button	TRM	Thermostated burner control card