
INDESIT company



Model type:
K6E32(W)/G

Commercial code:
F033171

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:

REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics


INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4280190c Exploded views

matr.40810.0001





4280190c

4280190c

Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00112424 | | | | instruction book gb 04 ind | | |
| 001 | C00112365 | | | 1 x C00117756 | back edge for cooker uk 589x104 | | |
| 002 | C00040071 | | | | electric hotplate 220mm 2kw | | |
| 003 | C00040072 | | | | element 145mm 1500w low | | |
| 004 | C00110424 | | | 1 x C00117699 | working table sand 04 white | | |
| 005 | C00009306 | | | | element cover - 145mm plate | | |
| 006 | C00017353 | | | | fixing cover - 220mm hotplate | | |
| 007 | C00013398 | | | 1 x C00029158 | element support | | |
| 008 | C00084323 | | | 1 x C00117887 | side panel dx white | | |
| 009 | C00098794 | | | | back panel cooker 60x60 lodz | | |
| 011 | C00084324 | | | 1 x C00117886 | side panel left white | | |
| 012 | C00098784 | | | | back strut rh/lh c60x60 lodz | | |
| 013 | C00140021 | | | | back support | | |
| 014 | C00031687 | | | | element cover - 180mm | | |
| 015 | C00032607 | | | | element 180mm 2kw low profile | | |
| 016 | C00064110 | | | | rear spacer | | |
| 017 | C00090210 | | | | box cover hinge | | |
| 099 | C00009296 | | | 1 x C00002506 | nut m6x6x10 | | |


4280210 Exploded views



4280210 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00098800 | | | | chimney c60x60 lodz | | |
| 001 | C00099212 | | | | reduction chimney c60x60 lodz | | |
| 004 | C00118110 | | | | mains terminal block | | |
| 006 | C00121897 | | | | thermostat, 16a 250v 250øc | | |
| 007 | C00082732 | | | | upper element oven/grill | | |
| 008 | C00108931 | | | | electric oven insulation mat | | |
| 009 | C00108930 | | | | cavity 7p c60x60 | | |
| 010 | C00098802 | | | | oven front panel c60x60 lodz | | |
| 011 | C00081579 | | | | oven door seal | | |
| 012 | C00098793 | | | 1 x C00297712 | hinge roller support right 60x60 | | |
| 013 | C00099836 | | | 1 x C00270220 | enamelled grill pan black | | |
| 014 | C00081578 | | | | oven grid | | |
| 014 | C00099837 | | | | dripping-pan grid hotpoint/creda | | |
| 015 | C00098803 | | | | condensation trim lower door - | | |
| 016 | C00108932 | | | 1 x C00081584 | oven back panel c60x60 | | |
| 017 | C00039578 | | | | push in spring clip - thermostat | | |
| 018 | C00081585 | | | | taptite screw | | |
| 019 | C00098787 | | | | base plate c60x60 lodz | | |
| 019 | C00098788 | | | | bracket for base plate c60x60 lodz | | |
| 020 | C00016119 | | | 1 x C00055585 | foot | | |
| 021 | C00139991 | | | | drawer/oven panel | | |
| 027 | C00098792 | | | 1 x C00297711 | hinge roller support left 60x60 | | |
| 028 | C00084399 | | | | heating element fan oven | | |
| 032 | C00108929 | | | 1 x C00093429 | oven insulation mat - rear 60x60 | | |
| 033 | C00076978 | | | | oven lamp 25w 220v | | |
| 034 | C00078426 | | | | lamp assembly 25 w 230 v | | |
| 035 | C00081574 | | | 1 x C00119339 | rear cross beam | | |
| 036 | C00081589 | | | | circulating fan motor 220-240v | | |
| 037 | C00099839 | | | | handle for drip tray hotpoint/creda | | |
| 038 | C00011093 | | | | deflector washer | | |
| 038 | C00011549 | | | | self-tapping screw 8px12,7 tsp- | | |
| 038 | C00112370 | | | | knob heat deflector plate | | |
| 099 | C00040619 | | | | flat washer d 4,3x9 | | |

4280340 Exploded views




4280340

4280340 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00013413 | | | | energy regulator (hotplate) 6+0 | n1015106 | |
| 002 | C00086539 | | | 1 x C00196058 | oven function switch f2000 uk | | |
| 003 | C00112397 | | | 1 x C00117678 | dashboard k6c32(w)/g | | |
| 004 | C00074135 | | | | neon lens clear | | |
| 005 | C00016035 | | | | control knob disc spring | | |
| 006 | C00110469 | | | 1 x C00117528 | timer knob wh ind c60x60 lodz | | |
| 006 | C00110500 | | | 1 x C00117527 | electrical knob-white ind c60 | | |
| 006 | C00112371 | | | 1 x C00117534 | energy regulation knob wh ind c60 | | |
| 007 | C00099195 | | | | oven inner door + inner door | | |
| 008 | C00110465 | | | 1 x C00118153<br>1 x C00143115 | white oven door 60 ind glass + | | |
| 009 | C00110467 | | | 1 x C00117532 | oven door handle white ind l=593 | | |
| 010 | C00098782 | | 20118... | | warming drawer front 60x60 lodz | | |
| 011 | C00112367 | | | 1 x C00117493 | white dishwarmer door support | | |
| 012 | C00110463 | | | 1 x C00117514 | dishwarmer door white 593x138 | | |
| 014 | C00139979 | | | | front drawer support | | |
| 015 | C00139980 | | | | drawer sheet metal c60x60 | | |
| 016 | C00098780 | | | | drawer support left 60x60 | | |
| 017 | C00098779 | | | | drawer support right 60x60 | | |
| 018 | C00098796 | | | | hinge for oven door normal | | |
| 019 | C00033337 | | | | hinge support | | |
| 024 | C00099267 | | | | controls mounting panel c60x60 | | |
| 025 | C00078436 | | | | oven thermostat | | |
| 026 | C00052578 | | | | timer electric 120 d=6mm | | |
| 027 | C00110472 | | | 1 x C00117530 | knob disc wh ind c60x60 lodz | | |
| 028 | C00074157 | | | | pilot light red | | |
| 028 | C00082507 | | | | pilot light green | | |
| 032 | C00019090 | 40930... | | | energy regulation switch - | n1015072 | |
| 032 | C00037056 | | 40929... | | energy regulator grill/hotplates | n1015072 | |
| 099 | C00013973 | | | | screw 8p x 12,75 tpr black | | |

# Notices

## n0512g01: INTRODUCED NEW DRAWER

---

## n0512i02: Changes to Terminal Block

---

## n1015072: REPLACEMENT OF ENERGY REGULATOR ON 60X60 COOKERS UK

---


From serial no. 40930.0001, the energy regulator has been replaced on all 60x60 cookers produced in the Lotz factory for the UK market. The regulator code 019090 (240V) has been introduced in place of code 037056 (230V). The new component is not interchangeable with the premodification item, which will continue to be stocked by the Spare Parts Warehouse as it is used on other products.

## n1015106: PLATES CHANGEOVER SWITCH C00013413


---

The plates changeover switch used for cookers produced in the Lodz plant can be supplied by three different manufacturers: Deka, Ego and Dreefs.
The three changeover switches, even though different in appearance, are interchangeable.
Part code C00013413 used for service operations is the EGO changeover switch.
Pictures of the three changeover switches and the relative electrical connection diagram of are given below.


# DEKA


49
P2
P1
P3
4
3
1
2
5
57,5
83,5
23±0,5
ROTATION
8
M4
28±0,2
0 position

# DREEFS


4
3
1
2
5
P2
P1
P3
70.5
23
49
29.5
16.5
M 4
28
0 position
ROTATION


EGO




| position | P3 | | P1 | | P2 | | |
|---|---|---|---|---|---|---|---|
| 0 | | | | | | | |
| 1 | X | X | X | | X | X | |
| 2 | X | X | | | X | X | |
| 3 | X | X | | | X | | |
| 4 | X | X | | | | X | |
| 5 | X | | | X | | X | |
| 6 | X | | X | | X | | |

## Electric schemes and links

Cod. 16001864000




se16001864000

# Legend

Legend: 16001864000

| | | | |
|---|---|---|---|
| AE | Ignition transformer | PE | Plate electric (Normal and Rapid) |
| AT | Ignition transformer | PEL | Wall socket |
| CF | Oven commutator | PIF | Cooking programmer |
| CP | Plate commutator(Normal end Rapid) | POT | Thermostated potentiometer |
| CT | Plate commutator(Automatic) | PT | Termoprotector |
| DC DR | Double Knob double crown burner control card | PTC | Thermostated sensor |
| EV | Electro-Valve | RCE | Grill heating element ex- ternal |
| FC | End of cooking programmer | RCI | Grill heating element internal |
| FRONT | Daschboard | RE | Energy regulator |
| I/LF | OVEN LIGHT SWITCH | RF | Oven lower heating element |
| I/LF-MG | OVEN LIGHT SWITCH + ROTISSERIE | RG | Grill heating element |
| I/MG | TURNSPIT SWITCH | RG COM | Grill heating element un- ion |
| IL | Knobs' Lighting | RV | Heating element ventilated oven |
| ILG | Lamp switch turnspit | SA | Boiler operating led |
| IT | Thermostated switch | SB | Thermostated burner led |
| L | Line (Feed) | SF | Warning light working |
| LF | Oven light | SO | Probe temperature |
| LI | Oven light | SP | Operating Indicator Light for the Plate |
| M | Suction motor handle | ST | Warning light thermostat |
| MG | Turnspit motor | TH | Thermostat fixed |
| MO | Terminal board | TH2 | Thermostated burner cooling |
| MUFF | Oven | THR | Adjustable thermostat |
| MV | Fan motor | TP | Termoprotector |
| N | Neutral (Feed) | TRAV | Support terminal board |
| PA | Ignition push-button | TRM | Thermostated burner control card |