
INDESIT company



Model type:

PK750TLGHHA

Commercial code:

F076631

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4450120A Exploded views



4450120A Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00289888				pan grid (rh)black 2f gh		
002	C00289893				rubber buffer for pan support gh		
003	C00064919				burner cap - semirapide black		
004	C00052929				burner ring - medium		
005	C00290005				knob gas dual(bk-ix)pi ha2011		
006	C00130607				sealing collar - knobs		
007	C00018819				seal - hob/worktop		
008	C00052941				natural gas jet (96)		
009	C00052926				burner cup - medium burner		
010	C00052934				electrode clip		
011	C00288668				spark ignition transformer 5f		
013	C00289714				gas pipe 5 pi2011 750 advanced		
014	C00289850				base cover 760rf/f-750r/t/mw h/a		
015	C00052952				clamp kit - hob/worktop		
016	C00290274				ignition microswitch (5)itw-		
017	C00289713				gas tap - triple burnerv.90°din r		
017	C00289756				gas tap - din aux-sr 28 copreci		
017	C00289881				gas tap - triple burner 61 copreci		
018	C00289759				gas pipe - aluminium tube		
018	C00289761				gas pipe - aluminium tube		
018	C00289762				gas pipe - aluminium tube		
018	C00289853				gas pipe - aluminium tube pk750t		
019	C00010506				sealing washer - gas elbow/pipe		
020	C00024370				elbow connection (1/2 male x 2)-		
021	C00052927				burner cup - small burner		
022	C00289833				burner cup - triple burner		
024	C00066166				nat gas aux. burner nozzle rapido		
025	C00289990				natural gas jet eco-tc d=103		
026	C00052925				burner cup - large burner		
027	C00118496			1 x C00052951	electrode l=520		
028	C00289758				thermocouple - aux/med.l600		
029	C00290826				natural gas jet rr d=122h sabaf		
030	C00290827				working table + glass ser. pk750tl		
031	C00289816				support pan grid p.i.h/a-11 adv bk		
032	C00289815				support pan grid (lh)p.i.h/a-11		

4450120A Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
033	C00289812			1 x C00289816	support pan grid p.i.h/a-11 adv bk		
034	C00289813				support pan grid (rh) p.i.h/a-11		
035	C00052930				burner base/flame splitter - small		
036	C00064918				burner cap auxiliary black semi		
037	C00052928				burner ring/flame splitter - large		
038	C00064920				burner cap rapide black		
039	C00289885				pan grid (lh) black sx 2f gh		
040	C00289884				pan grid (centre)gh black 1f		
041	C00289846				burner base/flame split. - triple		
042	C00289895				burner cap outer tc.defendi		
043	C00289848				electrode tc (3.3kw) l=450		
044	C00289849			1 x C00305938	thermocouple tc bai. l=450		
045	C00111235				microswitch ring		
046	C00297837				terminal block 5 f.+cavo 6a		
047	C00290275				ignition microswitch (5)led itw-		
051	C00291345				kit glass cover c7k(bk)		
052	C00291360				support glass cover lh		
053	C00081133				cover left hinge		
054	C00075713				cover right hinge chromed new		
055	C00291359				support glass cover rh		
056	C00053196				rubber buffer - glass lid front		
099	C00280173				junction clamp richco		
099	C00280352				jets kit for lpg sh07sgwax		
099	C00290277				wiring terminal		