
INDESIT company



Model type:
D310MSTIX/HA

Commercial code:
F050119

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

41711g0 Exploded views



41711g0 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00081685 | | | | user instruction book-i-de-es-fr-nl- | | |
| 001 | C00076405 | | | | rubber buffer - pan grid | | |
| 002 | C00081712 | | | | burner grid (1 burner) - black | | |
| 003 | C00053175 | | | | burner cap (centre disc)triple black | | |
| 004 | C00053174 | | | | outer burner cap black work triple | | |
| 005 | C00053173 | | | | burner base/flame splitter - triple | | |
| 006 | C00008505 | | | | retention plate 12x8x2 | | |
| 006 | C00053219 | | | | knob (gas tap/switch) - black | | |
| 007 | C00039156 | | | | knob disc - spring | | |
| 008 | C00053220 | | | | knob disc black | | |
| 009 | C00081741 | | | | compression ring | | |
| 010 | C00081731 | | | | microswitch 1f. | | |
| 011 | C00057210 | | | | gas pipe elbow 1/2" gas | | |
| 012 | C00057243 | | | | sealing washer-gas elbow/pipe | | |
| 013 | C00053254 | | | | burner cup - triple burner | | |
| 014 | C00081759 | | | | connection pipe | | |
| 015 | C00045232 | | | | surround - ignition button | | |
| 016 | C00081740 | | | | spacer | | |
| 017 | C00081742 | | | | pipe - tap | | |
| 018 | C00081743 | | | | burner tap by-pass 60/100 | | |
| 019 | C00081766 | | | | barrier | | |
| 020 | C00081715 | | | | spark ignition transformer | | |
| 021 | C00081739 | | | | insulator | | |
| 022 | C00081732 | | | | bracket - supply gas pipe | | |
| 023 | C00045235 | | | | spring nut | | |
| 024 | C00057251 | | | | plate clamp hobs | | |
| 025 | C00081718 | | | | base cover tray | | |
| 026 | C00045245 | | | | cable clamp - mains cable (black) | | |
| 027 | C00076427 | | | | terminal board cover | | |
| 028 | C00045248 | | | | terminal block (2 pole) | | |
| 029 | C00076428 | | | | fixing base terminal board electro | | |
| 030 | C00076429 | | | | terminal board support | | |
| 031 | C00045282 | | | | gasket for nozzle with valve | | |
| 032 | C00052934 | | | | electrode clip | | |
| 033 | C00053244 | | | | ignition spark plug - triple burner | | |

41711g0 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 034 | C00061955 | | | 1 x C00094330 | thermocouple - triple burner | | |
| 035 | C00081726 | | | 1 x C00002373 | taptite screw | | |
| 036 | C00081724 | | | 1 x C00026766 | support bracket - glass cover | | |
| 037 | C00081713 | | | 1 x C00032682 | blanking plug - lid hinge hole | | |
| 038 | C00081738 | | | | impellor thermocouple | | |
| 039 | C00259625 | | | | spillage tray - stainless steel ha | | |
| 040 | C00081129 | | | | glass lid (not uk) cd 3(mr)t | | |
| 041 | C00081133 | | | | cover left hinge | | |
| 042 | C00081132 | | | | cover right hinge | | |
| 043 | C00081131 | | | | cover left support tc | | |
| 044 | C00081130 | | | | cover right support tc | | |
| 045 | C00081298 | | | | taptite screw m4x12 f.ron.t.e.zntrp | | |
| 046 | C00053196 | | | | rubber buffer - glass lid front | | |
| 099 | C00045250 | | | | clamping plate - hob/worktop | | |