
INDESIT company



Model type:
HCD662EU

Commercial code:
F084417

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

MIDW01 Exploded views



MIDW01 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
001	C00286538				float		
002	C00300655				flowmeter		
003	C00300656				inlet hose		
004	C00300657				inlet valve		
005	C00286355				inlet valve block		
006	C00300659				pressure switch		
007	C00300662				pipe pressostat		
008	C00300660				water softener		
009	C00300663				seal o-ring 10.5×4.5		
010	C00300664				inlet hose of air breather		
011	C00286327				seal - softener/wash chamber		
014	C00300666				float		
015	C00286360				retaining ring - water inlet		
016	C00286366				water inlet seal		
017	C00286330				air break + turbine		
018	C00300668				backboard		
019	C00286332				support rear cross beam		
020	C00304650				tank assembley		
021	C00300701				soundproofing top		
022	C00286334				corner fix		
023	C00286370				shell left+right+top		
024	C00300667				door clamp		
025	C00286374				frame support for tub seal		
026	C00286333				door lock		
027	C00286394				retaining ring - siphon		
028	C00286612				inlet/safety valve		
029	C00286335				seal o-ring 21×3		
030	C00300669				siphon		
031	C00304651				cutlery basket		
032	C00304652				basket		
033	C00286338				detergent/rinse aid dispenser		
034	C00300670				inner door panel stainless		
035	C00300671				door handle assembly		
036	C00286340				dispenser bracket		
037	C00300672				control board assembly		

MIDW01 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
038	C00304639				outer door hcd 662 eu		
039	C00304653				display cover		
040	C00304654				botton		
041	C00300678				knob assembly		
042	C00300679				light cover		
043	C00300680				light cover		
044	C00300681				door knob cover		
045	C00304655				on/off button		
046	C00300683				door spring		
047	C00286396				hinge wire		
053	C00300684				right front bearing plate		
054	C00300685				hinge connection plate		
056	C00300686				right front bearing plate		
058	C00286572				plinth panel		
059	C00286577				main board cover		
060	C00300687				base		
061	C00286580				main board cover		
062	C00300688				drain pump		
065	C00304657				support bracket - heating element		
066	C00304656				st.steel filter		
069	C00286349				outlet filter stainless		
071	C00286381				siphon + internal pipe		
072	C00300691				internal pipe		
073	C00300692				door seal - top and sides		
074	C00304658				spray arm		
075	C00300694				support - wash arm bush		
076	C00286595				sump fixing ferrule		
077	C00300695				sump fixing ferrule		
078	C00286606				heating element seal		
079	C00304659				heating elements assembly		
080	C00300697				heating cover		
081	C00286592				sump		
082	C00286611				motor seal		
083	C00286393				motor washing		
084	C00286614				protecting motor		

MIDW01 Spare parts list


Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
085	C00286385				outlet tube of softener		
087	C00286646				drain hose fastener		
088	C00300698				temperature sensor (ntc)		
089	C00286390				rubber stopple		
090	C00300699				salt filler		
091	C00286570				measure - spoon		
092	C00286567				hook for drain hose		
093	C00286566				supply cable		
094	C00286383				wiring		
095	C00286389				inlet hose		

Electric schemes and links

Cod. HCD662

CODE	Designation
ACL	Live(Alternating Current)
ACN	Neutra(Alternating Current)
E	Earth
D/Ed	Dispenser
EV1	Inlet Valve
EV2	Softener Valve
EV3	Halfload Valve
IAQS	Overflow Switch
CB	Control Board
FM	Flow Meter
P2	Dry Heating Protect Switch
P0	Water Level Switch(83/63)
P1	Water Level Switch(140/120)
LSB	Rinse Aid Indicator
ISB	Rinse Aid Detector
EV4	Water Diverter
S2	Protection Overheating(PS)
S1	Protection Overheating(ML)
C	Capacitor
FUSE	Fuse(3.15A)
TS□	□℃ Thermostat
FAN	Fan
IG	Power Switch
PS	Drain Pump
TM	Timer Motor
ML	Wash Pump
LSS	Salt Indication
ISS	Salt Detector
LS	Power Indication
F	Fliter
ITR2	Temperature Fuse
ITR1	Safety Thermostat
R	Heater
DOOR	Door Switch
IS	Door Switch
RE	Temperature sensor(NTC)

CODE	Designation
BU	Blue
YE	Yellow
GN	Green
WH	White
RD	Red
BK	Black
PK	Pink
GY	Gray
OR	Orange
BR	Brown
VT	Violet
PU	Purple
CL	Clear
YE+GN	Yellow+Green bicolor
□+△	□+△ bicolor



Legend

Legend: HCD662