
INDESIT company



Model type:
DK302IX/HA

Commercial code:
F050114

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

41711b0 Exploded views



41711b0 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00173552				installation&user guide in turkish		
001	C00045345				indicator light - red		
002	C00059521			1 x C00276851	pilot lamp lens red		
003	C00081816				indicator light		
004	C00081749			1 x C00276846	pilot lamp lens		
006	C00045313				indicator light (l350-150)		
007	C00008505				retention plate 12x8x2		
007	C00053219				knob (gas tap/switch) - black		
008	C00039156				knob disc - spring		
009	C00053220				knob disc black		
010	C00028917				insert fix under knob disc to		
011	C00045315				radiant plate ring 145mm		
012	C00045326				hotplate power regulator		
013	C00081814				fixing bracket - electric ring		
014	C00045235				spring nut		
015	C00081752				plate clamp hobs		
016	C00045322				cover - terminal block		
017	C00045323				cable clamp		
018	C00045324				terminal block		
019	C00045325				insulation plate - terminal block		
020	C00045311				element for glass ceramic hob		
021	C00045318				retainer - radiant ring		
022	C00045316				radiant plate ring 180mm		
023	C00259618				spillage tray - stainless steel ha		
099	C00045328				fixing bracket & seal-		