
INDESIT company



Model type:

KBH6000 BI

Commercial code:

F029832

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics


INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

4522820 Exploded views







4522820 Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00096944				user booklet it-gb-fr-de-nl-es-pt		
001	C00097180				top bi		
002	C00108843			1 x C00275415	seal - hob/worktop pvc sr 5x5		
003	C00139053				heater 1700w/230v		
004	C00139052				heater 1200w/230v		
005	C00096945				basin bottom		
006	C00096948				residual leds wiring harness		
007	C00096946				residual heat indicator support		
008	C00140179				insulator		
009	C00096947			1 x C00140538	fixing spring		
010	C00130562				cable clamp		
011	C00064755				drain hose collar		
012	C00136364				fixing spring		
099	C00096949				heaters wiring harness		
099	C00108816			1 x C00142145	hob fixing squares (kit)		

Electric schemes and links

Cod. 160017032





Legend

Legend: 160017032