
INDESIT company



Model type:
ARTXL109EU

Commercial code:
F060609

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes


1260110 Exploded views



1260110 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00041575 | | | | adhesive hook | | |
| 002 | C00083909 | | | | blanking plate-rear(test plug) tl | | |
| 003 | C00065320 | | | | anchorage pad - suspension | | |
| 004 | C00112632 | | 00930... | 1 x C00281816<br>1 x C00281831 | back panel tl evoii | | |
| 004 | C00281816 | 01001... | | | back panel tl new | | |
| 005 | C00083901 | | | | wire protection | | |
| 006 | C00117340 | | | 1 x C00117342 | side panel right tl white(pw) | | |
| 007 | C00303587 | | | | kit shock absorber 120n top | | |
| 008 | C00280757 | | | | plastic expansion peg new | | |
| 010 | C00091071 | | | | rear wheel | | |
| 013 | C00264322 | | | | foot h32.5 mm | | |
| 014 | C00083793 | | | | cam lever+truck | | |
| 015 | C00083786 | | | | nut ro-mob m6 d.28 1.5 top | | |
| 016 | C00083780 | | | | block side panel cabinet | | |
| 017 | C00116852 | | | | white(pw) base tl evoii | | |
| 018 | C00065071 | | | | side panel trim (90701) | | |
| 019 | C00117345 | | | | front panel tl white(pw) | | |
| 020 | C00117341 | | | 1 x C00117342 | side panel left tl white(pw) | | |
| 021 | C00115246 | | | | front unsound matress tl evoii | | |
| 099 | C00064550 | | | | drain hose holder | | |


1260260 Exploded views



1260260 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00111494 | | | | door interlock tl evoii | | |
| 002 | C00084359 | | | | cover siphon tl ph2001 | | |
| 005 | C00083918 | | | | blocking stem dispenser | | |
| 006 | C00083922 | | | | spring dispensertl ph2001 | | |
| 007 | C00116868 | | | | push-button dispenser white(pw) tl | | |
| 008 | C00116869 | | | | dispenser white(pw) tl ph2001 | | |
| 009 | C00270184 | | | | handle cover pw tl ha n.e.2008 | | |
| 010 | C00270180 | | | | white(pw) cover ha tl new est | | |
| 011 | C00087073 | | | | spring support | | |
| 012 | C00270192 | | | | knob pw tl ha new est.2008 | | |
| 013 | C00270191 | | | | knob pw tl ha new est.2008 | | |
| 014 | C00270191 | | | | knob pw tl ha new est.2008 | | |
| 015 | C00270248 | | | | console white(pw) artxl109eu | | |
| 016 | C00255147 | | | | light guide status | | |
| 017 | C00255691 | | | | start lens | | |
| 017 | C00259417 | | | | pushbutton white pw start/pause | | |
| 018 | C00255148 | | | | light guide option | | |
| 019 | C00255480 | | | | option buttons (led) (4) | | |
| 020 | C00259420 | | | | pushbutton white pw on/off | | |
| 021 | C00259287 | | | | pcb support led | | |
| 022 | C00270188 | | | 1 x C00277182 | display led 3 knobs tl new ha | | |
| 023 | C00031331 | | | 1 x C00033210 | clamp | | |
| 025 | C00143125 | | | | white(pw) lower cover tl evoii | | |
| 026 | C00057933 | | | | bellows clamp (tank front) | | |
| 027 | C00111495 | | | | diaphragm tl evoii | | |
| 028 | C00116866 | | | | white(pw) protection diaphragm tl | | |
| 029 | C00111496 | | | | rubber buffer tl evoii | | |


1260310 Exploded views



1260310 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00083894 | | | | lifter with weight | | |
| 002 | C00068143 | | | | binding d=37 | | |
| 002 | C00112602 | | 00930... | | steam exhaust hose tl evoii | | |
| 002 | C00281835 | 01001... | | | steam exhaust hose tl rec.st.by | | |
| 004 | C00083798 | | | | suspension spring - tank tl ph2001 | | |
| 004 | C00085463 | | | | front suspension spring - tank tl | | |
| 009 | C00083794 | | | | counterweight dx tl ph2001 | | |
| 010 | C00041605 | | | | conic washer | | |
| 011 | C00083797 | | | | screw sw. 8x27 tc-t30 | | |
| 012 | C00092020 | 90903... | | | belt tl1200 1214j5/1226j5 | | |
| 012 | C00112741 | | 90902... | 1 x C00092020 | belt 1226j6 tl evoii | | |
| 013 | C00143260 | | | | drum pulley bolt m8x23 torx tefl | | |
| 014 | C00142832 | | | | drum pulley d280 24,2 tl ph2001 | | |
| 015 | C00111502 | | | | hose tank to filter oko tl evoii | | |
| 016 | C00008612 | | | | tube clamp 34,6-36,4 | | |
| 017 | C00111505 | | 00930... | 1 x C00281816<br>1 x C00281835<br>1 x C00282093 | plastic tank 600/1000 tl evoii## | n4009a02 | |
| 017 | C00282093 | 01001... | | | plastic tank 600/1000 tl ## | | |
| 018 | C00083896 | | | 1 x C00195213 | counterweight sx tl ph2001 | | |
| 019 | C00055303 | | | | insulation panel | | |
| 021 | C00041605 | | | | conic washer | | |
| 022 | C00083797 | | | | screw sw. 8x27 tc-t30 | | |
| 023 | C00087966 | | | | support | | |
| 024 | C00080691 | | | | kit boltz and nutz tl | n1040245 | |
| 024 | C00112743 | | | 1 x C00252375 | load orifice soft 'tl evoii' | n1040245 | |
| 025 | C00114990 | | | | blue push-button tlevoii | n1040345 | |
| 026 | C00114989 | | | | button spring tl evoii | n1040345 | |
| 099 | C00091902 | | | | kit package tl ph2002 | | |

1260410A Exploded views



1260410A Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 002 | C00111493 | | | | pressure switch 1+1 liv. tl evoii | | |
| 003 | C00092412 | | | | hose clamp | | |
| 004 | C00083897 | | | | pipe pressostat tl ph2001 | | |
| 005 | C00092173 | | | | air trap x oko | | |
| 006 | C00019902 | | | | plastic -u- to make drain hose | | |
| 007 | C00051563 | | | | drain hose - to sink | | |
| 008 | C00141862 | | | 1 x C00281986 | self cleaning pump tl evoii | | |
| | | | | 1 x C00302918 | | | |
| 010 | C00084333 | | 80817... | 1 x C00268497 | screw m8x35 tc-t30 | | |
| 010 | C00268497 | 80818... | | | screw m8x35 tc-t30 | | |
| 011 | C00265832 | | | | motor three phase p32 tl evoii | | |
| 012 | C00266015 | | 80817... | | fixing nut motor three phase tl | | |
| 014 | C00083915 | | | | thermistor ntc | | |
| 015 | C00110148 | | | | heater 1700w-230v tl | | |
| 016 | C00003070 | | | | mains inlet hose cold 25c 10bar | | |
| 016 | C00005572 | | | | sealing washer-mains inlet hose | | |
| 017 | C00254298 | | | | module(3 phase /3.5 software/inc | | |
| 019 | C00270247 | | | | card artxl109eu evoii 8kb sw | | |
| 020 | C00115769 | | | | supply cable 3 x 1.0 1,5mt shuko | | |
| 021 | C00281831 | 01001... | | | grate steam exhaust hose tl/s-by | | |
| 022 | C00116159 | | | | electrovalve 1e2u p.2.5 | | |
| 022 | C00116161 | | | | protection electrovalve tl | | |
| 023 | C00013562 | | | | tube clamp 15,1-15,9 | | |
| 024 | C00083941 | | | | distribution assembly tl | | |
| 025 | C00097841 | | | | hose fill valve l=145 | | |
| 026 | C00119946 | | | | wiring filter-pressure switch- | | |
| 026 | C00195340 | | | | wiring ml + ps (tl) 24000101511 | | |
| 026 | C00261791 | | | | wiring comunic. display -j11 | | |
| 026 | C00264172 | | | | wiring door switch d2 j4 | | |
| 026 | C00270325 | | | | wiring evl + evp+ntc (module j8) | | |
| 026 | C00270330 | | | | wiring earth | | |

# Notices

## n4009a02: Motor fixing changed on Top Loading washing machines

---

Top Loading washing machines have changed the fix of motor to the tub.
The tub design is changed in the motor fixing side and two new screws code C00268497 are introduced instead of the old screws C00084333 and the old nut:

C00266015 nut of products with Triphase motor;

C00258673 nut of products with Collector motor.

Spare parts warehouse will go on to manage only the new tubs with the same spare part codes:

C00111505 - Tub 600/1000 rpm

C00111573 - Tub 1200 rpm

C00252343 - Tub 1400 rpm

In assistance on premodification products with the new tubs, you have to fix the motor using the new screws C00268497 instead of the screws and nut that you find in the product.

Dete of modify in production:


s/n 80818.0001 - all models 1400 rpm Collector and Triphase motor

s/n 80818.0001 - all models 600 – 800 – 1000 – 1200 rpm Triphase motor

s/n 90113.0001 - all models 600 – 800 – 1000 – 1200 rpm Collector motor

## Electric schemes and links

Cod. 16000000000



# Legend

Legend: 16000000000

| | | | |
|---|---|---|---|
| AQS | Aquastop electrovalve | Mzbn/MTA | zbn timer motor |
| B | Buzzer | N | Neutral or Terminal Board |
| BC | Blocco Cesto | NC | Spin cycle exclusion |
| BF | Terminal board contact, motor fan and dryer | P | Pressure switch |
| BP | Buzzer | P1 | 1st level pressure cut-off switch |
| C | Condensator | P2 | 2nd level pressure cut-off switch |
| CA | Condensator | PA | High speed potentiometer |
| DV | Switching device | PB | Low speed potentiometer |
| EF/CL | Electro-Valve Cold Water / Bleach | PL | Pure Wool |
| EF/L | Electro-Valve Cold Water / Wash | PM | Motor Thermoprotector |
| EF/P | Electro-Valve Cold Water / Prewash | PR | Timer programmer or Pressure switch |
| ER | Exclude Heating Element | PS | Drain pump |
| ET | Thermostat disactivation | R | Heating element |
| EV | Electrovalve | RE | Relay |
| EVA | Dryer electrovalve | RR | Heating element |
| EVC | Hot water electrovalve | RV | Speed regulator |
| EVF | Elettrovalvola acqua fredda | Ras/RA | Dryer heating element |
| EVL | Wash electrovalve | S | LED |
| EVP | Pre Wash electrovalve | SL | Line LED |
| FA | Antijamming filter | SO | Door LED |
| FD | Delicate drying cycle thermostat | SR | Heating LED |
| FE | Strong drying cycle thermostat | ST | Temperature selector |
| FRT | Thermofusible Heating Element | SV | Speed Selector for Spin |
| I | Inverter | T | Timer contacts |
| I1..2..3.. | Switches/switching devices | TA | Drying timer contacts |
| IA | Switch On/Off | TB | Low Temperature Thermostat |
| IC | Switch N.C. - 1/2 Load | TC | Spider wheel earth |
| ID | Switch display | TFL | Flange earth |
| IE | Water Saving Device | TG | Main earth |
| IF | Switch - Spin Reduction | TH | Thermostat |
| IP | Door switch | TH1 | 1st temperature thermostat |
| IR | Line switch | TH2 | 2nd temperature thermostat |
| IS | Water-stop | TH3 | 3rd temperature thermostat |

| | | | |
|---|---|---|---|
| L | Line or Lamp | THF | Operating thermostat |
| LB | Low Level | THR | Adjustable thermostat |
| LN | Normal Level | TM | Motor earth |
| LS | Pilot lamp | TMB | Main cabinet earth |
| M | Earth-symbol | TMP | Motor thermal protector |
| MC | Spin cycle motor | TMS | Thermostop |
| MI | MOTOR WITH PULLEY | TP | Thermal protector |
| ML | Wash cycle motor | TPS | Drain pump earth |
| MO | Terminal Board | TR | Heating element earth |
| MP | Door dip-switch | TS | Safety thermostat |
| MR | Thermal Lock | TT | Timer earthing connection |
| MT | Timer motor | TTH | Earthing Thermostat |
| MV | Motor fan | TV | Tank earth |
| MV -Ras | Dryer heating element | ZBN | Timer |