Rice Cooker

HD4750/00

Service
Service
Service



Philips Domestic Appliances and Personal Care

ServiceManual

PRODUCT INFORMATION

Functions:

- Keep warm time, Ready signal, Preset ready time, Reheating, Small portion cooking, Quick cook, Backup memory.

Safety

- Product meets the requirements regarding interference suppression on radio and television.
- After the product has been repaired, it should function properly and has to meet the safety requirements as laid down officially established at this moment.

TECHNICAL INFORMATION

- Voltage	: 220 - 240 V
- Frequency	: 50 - 60 Hz
- Power consumption	: 700 W (3-dimension heating: base, side & top)
- Colour setting	: Sparkling white
- Contents of water	: 1000 cc
- SAP coding	: HD4750/00

Published by Philips Domestic Appliances and Personal Care Printed in the Netherlands © Copyright reserved Subject to modification

07/08

PHILIPS

DISASSEMBLY- AND RE-ASSEMBLY ADVISE


- No specific issues.

REPAIR INSTRUCTION

- No specific issues.

OPTIONAL (accessories)

- Steam tray, rice scoop + holder, soup scoop + holder, measuring cup.
  (See exploded view for more information.)



PARTS LIST

Pos	Service code	Description	Remark
1	9965 000 28341	Measuring cup	
2	9965 000 33907	Steam Tray (1000 cc)	
3	9965 000 34948	Inner pot 1000 cc	**Traditional Chinese / English water level**
	4222 459 45006	**Inner pot 1000 cc**	**Simplified Chinese / English water level**
4	9965 000 33926	Heating plate 230 V / 700 W	
5	9965 000 33911	Bottom Sensor (incl. fuse & sensor)	
6	9965 000 33927	Keystroke + PCB LCD display 230 V	**Traditional Chinese**
	4222 459 45005	**Keystroke + PCB LCD display 230 V**	**Simplified Chinese**
7	9965 000 33928	Power PCB 230 V	
8	9965 000 33904	Spatula	
9	9965 000 33905	Rice scoop	
10	9965 000 33929	Steam valve upper assy	
11	9965 000 33930	Steam seal	
12	9965 000 33931	Steam base	
13	9965 000 33932	Rubber seal valve lid	
14	9965 000 33933	Upper lid ring seal	
15	9965 000 33912	Pot hook/holder	White
16	9965 000 33934	Lower lid assy	
17	9965 000 33935	Fuse 142 °C	
18	9965 000 33906	Appliance cord inlet	
19	9965 000 28343	Cord	Euro
20	9965 000 28344	Cord	S'pore / Hong Kong
	4222 459 45235	**Battery for PCB**	**Suitable for all version**

= changed

HD4750/00

