
INDESIT company



Model type:
A44CEX

Commercial code:
F026485

General notes

Technical Documentation guidelines

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:

REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics


INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

1190190m

Exploded views



1190190m Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
000	C00074626				kit connection lb-dryers		
000	C00087044				user istructions		
001	C00086524				cover		
002	C00085323				side panel		
002	C00085371				back panel		
004	C00085325				top rear crosspiece		
005	C00081321				top bracket		
006	C00085372				bottom back panel		
007	C00085327				interspace		
008	C00085373				sink		
009	C00085374				hose sink		
011	C00086525				drum		
012	C00770145				extractable beater (ex 810145)		
013	C00770146				trommelrib+sensor (was 810146)		
014	C00770150				sensorstrip trommel (was 810150)		
015	C00770148				afdichtingskapje (was 810148)		
016	C00090733				belt installing tool 'iar' ##	n1040228	
016	C00770336				belt l = 1932 mm h 9		
017	C00770285				felp tape (ex810285)		
018	C00085376				engine compartment door		
019	C00087248				nut		
019	C00770055				drum support (ex 810055)		
020	C00770101				bearing 22x7x8 608-2z (ex		
021	C00770103				bearing locking disc (ex 810103)		
022	C00770322				steun rechts		
023	C00770323				steun links		
024	C00063885				bracket thermostat		
025	C00770219				thermostaat 1 t 90ø c nc (was		
028	C00085332				radio interference suppressor		
029	C00085333				heating element220v 2400w/230v		
030	C00063677				spring		
031	C00063893				thermostat 120øc		
032	C00085334				crossing of cable		
033	C00085335				supply cable		
034	C00063676				thermostat 135øc		

1190190m Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
035	C00086526				front panel		
036	C00086527			1 x C00089557	plate		
037	C00085378				bottom crosspiece		
038	C00085379				pin for plinth		
039	C00085380				pin for plinth		
040	C00087042				square		
041	C00085382				kick plate		
042	C00085383				tampa do vao de condensacao		
043	C00085384				guarnicao tampa vao condensacao		
044	C00085385				strike plate		
045	C00085386				spring		
046	C00085387				spring		
047	C00086528				hinge plate outer case		
049	C00086529			1 x C00092880	microswitch		
050	C00086530			1 x C00089749	lid assembly white		
051	C00086531				conveyor		
052	C00770222				bearing support		
054	C00086532				seal		
055	C00086533				front filter		
056	C00770218				thermostaatplaatje (was 810218)		
057	C00086534				safety thermostat gasket		
058	C00086535				lamp-socket		
058	C00094292				bulb light protection iar		
059	C00086536				bracket		
060	C00086537				door interlock		
061	C00086538			1 x C00092882	filter		
062	C00086540				door gasket		
063	C00086541				probe support 'iar'		
064	C00085388				sink upper		
065	C00085389				lower sink		
066	C00770252				pakking condensorhuis (was		
067	C00085390				pakking condensorhuis		
068	C00085391				pakking condensorhuis short		
069	C00770325				houder condensor		
070	C00770349				condensor		

1190190m Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
071	C00085392				side front panel		
072	C00085393				side front panel		
073	C00770347				rubber condensor		
074	C00770348				pakking condensor		
075	C00770346				greep condensor		
076	C00770326				ventilatorkap		
077	C00086542				ventilatorkap		
078	C00063891				motor		
080	C00077219				blower fan		
081	C00770048				rubber shock absorber (ex 810048)		
082	C00770242				spacer motor support (ex 810242)		
083	C00063889				seal blower fan		
084	C00085395				drain pump		
085	C00085396				drain pump hose		
086	C00085397				pump cover		
087	C00770330				slang condensor		
088	C00085398				dryer loading		
089	C00770251				plug condensorhuis (was 810251)		
091	C00085399				rod float		
092	C00085400				float		
093	C00085401				micro support		
094	C00770034				voetje (was 810034)		
095	C00085402				bodemplaat		
096	C00086543				dashboard		
097	C00087043				drawer handle		
098	C00085412				condensate collector drawer		
099	C00086546				support knob timer		
100	C00086547				timer knob		
101	C00770999				knob spring timer		
102	C00086548				pushbotton switch		
103	C00086549				pushbotton switch		
104	C00086550				timer		
105	C00086551				led		
106	C00085343				switch nc		
106	C00085344				switch na+na		


1190190m Spare parts list

Ref.	Code	From	To S/N	Substitute	Description	Notice	Industrial
106	C00085414				switch na		
107	C00085416				kit com escovas secador iar		
108	C00085417				kit suporte fixo+movel iar		
109	C00077230				cablagem com escovas iar		
110	C00770211				klemveer sensorborstel (was		
111	C00085418				injector iar		
112	C00085419				tubo da gaveta ao injector iar		
113	C00077046			1 x C00077042	support top		
999	C00063403				top hinge block black		
999	C00063404				bottom hinge block		
999	C00087383				door hook		
999	C00089557				locking assembly		
999	C00770047				washer		
999	C00770140				klemveer waterreservoir (was		
999	C00770144				wiring fixing (ex 810144)		
999	C00770241				condensator 10 mf (was 810241)		
999	C00770243				terminall (was 810243)		
999	C00770295				afvoerslang mea (was 810295)		
999	C00770315				verwarmingselementscrew 4,2x9,5		
999	C00770328				rooster		
999	C00770345				ring condensor		


Notices


n1040228: Replacing the belt.


To replace the belt, perform the following instructions:
1) Check that there are no rubber residues in the motor pulley (photo 1).
2) Position the dryer on its front, remove the back panel and check that the basket opening lip is positioned correctly see photo 3 and 4.
3) Remount the belt and check that it is positioned correctly on the motor pulley (1-2 slots from the bottom), perform one complete turn of the basket by hand to stabilize the belt positioning.








Foto 1



Posizione cesto non corretta
Foto 2
Posizione cesto corretta
Il labbro bocca cesto deve essere esterno alla parete dell'autolubrificante


Labbro bocca cesto
Foto 3

Electric schemes and links

Cod. ce036700

CE036700



LEGENDA


GAD	=	FILTRO RETE	P	=	POMPA
IA	=	TASTO ANTIPIEGA	Pp	=	TASTO START CICLO
IG	=	TASTO ON–OFF	R	=	RESISTENZA
L1	=	LAMPADA CESTO	S1	=	SPAZZOLA 1
LED1	=	LED ON–OFF	S2	=	SPAZZOLA 2
LED2	=	LED FILTRO	T	=	TIMER
LED3	=	LED GALLEGGIANTE	T1	=	TERMOSTATO
M	=	MOTORE	T2 T3	=	TERMOSTATO RESISTENZA
Mc	=	MICRO PORTA	EV	=	ELETTROVENTILATORE
Mcg	=	MICRO GALLEGGIANTE	C	=	CONDENSATORE

Legend

Legend: ce036700

Electric schemes and links

Cod. se095900



LEGENDA

GAD	=	FILTRO RETE	P	=	POMPA
IA	=	TASTO ANTIPIEGA	Pp	=	TASTO START CICLO
IG	=	TASTO ON-OFF	R	=	RESISTENZA
L1	=	LAMPADA CESTO	S1	=	SPAZZOLA 1
LED1	=	LED ON-OFF	S2	=	SPAZZOLA 2
LED2	=	LED FILTRO	T	=	TIMER
LED3	=	LED GALLEGGIANTE	T1	=	TERMOSTATO
M	=	MOTORE	T2 T3	=	TERMOSTATO RESISTENZA
Mc	=	MICRO PORTA	EV	=	ELETTROVENTILATORE
Mcg	=	MICRO GALLEGGIANTE	C	=	CONDENSATORE

Legend

Legend: se095900