
INDESIT company



Model type:
IDL600EU.2

Commercial code:
F040887

# General notes

## Technical Documentation guidelines

---

---

You can find herewith some generic information to simplify cunsulting of technical documentation:

1. Models of same range share the same exploded views, which report the richest set of spare parts:generally, a model does not necessarly have a related spare part for each particular shown on exploded views.

2. Some spare parts can not be represented directly on the exploded views (instruction booklets, specific kit, etc...). You can find those codes in the spare parts list with the same reference of particular where spares are installed or with references 099, 999. Instruction booklets, once managed, appear with 000 reference.

3. On the higher right site of each exploded view there is a serial number which indicates the beginning of the production of certain range:some models might have more than an exploded view for a given category, each distinguished by a different serial no.and linked to another spare parts list, In this case, serial no. is required to supply the right spare part code. Exploded view to be considered is the one with a more recent serial no. but previous than the one of the model that needs assistance.

4.Exploded views might require further updates even after publishing. Addition of new spares will go on following the already existing numeration references. Revision number of an exploded view is shown into last four digits of serial number into upper right hand corner.

5.The spare parts list associated to an exploded view shows related codes of spares managed for a certain model; for each spare part other informations are available:


REF: reference no of spare into a table; SUBSTITUTE: list of spare(s) which can replace a code but that keeps same functional characteristics

INDUSTRIAL CODE: list of variables of a model (shown into model label) where such spare is used; NOTICE: code of information(s) to refer to complete technical intervention, track for changes or to find correct spare part code.

6. Some notices, into a same section are generic therefore cannot be directly linked to a spare part. In order to assist a model in the best way as possible, it is helpful to pay attention to all notices and constantly verify documentation updates

7.Technical documentation cover shows model name and its commercial codes

2220110 Exploded views




2220110 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 000 | C00143926 | | | | instruction book bg-cs-uh-hr-sr-sk | | |
| 000 | C00143927 | | | | instruction book en-fr-nl-es-pt-pl- | | |
| 001 | C00092417 | | | 1 x C00093154 | left side panel lh polar | | |
| 002 | C00075715 | | | | rear cover | | |
| 003 | C00033591 | | | | rear support - top | | |
| 004 | C00142986 | | | | cover white(pw) 'indesit evo3' | | |
| 005 | C00057504 | | | | hook - top cover retention | | |
| 006 | C00085024 | | | 1 x C00037135<br>1 x C00297907<br>1 x C00297909<br>1 x C00297910 | catch plate (cabinet) | | |
| 007 | C00141317 | | | | top and side door seal (1638mm) | | |
| 009 | C00092418 | | | 1 x C00093154 | right side panel polar | | |
| 010 | C00094117 | | | | rail back stop evo3 | | |
| 011 | C00094116 | | | 1 x C00094112 | basket runner - upper evo3 | | |
| 012 | C00094112 | | | | runner assembly | | |
| 013 | C00094118 | | | | runner end stop | | |
| 014 | C00109659 | | | 1 x C00110518 | upper basket noclik/clak markii | | |
| 015 | C00097098 | | | | flap upper basket light blu 278 | | |
| 016 | C00056397 | | | 1 x C00054825 | lower basket 'lsv61ix' | | |
| 017 | C00091600 | | | | rear support - middle | | |
| 018 | C00091601 | | | | lower rear support hot or cold | | |
| 019 | C00143383 | | | | radio interference suppressor rohs | | |
| 020 | C00054830 | | | | drain hose fastener | | |
| 021 | C00143005 | | | | plinth panel swell | | |
| 022 | C00109991 | | | | adjustable foot | | |
| 023 | C00056010 | | | | foot support x | | |
| 024 | C00092555 | | | | foot 155mm | | |
| 025 | C00118842 | | | | tray on bottom of tub 60cm | | |
| 026 | C00119016 | | | | front support lower 60cm npe | | |
| 027 | C00076390 | | | | front panel soundproofing l.i.60cm | | |
| 029 | C00079013 | | | | door spring adjuster | | |
| 030 | C00054932 | | | | frame support for tub seal 60cm | n1045047 | |
| 032 | C00104638 | | | | basket roller axis | | |
| 033 | C00056347 | | | | lower basket wheel | | |

2220110 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 034 | C00078869 | | | | cutlery basket divider | | |
| 035 | C00094191 | | | 1 x C00109840 | upper basket roller evo3 | | |
| 036 | C00094189 | | | | roller axle upper basket | | |
| 037 | C00082457 | | | | sponge | | |
| 038 | C00097097 | | | | cutlery basket | | |
| 042 | C00054833 | | | | top for front support | | |

2220220 Exploded views




2220220 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00054925 | | | | upper was basket guide casing | | |
| 002 | C00144315 | | | | top spray arm nut with seal (rohs) | | |
| 003 | C00110526 | | | | water supply distribution assembly | | |
| 004 | C00110527 | | | | upper wash arm feed pipe | | |
| 005 | C00075746 | | | | upper wash arm curved set | | |
| 006 | C00143371 | | | 1 x C00280937 | supply cable schuko rohs | | |
| 008 | C00144176 | | | | inlet hose 1500mm | | |
| 011 | C00054863 | | | 1 x C00142344 | central filter | | |
| 012 | C00145075 | | | | stainless steel outlet filter | | |
| 013 | C00081164 | | | 1 x C00142344 | filter cylindrical | | |
| 014 | C00061929 | | | | outer fine rotating polyester filter | | |
| 015 | C00054854 | | | | sump fixing ferrule | | |
| 016 | C00054828 | | | | gasket - sump fixing ring | | |
| 017 | C00143739 | | 70318... | | drain pump 230v 50hz evo3 rohs | n1045133 | |
| 017 | C00143766 | 70319... | | | drain pump (td) | | |
| 018 | C00054869 | | | | drain hose | | |
| 019 | C00081162 | | | | container - overflow unit | | |
| 020 | C00143107 | | | | microswitch acquastop rohs | | |
| 021 | C00058843 | | | | float - overflow unit | | |
| 022 | C00095801 | | | | pressure hose clip evo3 | | |
| 023 | C00094154 | | | | pipe pressostat lvs evo3 | | |
| 024 | C00143740 | | | | pressure switch 90 71 evo3 rohs | | |
| 025 | C00111855 | | | 1 x C00115348 | tube water inlet electrovalve/air- | | |
| 026 | C00054868 | | | | tube - softener/sump l.(480mm) | | |
| 030 | C00110611 | | | | inlet valve | | |
| 031 | C00086801 | | | | protection electrovalve | | |
| 032 | C00094171 | | | | water softener adjustable evo3 | | |
| 034 | C00144235 | | | | retaining ring - softener rohs | | |
| 035 | C00041088 | | | | salt cap | | |
| 036 | C00005819 | | | | salt funnel | | |
| 038 | C00055005 | | | | pump cover | | |
| 039 | C00054917 | | | | seal 'o'ring (23,81x2,62) | | |
| 040 | C00094143 | | | 1 x C00141158 | set sump evo3 | | |
| 041 | C00079016 | | | | pipe rubber sump-pump | | |
| 042 | C00094157 | | | 1 x C00142435 | high pressure sensor assembly | | |

2220220 Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 043 | C00076628 | | | | tub spring | | |
| 044 | C00076627 | | | | wash motor/pump assy 220v-60w | | |
| 045 | C00094159 | | 60903... | | overflow connector evo3 | | |
| 045 | C00196353 | 60904... | | | overflow connector evo3 | | |
| 046 | C00075695 | | | | connection gasket overflow | | |
| 047 | C00143580 | | 60903... | | bodytop overflow evo3 rohs | | |
| 047 | C00196352 | 60904... | | 1 x C00094159<br>1 x C00143580 | bodytop overflow evo3 rohs | | |
| 048 | C00144189 | | | | cap corner for supp.wash.blade | | |
| 049 | C00144196 | | | | support - lower wash arm bush | | |
| 050 | C00078394 | | | | outlet pump support | | |
| 051 | C00057710 | | | 1 x C00091568 | suction motor oven bottom | | |
| 052 | C00057684 | | | | washing heating element 2000w | | |
| 053 | C00094182 | | | | lower wash arm | | |
| 054 | C00084600 | | | | o ring seal 38 mm | | |
| 055 | C00144335 | | | | ring-nut for air-flow body rohs | | |
| 057 | C00141308 | | | 1 x C00141655 | air break + turbine evo3 | | |
| 058 | C00094152 | | | | external pipe (hidden heating | | |
| 062 | C00098769 | | | | upper wash arm seal | | |
| 099 | C00040005 | | | 1 x C00033026 | grease amblig ta 1 gr. | | |
| 099 | C00073917 | | | | clamp for pump cover | | |
| 099 | C00075678 | | | | clamp for electrovalve evo3 | | |
| 099 | C00077010 | | | | clamp washing heating element | | |
| 099 | C00084479 | | | | hose clamp | | |

2220320D Exploded views



2220320D Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 001 | C00051755 | | | | rinse aid cap (pair) raised & flush | | |
| 002 | C00143801 | | | | electrodisp.(no lamp rinseaid- | | |
| 003 | C00091543 | | | 1 x C00290247 | door seal lower 60cm | | |
| 003 | C00108981 | | | 1 x C00290242 | inner door panel | | |
| 004 | C00085358 | | | | microswitch | | |
| 005 | C00094128 | | | 1 x C00195887 | locking assembly evo3 | | |
| 006 | C00143538 | | | | timer bit100.1 'e9' rohs + | | |
| 008 | C00143369 | | | | 8 functions selector rohs | | |
| 009 | C00142650 | | | | on-off switch (double pole) (dw) | | |
| 010 | C00112905 | 70318... | | | wiring harness assembly | | |
| 010 | C00256801 | 70319... | | | parallel wiring harness assy | | |
| 011 | C00096881 | | | 1 x C00112262 | pilot light red 230v ra2,5 ind. | | |
| 012 | C00144847 | | | | dashboard white(pw) idl600eu.2 | | |
| 013 | C00143006 | | | | on-off push button - white | | |
| 014 | C00143007 | | | | white(pw) push-button indesit | | |
| 015 | C00143003 | | | | knob - white | | |
| 016 | C00143007 | | | | white(pw) push-button indesit | | |
| 017 | C00143000 | | | | bowed outer door shell - white | | |
| 018 | C00065127 | | | 1 x C00054815 | hinge item, right | | |
| 019 | C00096996 | | | | hinge assembly 'lvs evo3' | | |
| 020 | C00058776 | | | | washer d = 6 mm | | |
| 021 | C00048504 | | | | hinge pin | | |
| 022 | C00065128 | | | 1 x C00054817 | hinge item, left | | |
| 023 | C00075689 | | | | door spring | | |
| 024 | C00066426 | | | | tube hinge spring | | |
| 025 | C00075693 | | | | gaffel x door spring | | |
| 026 | C00108978 | | | | door spacer assy indesit evo3 | | |
| 028 | C00143541 | | | | start/reset pcb card | | |
| 029 | C00096882 | | | | pilot light red 12v r 2,5 indes. | | |
| 030 | C00097419 | | | | light track lamp 'indesit' evo3 | | |
| 031 | C00098134 | | | | door detergent electrodispenser | | |
| 032 | C00140679 | | | | seal spring | | |
| 099 | C00076108 | | | 1 x C00012687 | screw canoe klip | | |
| 099 | C00084911 | | | 1 x C00304782 | screw 3.5x9.5 | | |
| 099 | C00085526 | | | | screw aflls 4x9 tcb61-tp20 | | |

2220320D Spare parts list

| Ref. | Code | From | To S/N | Substitute | Description | Notice | Industrial |
|---|---|---|---|---|---|---|---|
| 099 | C00094120 | | | | fixing bolt inner door/dashboard | | |
| 099 | C00094141 | | | | fixing screw inner/outer door | | |

Notices

## n1045048: BIT 100 CARD INITIALIZATION

---

Free-standing dishwasher

1- Close the door and switch the dishwasher on.
2- Wait for the test cycle to start ( 2 LEDs light up or "ROD" appears on dishwashers with display).
3- Wait 10 seconds ( dishwasher will start to fill water...)
N.B. If the cycle fails to start the card has probably already initialized, so proceed to point 5.
4- To reset the test cycle turn the programme button to reset or hold down the start/reset button for 5 seconds. (Wait for the buzzer to beep three times or if the dishwasher does not have a buzzer, wait for the programme LEDs to switch off.)
5- To check the aforementioned steps have completed successfully, select a programme and see if it starts; (reset it after this check).
6- The dishwasher is ready for the customer.

Built-in dishwashers

1- Close the door and switch the dishwasher on.
2- Wait for the test cycle to start
3- Wait 10 seconds ( the dishwasher will start to fill...)
N.B. If the cycle fails to start the card has probably already initialized, so proceed to point 5.
4- To reset the cycle, open the door (2 LEDs lit up) and press the programme button for three bips of the buzzer (or until the programme LEDs go off for dishwashers with no buzzer).
5- To check the aforementioned steps have completed successfully, press the select programme button and check that the indicator light beside the corresponding programme comes on.
6- The dishwasher is ready for thecustomer.

## n1045133: New thermoprotected drain pump in parallel with wash electric pump

---

The drain pump electrical connection has been modified from a configuration in series with the wash electric pump to one in parallel.

The drain pump in series with the wash electric pump is fed through the wash electric pump causing a voltage drop equal to -15V (diagram N1045133-134FIG1).

The drain pump in series with the wash electric pump is electrically fed directly by the F-N line, without any voltage drop (diagram N1045133-134FIG1).

New parts:
Wiring in parallel
C00118767(Rohs 143766) - thermoprotected drain pump 220/240V 50HZ 26W - picture (N1045133-134FIG3)

Premodification parts:
Wiring in series
C00112306(Rohs 143739) - drain pump 230V 50HZ 22W - picture (N1045133-134FIG4)

The codes of the new and premodification wirings are given in note N1045129.


Important!!
The thermoprotected drain pump cannot be installed on premodification dishwashers.
The non-thermoprotected drain pump cannot be installed on modified dishwashers.

Models/serial nos. affected by modification:
cc29511 - s/n 60316.0001 - LI620
cc29930 - s/n 60323.0001 - DI6
cc29931 - s/n 60320.0001 - DI620
cc29943 - s/n 60401.0001 - LV640AWH
cc30300 - s/n 60401.0001 - LV660ABKFR
cc30301 - s/n 60401.0001 - LV660AIXFR
cc32006 - s/n 60305.0001 - IDL50EU.2
cc32215 - s/n 60306.0001 - IDL55EU.2
cc32220 - s/n 60306.0001 - IDL55DE.2
cc32221 - s/n 60307.0001 - IDL50SK.2
cc32224 - s/n 60401.0001 - IDL55SDE.2
cc32271 - s/n 60322.0001 - IDLB2EU
cc33223 - s/n 60222.0001 - DVG622IX
cc33614 - s/n 60401.0001 - LVR640AAN
cc34119 - s/n 60307.0001 - IDL55IT.2
cc34120 - s/n 60309.0001 - IDL55SIT.2
cc34457 - s/n 60222.0001 - IDL502FR.2
cc34458 - s/n 60306.0001 - IDL552FR.2
cc34499 - s/n 60222.0001 - IDL50SEU.2
cc34518 - s/n 60222.0001 - L63EU.2
cc34865 - s/n 60222.0001 - IDL500FR.2
cc35314 - s/n 60306.0001 - IDL57PT.2
cc36154 - s/n 60306.0001 - IDL553FR.2
cc39329 - s/n 60222.0001 - IDL506FR.2
cc39330 - s/n 60306.0001 - IDL556FR.2
cc39331 - s/n 60306.0001 - IDL556SFR.2
cc40041 - s/n 60414.0001 - IDL42EU.C
cc40220 - s/n 60430.0001 - IDL42FR.C
cc30299 - s/n 60418.0001 - LV660AWHFR
cc29939 - s/n 60421.0001 - LV620BK
cc29940 - s/n 60421.0001 - LV620WH
cc29941 - s/n 60421.0001 - LV620IX
cc29946 - s/n 60422.0001 - LV640AIX
cc29942 - s/n 60424.0001 - LV640ABK
cc29512 - s/n 60501.0001 - LI640A
cc33942 - s/n 60501.0001 - LI641A
cc40916 - s/n 60502.0001 - L6064EU
cc40911 - s/n 60502.0001 - L6061EU

cc37341 - s/n 60502.0001 - L62IT.2
cc35316 - s/n 60502.0001 - L61EU.2
cc29907 - s/n 60502.0001 - L61AG
cc34283 - s/n 60529.0001 - IDL52EU.2
cc41049 - s/n 60605.0001 - L65IT
cc23510 - s/n 70618.0001 - D61EX50-60
cc29912 - s/n 70320.0001 - L63AUS
cc29913 - s/n 70326.0001 - L63XAUS
cc29921 - s/n 70318.0001 - LV650AIX
cc29922 - s/n 70227.0001 - LV650AALU
cc29923 - s/n 70329.0001 - LV650AOW
cc29924 - s/n 70227.0001 - LV650AWH
cc29925 - s/n 70227.0001 - LV650ABK
cc30304 - s/n 70326.0001 - LI660A
cc30369 - s/n 70323.0001 - DI630A
cc32217 - s/n 70326.0001 - IDL51EU.2
cc33229 - s/n 70326.0001 - DVG652AIX
cc33616 - s/n 70326.0001 - LVR670AN
cc33617 - s/n 70326.0001 - LVR670OW
cc33751 - s/n 70326.0001 - LVX12-45IX
cc33944 - s/n 70329.0001 - LI661A
cc34502 - s/n 70326.0001 - IDL60SAUS.2
cc34519 - s/n 70115.0001 - IDTMEU
cc37546 - s/n 70326.0001 - L6049FR
cc40887 - s/n 70319.0001 - IDL600EU.2
cc40888 - s/n 70319.0001 - IDL600SEU.2
cc40889 - s/n 70129.0001 - IDL750SEU.2
cc40891 - s/n 70122.0001 - IDL750EU.2
cc41165 - s/n 70327.0001 - IDL63EU.2
cc41166 - s/n 70319.0001 - IDL6021EU.2
cc41203 - s/n 70326.0001 - IDL550SIT.2
cc41204 - s/n 70326.0001 - IDL600IT.2
cc41205 - s/n 70326.0001 - IDL600SIT.2
cc42061 - s/n 70326.0001 - DI623A
cc42062 - s/n 70301.0001 - DI650A
cc42063 - s/n 70326.0001 - DVG623BK
cc42065 - s/n 70325.0001 - DVG623WH
cc42242 - s/n 70326.0001 - IDL6049SK.2
cc43218 - s/n 70301.0001 - DI653A
cc43942 - s/n 70326.0001 - DVGN623BK
cc43944 - s/n 70326.0001 - DVGN623WH
cc47650 - s/n 70326.0001 - L64AUS
cc47651 - s/n 70326.0001 - L64XAUS
cc39332 - s/n 70301.0001 - IDL706FR.2
cc34459 - s/n 60306.0001 - IDL555SFR.2
cc32227 - s/n 60222.0001 - L63SK.2
cc33212 - s/n 60222.0001 - DVG621IX


N1045133/134FIG1


Drying pump connected electrically in series to the motor washing




N1045133/134FIG2

Drying pump connected electrically in parallel to the motor washing







## Electric schemes and links

Cod. 16001738100



# Legend

Legend: 16001738100

| | | | |
|---|---|---|---|
| A.. | Timer contact | LPA | Door open |
| AQS | Aquastop electrovalve | LPR | Prewash LED |
| B.. | Timer contact | LRI | Rinse LED |
| C | Condensor | LS | Mains LED -Pilot lampe On/Off |
| C.. | Timer contact | LSB | Polisher LED |
| CL | Slow cam | LSC | Cycle ranning lamp |
| CM | Wash pump motor connector | LSE | Acquastop LED |
| CN | Connector | LSS | Salt LED |
| CV | Fast cam | LV | Fan off lamp |
| D-ED | Dispenser - Electric dosing device | M | Terminal box |
| D.. | Timer contact | MB | Polisher dip-switch |
| DB | Brightener dispenser | ME | Acquastop dip-switch |
| DD | Display - Detergent dispenser | ML | Wash motor |
| E1 | Cold water electrovalve | MM | Handle dip-switch |
| E2 | Regeneration electrovalve | MP | Door dip-switch |
| E3 | Hot water electrovalve | MR | Delay-timer motor - Terminal board |
| ECO | Saving switch | MT | Timer motor |
| ED | Detergent/Brightener dispenser | MTR | Fast forward timer motor |
| EV1 | Cold water electrovalve MM- Handle dip-switch | MV | Motor fan |
| EV1/2 | Half-load electrovalve | P | Pressure switch |
| EV2 | Regeneration electrovalve | P.. | Pressure switch contact |
| EV3 | Hot water electrovalve | P1 | Stage 1 pressure |
| EVC | Hot water electrovalve | P2 | Stage 2 pressure switch |
| EVF | Cold water electrovalve | PAP | High pressure switch |
| EVR | Regeneration water electrovalve | PO | Overflow pressure switch |
| F | Anti-interference filter ML- Wash motor | PS | Drain pump |
| FA | Radio interferences | PULS | Push-button panel |
| I1 | On/Off switch - Plus cycle switch -IEC cycle | R | Heating element |
| I1/2 | Switch half-load | R.D. | Delay rotary selector |
| I2 | Fast switch -IEC cycle switch (standard) - | RA | Heating element drying |
| I2H | 2-hour delay switch | ROT D | Delay rotary selector |
| I3 | Saving switch- Switch for cycle with no pre- | ROT. | Rotary selector |
| I4 | Switch for cycle fresh dirty | S | Motor overload cutout |

| | | | |
|---|---|---|---|
| I4H | 4-hour delay switch | SC | Selector cycli |
| I5-ICR | Fast cycle switch | SS | Salt detector |
| I6 | Soak cycle switch | ST | START |
| I6H | 6-hour delay switch | T.. | Delay-tymer contact |
| IAQS | Aquastop switch | T1 | Power supply earth cable -Thermostat 45?C |
| ID | Switch display | T2 | Lid earth -Thermostat 55?C |
| IE | Saving switch | T3 | Timer earth -Thermostat 65?C |
| IEXD | Exstra dray switch | T36 | 36?C N.O. Thermostat |
| IG | Main switch | T4 | Heating element earth |
| IMV | Off motor fan switch | T46 | 46?C N.O. Thermostat |
| IP | High temperature switch | T5 | Drain pump earth |
| IS | Cut-off switch | T57 | 57?C N.O. Thermostat |
| ISB | Polisher led switch | T6 | Wash motor earth |
| ISS | Salt LED switch | T8 | External lid earth |
| ITR | Heating element switch | TE | Relay switch |
| L | Mains LED | THP | Thermoprotector |
| L1 | Cycle 1 lamp | TM | Timer |
| L1/2 | Lamp cjcle half-load | TS | Safety thermostat |
| L2 | Cycle 2 lamp | TS 40 | Thermostat 40 ?C |
| L3 | Cycle 3 lamp | TS 50 | Thermostat 50 ?C |
| L4 | Cycle 4 lamp | TS 62 | Thermostat 62 ?C |
| L5 | Cycle 5 lamp | TS1 | Min. temperature thermostat |
| L6 | Cycle 6 lamp | TS2 | Max. temperature thermostat |
| LA | Drying LED | TT | Terminal box support earth |
| LAQ | Aquastop on lamp | Tcp | nner-door earthing connection |
| LC | Cycle ranning lamp | Tfa | Radio interference |
| LD | Delay activated lamp | Tml | Pump wash motor earthing connection |
| LE | Saving cycle | Tpg | Large door earthing connection |
| LH2 | 2-hour delay lamp | Tpi | Inspection door earthing connection |
| LH4 | 4-hour delay lamp | Tpr | Pressure switch |
| LH6 | 6-hour delay lamp | Tps | Discharge pump earthing connection |
| LL | Wash LED | Tr | Heating element |
| LP | High temperature LED | Tte | Delay-timer earthing connection |